

TLx49012 evaluation kit user guide

XENSIV™ angle sensors

About this document

Scope and purpose

This document describes the hardware and software functionality of the XENSIV™ TLx49012 evaluation kit ([TLX49012 EVAL KIT](#)).

Intended audience

This document is intended for hardware and software engineers involved in the evaluation of the XENSIV™ TLx49012 angle sensors.

About this product group

Infineon's portfolio of [XENSIV™ angle sensors](#) comprises single and dual-channel solutions suitable for all types of automotive, industrial, and consumer rotation applications. These high-precision sensors are available with Hall, anisotropic magnetoresistance (AMR), giant magnetoresistance (GMR), and tunneling magnetoresistance (TMR) sensor technology.

Target applications

- [Automotive body electronics](#)
- [Industrial motor drives and controls](#)
- [Drones](#)

Evaluation Board

This board is to be used during the design-in process for evaluating and measuring characteristic curves, and for checking datasheet specifications.

Note: PCB and auxiliary circuits are NOT optimized for final customer design.

Safety precautions

Safety precautions

Note: Please note the following warnings regarding the hazards associated with development systems.

Table 1 **Safety precautions**

	Caution: The heat sink and device surfaces of the evaluation or reference board may become hot during testing. Hence, necessary precautions are required while handling the board. Failure to comply may cause injury.
	Caution: The evaluation or reference board contains parts and assemblies sensitive to electrostatic discharge (ESD). Electrostatic control precautions are required when installing, testing, servicing or repairing the assembly. Component damage may result if ESD control procedures are not followed. If you are not familiar with electrostatic control procedures, refer to the applicable ESD protection handbooks and guidelines.
	Caution: The evaluation or reference board is shipped with packing materials that need to be removed prior to installation. Failure to remove all packing materials that are unnecessary for system installation may result in overheating or abnormal operating conditions.

Table of contents

Table of contents

About this document.....	1
About this product group.....	1
Safety precautions.....	2
Table of contents.....	3
1 The board at a glance.....	5
2 System and functional description	6
2.1 Getting started.....	6
2.2 Description of functional units	6
2.2.1 TLx49012 Satellite Board	6
2.2.2 Position sensors interface board (PSIB)	7
3 System design	8
3.1 Schematics	8
3.2 Layout	13
3.3 Bill of materials.....	13
4 Evaluation software	15
4.1 Requirements	15
4.2 Software download	15
4.2.1 Requesting access to a restricted evaluation kit tool.....	16
4.2.1.1 Browse for the required tool.....	16
4.2.1.2 Add the tool to cart	16
4.2.1.3 Questionnaire.....	17
4.2.1.4 Submit order	18
4.3 Software installation	18
4.4 Uninstalling the software	21
5 Using the evaluation software	22
5.1 Startup screen	22
5.2 Application settings.....	22
5.3 Main menu	24
5.4 IF Readout view	25
5.4.1 Readout control	26
5.4.2 TLx49012 extended configuration (Sensor Configuration)	27
5.4.2.1 Interface configuration	28
5.4.2.2 LUT configuration	29
5.4.2.3 User configuration	30
5.4.2.4 CMTF configuration	31
5.4.3 TLx49012 interface configuration detection	32
5.4.4 Interface selection for multiple interface mode	32
5.4.5 TLx49012 data display.....	33
5.4.5.1 TLx49012 data display – SPI mode	33
5.4.5.2 TLx49012 data display – ABZ mode.....	34
5.4.5.3 TLx49012 data display – PWM mode	35
5.4.5.4 TLx49012 data display – UVW mode.....	36
5.4.6 Sensor data logging	37
5.5 SPI readout view.....	38
5.5.1 Readout control	39
5.5.2 Register configuration	39

TLx49012 evaluation kit user guide

XENSIV™ angle sensors

Table of contents

5.5.3	TLx49012 Basic Configuration	40
5.5.4	TLx49012 Extended Configuration	41
5.5.5	Synchronization trigger	41
5.5.6	LUT registers.....	44
5.5.7	Readout control	45
5.5.8	TLx49012 SPI data display	46
5.5.8.1	TLx49012 SPI data display – Angle & Speed	46
5.5.8.2	TLx49012 SPI data display – Vector Length	47
5.5.8.3	TLx49012 SPI data display – X/Y/SysCal	47
5.5.9	Sensor data logging	48
5.6	Memory map.....	50
5.6.1	Memory map zones	51
5.6.1.1	Configurable zone	51
5.6.1.2	LUT zone.....	52
5.6.1.3	CMTP zone	53
5.6.2	Non-volatile memory programming	53
5.6.2.1	NVM programming using converted USER data	54
6	Related resources	55
Appendices		56
A	Appendix 1 – Hardware revision history.....	56
References.....		57
Glossary		58
Revision history.....		60
Disclaimer.....		61

TLx49012 evaluation kit user guide

XENSIV™ angle sensors

1 The board at a glance

1 The board at a glance

The TLx49012 evaluation kit enables the evaluation of the TLx49012 magnetic position sensor. The compatible software provided is designed to visualize data acquired from the TLx49012 position sensor with all supported interface settings and configurations.

The TLx49012 sensors are used to determine the position in applications where a rotational movement must be monitored. The versatility of the sensor can be seen in the multitude of supported output interfaces.

The TLx49012 evaluation kit offers a full set of features for sensor interfacing, data acquisition, interpretation and logging, volatile memory configuration, and sensor Customer Multi-Time Programmable memory (CMTP) configuration read/programming in limited cases.

The TLx49012 evaluation kit (V1.1) is shown in [Figure 1](#).




Figure 1 TLx49012 evaluation kit

Note: [Figure 1](#) is generic; the latest variant may include modifications.

The evaluation kit consists of the following components:

- TLx49012 Satellite Board
- Position sensors interface board (PSIB)
- Magnetic rotational knob with support for end/out of shaft positioning

Table 2 TLx49012 evaluation kit list with ordering part numbers

Name	Description	Infineon Sample Request (ISaR) SP number
TLx49012 EVAL KIT	TLE49012-S0001 evaluation kit, based on POSIF board	SP006064343
TLI49012 EVAL KIT	TLI49012 evaluation kit	SP006227376

2 System and functional description

This section provides a detailed description of the latest hardware design version of TLx49012 evaluation kit. See [Appendix 1 – Hardware revision history](#) for details on previous hardware variants.

2.1 Getting started

The evaluation kit is composed of two separate PCBs connected via clip-on surface mount technology (SMT) connectors:

- **Position Sensors Interface Board:** The primary purpose of this PCB is to control the system and to interface it with the PC via USB
- **TLx49012 Satellite Board:** The primary purpose of this board is to interface the sensors and to provide the necessary peripherals for analysis and measurements to the PSIB board

2.2 Description of functional units

2.2.1 TLx49012 Satellite Board

This section offers a detailed description of the latest hardware design version of the **TLI49012 Satellite Board**, version **V1.3**.

The hardware is composed of the following main blocks:

- **Onboard SMT connectors (J1-J4):** Used for connecting the satellite board to the PSIB MCU board
- **TLx49012 (U1):** Sensor under evaluation. The sensor is supplied with ON/OFF controlled 3.3 V from the PSIB board
- **DC-DC boost converter (IC1):** DC-DC boost converter used to generate the programming voltage necessary for CMTTP programming
- **External EEPROM (IC3, P1):** I²C External EEPROM used for storing board information
- **Auxiliary connector:** PCB-side connector for TLx49012 pinout. It can be used for debugging or connecting an external mounted TLx49012 sensor (Note that onboard sensor must not be populated on the satellite board for this use case) or using the satellite board on its own
- **LED (S1):** Used to indicate the presence of the programming voltage (DS1)

Attention: *The hardware version presented in this document is for the TLI49012 Satellite Board. The TLE49012 Satellite Board presents no hardware changes from this except for the modified silkscreen.*

2 System and functional description




Figure 2 TLx49012 Satellite Board 3D view with pinout – Top (left), bottom (right)

2.2.2 Position sensors interface board (PSIB)

The main purpose of the PSIB board is to control the system and to interface it with the PC via USB.

The hardware of the position sensor interface board consists of the following main blocks:

- **On board SMT connectors (S1-S4):** Used for connecting the satellite board to the PSIB microcontroller unit (MCU) board
- **Power supply:** The input voltage is provided by the 5 V USB supply. This input is then regulated to 3.3 V by TLS208D1EJV33 (IC1). Both the 5 V and the 3.3 V supplies are controlled using voltage trackers TLE4254GA (IC4) and TLE4250-2G (IC5)
- **Target Microcontroller (U1):** The main microcontroller is an XMC4700 in a PG-LQFP-100-25 package with 2048 KB of flash. This device does all the required data processing and handles the communication with the sensors and data forwarding to USB via the FTDI controller
- **FTDI controller (IC3):** This device is responsible for the USB communication, converting the UART interface to USB, and vice versa
- **USB connector (J1):** The board is equipped with a Micro-USB connector, which serves dual purposes:
 - Supplying the board with ~5 V from USB port
 - Ensuring data communication between the PC and microcontroller

3 System design

3 System design

3.1 Schematics




Figure 3 **TLx49012 Satellite Board schematic**

3 System design




Figure 4 Position sensors interface board (PSIB) schematic – page 1 of page 4




Figure 5 Position sensors interface board (PSIB) schematic – page 2 of page 4




Figure 6 Position sensors interface board (PSIB) schematic – page 3 of page 4




Figure 7 Position sensors interface board (PSIB) schematic – page 4 of page 4

3 System design

3.2 Layout

The design described in [Section 2.2.1](#) is physically implemented in PCB technology using a standard process with the following characteristics:

- **PCB material:** FR4
- **PCB thickness:** 1.65 mm $\pm$ 10%
- **Copper:** 2 layers top/bottom (35 μ m, 35 μ m thickness)




Figure 8 TLx49012 satellite board PCB layout – Top (left), bottom (right)

3.3 Bill of materials

Table 3 TLx49012 Satellite Board bill of materials

Designator	Description	Quantity	Assembled on PCB	Infineon part
C1, C4	100 nF 0402 16 V	2	Yes	No
C2	C0805C106K8PACTU	1	Yes	No
C3	10 μ F 0603 25 V	1	Yes	No
DS1	150060VS75000	1	Yes	No
IC1	MAX17291ATA+	1	Yes	No
IC3	M24512E-FMC6TG	1	Yes	No
J1, J2, J3, J4	DF23C-10DP-0.5V_91_	4	Yes	No
L1	LQM21DH100M70L	1	Yes	No
P1	MHDR1X4	1	No	No
R1, R2	2K2 0603	2	Yes	No
R3, R4	10K 0603	2	Yes	No
R5	4.75M 0603	1	Yes	No
R6	402K 0603	1	Yes	No
R7, R8	0R 0603	2	Yes	No
R9	10R 0603	1	Yes	No
R11	180R 0603	1	Yes	No

3 System design

Designator	Description	Quantity	Assembled on PCB	Infineon part
TP1	5019	1	Yes	No
U1	TLx49012 (XENSIV™ evaluated sensor)	1	Yes	Yes

4 Evaluation software

4 Evaluation software

Download the evaluation software via the [Infineon Development Center](#) online platform or [Infineon Development Center Launcher](#) application. It is recommended to install the Infineon Developer Center Launcher application before installing the evaluation software.

The software package contains:

- A graphical user interface (GUI) software for sensor evaluation
- FTDI CMD Drivers

4.1 Requirements

The TLx49012 evaluation kit hardware and software bundle is developed and tested on the following PC configurations:

- **Operating system:** Windows 10/Windows 11
- **RAM:** 8 GB (maximum RAM usage estimated at 250 MB, when data logging is ON)
- **Storage:** 512 GB (minimum required for installation: 250 MB, including dependencies)
- **CPU:** 3 GHz, 4 cores (lower performance CPUs might impact the performance of the GUI)

4.2 Software download

To access the evaluation software, go to the **Assets** section of your preferred platform and search for “TLx49012” and it displays as [XENSIV™ TLx49012 Angle Sensor Evaluation Kit](#).




Figure 9 Infineon Development Center – online tools

Note: **XENSIV™ TLx49012 Angle Sensor Evaluation Software** is only available for users registered with a myInfineon account and who have obtained a valid license through the request process outlined in [Section 4.2.1](#).

4.2.1 Requesting access to a restricted evaluation kit tool

This section describes the request procedure for accessing an Infineon restricted evaluation kit tool.

Note: Only users who have a valid account with myInfineon can place a request.

Note: Users must use the [Infineon Developer Center website](#). Tool request procedure is not available from the Infineon Developer Center (IDC) Launcher.

Follow these steps for requesting a software package:

1. Browse for software
2. Add to cart
3. Answer question form
4. Submit order

4.2.1.1 Browse for the required tool

- Navigate to the [IDC website](#) and “Tools” section. Enter a keyword for the target tool in the search bar ([Figure 10](#))
- Click the **Request** button to add the tool to the Cart

Note: If the target tool is already in the cart, the **Request** button will be disabled.
This procedure is exemplified for a generic tool. Apply the procedure for the target tool




Figure 10 Browse for the tool

4.2.1.2 Add the tool to cart

Click the **Request** button, you can view the cart content and continue with the request process ([Figure 11](#)).





Figure 11 View Cart

4 Evaluation software

4.2.1.3 Questionnaire

After requesting the tool from the cart, you must fill out the required details for a set of questions to proceed with the order (Figure 12).



My Space Tools Software

1 Cart 2 Additional information 3 Summary

Checkout: Additional information

Please fill the questionnaire(s) to proceed with your order.

XENSIV™ TLx49012 Angle Sensor Evaluation Software

- 1 First Name
- 2 Last Name
- 3 Company
- 4 Country
- 5 What is your target application type?
e.g. steering systems, window automation, seat adjustment, etc...
- 6 Your role?
e.g. Engineer, Marketing, Sales etc...
- 7 Your contact person at Infineon (e-mail address of your Infineon Sales/Technical Marketing contact)
(e-mail address contact)
- 8 Any other comments you would like to give us (optional)
- 9 Infineon's Privacy Policy

I agree that my personal data stated above may be shared with and processed by Infineon, meaning I may be contacted by Infineon via email and phone to provide me with marketing information about Infineon products, services & events based on my subscriptions & interactions, to perform surveys, and to improve my experience using data analytics. I additionally agree to Infineon transmitting my data to its licensed distributors & partners for contact regarding sales support matters via email and phone. I can revoke my consent any time.

Please visit Infineon's Privacy Policy for more information.

☐ I accept the privacy policy

Figure 12 Questionnaire

Question number 7 highlighted in Figure 12 is used to verify the user's right of access to the restricted tool. Tool owner can check with the Infineon contact if the request is valid.

Note: If a valid contact person is not provided, the request will be denied.

TLx49012 evaluation kit user guide

XENSIV™ angle sensors

4 Evaluation software

4.2.1.4 Submit order

As soon as the checkout is completed, you can see all your requests including status of the approval under [My Space > My Orders](#) (Figure 13).




Figure 13 Submit request

4.3 Software installation

1. Download the [XENSIV™ TLx49012 Angle Sensor Evaluation Kit](#) installer as mentioned in the earlier section and click the **Install** button

Note: Ensure that administrator rights are enabled before installation.

The installer file contains the following:

- Binaries/compiled objects needed for running the GUI
- FTDI driver for establishing a serial port communication with the onboard FTDI device
- .NET 4.8 online installer (needed only for older versions of Windows, if you do not have this already installed). Requires a stable Internet connection

2. Accept the License Agreement and click **Next**




Figure 14 Software installation – license agreement

4 Evaluation software

3. Select **Quick Installation** (recommended) and click **Install** to begin the installation process




Figure 15 Software installation step – quick installation

4. After the binaries have been copied to the installation folder, install the **FTDI CMD Drivers**.
If this driver is already installed on your PC, skip this operation. If this driver is not installed, the USB connection between the PC and the TLx49012 evaluation kit will not function




Figure 16 Software installation step – FTDI CDM drivers installation

5. Install **.NET Framework 4.8**. For operating systems starting from **Windows 10 build 1903** and later, this comes pre-installed. If the framework is not already installed, an active Internet connection is required to complete the installation process

TLx49012 evaluation kit user guide

XENSIV™ angle sensors

4 Evaluation software




Figure 17 Software installation – .NET 4.8 installation

6. You are notified when all installer processes are complete and a shortcut is created on the desktop by default. You can choose to run the installed **XENSIV™ TLx49012 Angle Sensor Evaluation Software** and click **Finish** to exit the setup




Figure 18 Software installation – completion

4 Evaluation software

4.4 Uninstalling the software

To uninstall the software package, go to **Start > Add or remove programs** and search for the **XENSIV™ TLx49012 Angle Sensor Evaluation Software**. Select **Uninstall** to delete the software from your PC.




Figure 19 **Software uninstall**

All installation files are deleted from the system except:

- FTDI driver, which can be uninstalled separately if required
- .NET 4.8 dependencies, which in most cases are part of the operating system

5 Using the evaluation software

This section describes all features and their usage of the XENSIV™ TLx49012 Angle Sensor Evaluation Software in correlation with the evaluation hardware. Ensure that the **TLx49012 evaluation kit** is connected to your PC via Micro-USB cable before exploring the next steps.

5.1 Startup screen

[Figure 20](#) shows the default screen of the XENSIV™ TLx49012 Angle Sensor Evaluation Software after startup. The graphical user interface (GUI) software monitors all USB ports and checks if any of them matches the signature of the **TLx49012 evaluation kit**. If a match is found, a new device will be displayed as shown in [Figure 20](#): “Port xx”. By selecting the device, the software will connect and flash the correct firmware for the target microcontroller. Software will also check for correct sensor detection.

Note: If the target does not have the latest firmware, it will be updated automatically.




Figure 20 Software usage – Startup screen

5.2 Application settings

In the top-left corner of the application, you can find the **Application Settings** button. Once it is selected, the settings menu will be displayed with multiple options ([Figure 21](#)):

- **Settings:** Displays the flashing application settings (described in detail after this section)
- **Fullscreen:** Toggles the application into full screen mode.
- **Report an issue!:** Send the user to a webpage where issues can be reported
- **User Guide:** Displays the user guide for this specific software
- **About:** Displays the current software and the firmware version
- **Quit:** Closes the application

5 Using the evaluation software




Figure 21 Software usage – Application Settings menu

Firmware flashing can be forced by selecting this option from **Settings** in the upper left menu ([Figure 22](#)). Select this option before connecting to the board (selecting the “Port xx”). This feature can be used for troubleshooting when automatic firmware updates encounter difficulties.




Figure 22 Software usage – Firmware flashing override

5 Using the evaluation software

5.3 Main menu

After successfully connecting to the evaluation kit, the software will display the main menu shown in [Figure 23](#). You can select between the main functionalities offered by the evaluation kit software by selecting the corresponding button:

- **IF Readout:** Implements various interface readouts and features of the TLx49012 sensor
- **SPI Readout:** Implements an SPI readout of different register values, while the sensor is in Test mode
- **Memory Map:** Implements various internal sensor memory operations, strictly for the **TLx49012** sensor
- **Sensor Configuration:** Implements a configuration window that can be used to configure the **TLx49012** sensor




Figure 23 Software usage – Main menu

5 Using the evaluation software

5.4 IF Readout view

The **Interface Readout** view is accessible by selecting the corresponding button in the software main menu. The open view is shown in [Figure 24](#).

This view displays, plots, and logs decoded data from the evaluated sensor through the configured interface. It also contains additional features and functionalities detailed in the next sections.

The **Interface Readout** view functionalities and features can be divided into the following groups, highlighted in [Figure 24](#):

1. Readout control
2. Volatile sensor memory configuration
3. TLx49012 interface configuration detection
4. Interface selection for multiple interface modes
5. TLx49012 data display
6. Sensor data logging




Figure 24 Software usage – IF Readout view

TLx49012 evaluation kit user guide

XENSIV™ angle sensors

5 Using the evaluation software

5.4.1 Readout control

The Readout control initiates continuous readout based on the active sensor configuration, retrieved from the TLx49012 sensor's volatile memory on the connected board. Depending on the communication protocol, four distinct views can be viewed (Figure 25). The possible modes are listed as follows accompanied with their corresponding read frequency:

- SPI Mode: 5000 Hz
- ABZ Mode: 1000 Hz
- UVW Mode: 5000 Hz
- PWM Mode: Variable 250 Hz to 4000 Hz




Figure 25 IF readout view – Possible readout views

5 Using the evaluation software

5.4.2 TLx49012 extended configuration (Sensor Configuration)

The TLx49012 is a highly configurable sensor. These configurations can be implemented through changing specific bitfields in the Memory Map. This can be implemented fully in the Memory Map view (shown in [Section 5.6](#)) by writing specific bits or alternatively, a straightforward combo-box/textbox approach is provided through the **Sensor Configuration** button. Clicking this button will prompt you to choose if you want to keep the current data or to perform a full sensor reset as shown in [Figure 26](#). This is implemented because the sensor has to be in Test Mode for the internal Memory Map to be accessed and changed, and as such, entering Test Mode will require a reset.




Figure 26 Sensor configuration – Data persistence

After you make a choice, the **Extended Sensor Configuration** window will be displayed. This window provides a simple but complete way to change the **USER_CONFIG** registers as well as the **LUT_CONFIG** registers.

The **Extended Sensor Configuration** view functionalities and features can be divided into the following groups, highlighted in [Figure 27](#):

1. Configuration selection tabs
2. View for current selection
3. Help button for explanations
4. The different buttons have the following functionalities:
 - **Reload:** The values from the registers are **all** re-populated into the UI, bringing the UI to the initial status
 - **Write:** Selected view with its associated configuration (as seen in the window) is written in the sensor. CRC is automatically calculated for both the USER and Look-up table (LUT) memory. After the write operation takes place, the sensor is soft-reset, and the registers from the bitmap configuration are re-read, and the values will be reloaded in the UI elements
 - **Reset:** The sensor is hard-reset through a power cycle (power off, power on), and the memory is re-read and UI re-populated
 - **Export as csv:** The values from the current view that are in the UI are logged and extracted into .CSV format. You will be prompted to enter a comment for the saved file, and upon confirming, the file will be saved in the selected location
 - **Import from csv:** This enables on-demand loading of the USER or LUT values. Clicking this button will prompt you to select a .CSV file. If the file contains invalid data values, the software will reject the input, and no changes will be made

5 Using the evaluation software




Figure 27 Extended sensor configuration – Configuration selection

Attention: The Extended Sensor Configuration window cannot be used with the A11 design step.

Attention: The Extended Sensor Configuration window can only be used with B11 design step sensor if the sensor's CMTP is fully fused. If not, the changes will not take effect. Additionally, certain bitfields are not configurable in the B11 design step sensors.

5.4.2.1 Interface configuration

The sensor's active communication interface is determined by the **if_mode** bitfield stored in volatile memory, which is loaded at startup from the CMTP. Alternatively, this interface can be changed temporarily through the **Interface configuration** tab in which the sensor is "soft-reset" by setting the appropriate bit in the **stat_en_0_reg**.

The **Interface Configuration** tab provides a simple way of interpretation and configuration of the **usr_config_1_reg** and **usr_config_2_reg** registers. The tab contains data about the possible changes that you can make through the UI elements as shown in [Figure 28](#) (8 drop downs and 2 text boxes):

- **Sensor Interface:** SPI/PWM/ABZ/UVW/ABZ + PWM/UVW + PWM
- ABZ Mode
- ABZ Z Mode
- ABZ Initial Position Pulses
- ABZ Pulses
- PWM Frequency
- PWM Starting Edge
- UVW Pole Pairs
- Sync Mode

- Sync Edge

Interface

Sensor Interface

UVW+PWM

ABZ

ABZ Mode

A/B Mode

ABZ Z Mode

Ungated for tz

ABZ Initial Position

Absolute Position Mode

ABZ Pulses

4082

UVW

UVW Pole Pairs

2

PWM

PWM Frequency

250 Hz

PWM Edge

Falling Edge

Sync

Sync Mode

Measurement Sync on configured ed

Sync Edge

Disable

Figure 28 Extended Sensor Configuration – Interface Configuration tab

5.4.2.2 LUT configuration

The volatile multipoint calibration (MPC) LUT area of the bitmap can be visualized and modified through the UI of the application in the LUT Configuration tab. This view offers automatic CRC recalculation, data change indication, and hover-enabled graph data points. This can be observed in [Figure 29](#).




Figure 29 Extended Sensor Configuration – LUT Configuration tab

TLx49012 evaluation kit user guide

XENSIV™ angle sensors

5 Using the evaluation software

5.4.2.3 User configuration

The **User Configuration** tab provides an extended way to see and configure the **usr_config_1_reg** to **usr_config_15_reg** registers. The UI elements are organized into **six** main categories, each having multiple drop downs, and text boxes used for input as shown in [Figure 30](#):

- Basic Interface Configuration
- Status Flags Configuration
- Input Spike Filtering Configuration
- Angle Configuration
- Dynamic Compensation Configuration
- System Configuration

Basic Interface Configuration

Sensor Interface SPI	Sync Mode Measurement Sync on configurec	SPI MOSI CRC Check MISO CRC inverted on read timec	ABZ Mode A/B Mode
PWM Frequency 2000 Hz	Sync Edge Disable	SPI MISO CRC Check MOSI CRC check enabled	ABZ Z Mode Ungated for tz
PWM Edge Falling Edge			ABZ Initial Position Absolute Position Mode
	UVW Pole Pairs 16		ABZ Pulses 4096

Angle Configuration

Angle Base 0	Angle Direction CCW	Ellipticity 0	Vector length minimum limit 6
X3 Base 0	Offset app X 0	OoS rotation for linear compensation 0	Vector length maximum limit 176
Y3 Base 0	Offset app Y 0		Safety mechanism vector length Fully compensated vector length

Input Spike Filter Configuration

IFA input spike filter Enabled	IFB input spike filter Enabled	IFC input spike filter Enabled
IFD input spike filter Enabled	IFE input spike filter Enabled	

Status Flags Configuration

CRC errors in CMTP Error Indicated	Voltage errors for VDD2V5x Error Indicated	Temperature below min error Error Indicated	Shear stress outside +/-100MPa Error Indicated
CRC errors in LUT area of bitmap Error Suppressed	Voltage errors for VDDA/VDDD Error Indicated	Temperature above max error Error Indicated	Diff stress outside +/-400MPa Error Indicated
CRC errors in User area of bitmap Error Suppressed	Undervoltage errors for VDDP Error Indicated	Test vectors out of range error Error Indicated	Overflow errors for ADC channels Error Indicated
	Overvoltage errors for VDDP Error Indicated		Overflow errors for Fw and CORDIC Error Indicated

Dynamic Compensation Configuration

Dynamic compensation enable Enabled	Dynamic compensation hysteresis +/-0.4 degree	Dynamic compensation factor K1 6	Number of samples for init 5
Dynamic compensation mode Continuous	Limit for Kalman prediction Disabled	Dynamic compensation factor K2 51	Time adjustment for dynamic comp 0
Dynamic compensation initialization Only on startup	Gradual adjustment of K1 during init K1 remains fixed at 1.0 during init		

System Configuration

Data sampling restart 1536 LSB16 (ca. 10C)	Angle base update by sys self-calib Disabled	System self-calibration setting Quadrature calibration, offset dis.	Multipoint calibration mode No multipoint calibration
ADC max range small range (default)			

Figure 30 Extended Sensor Configuration – User Configuration tab

5.4.2.4 CMTMP configuration

The **CMTMP Configuration** tab provides a way to convert the values saved in **Volatile Memory** tabs into Non-Volatile Memory data that can either be saved into a **.CSV** file for later use or writing to the sensor's internal memory. This view contains two checkboxes that you can select to write either the LUT or USER part of CMTMP or both, see [Figure 32](#).

Clicking the **Write** button will prompt you to confirm the selection as shown in [Figure 31](#).

Attention: *The sensor has a limited number of writes. In the current version of the sensor, the CMTMP can only be written once per address. This does mean that you can write the LUT and the USER section of the CMTMP only once. After this is implemented, the software will automatically check and stop the user from trying to write the section further. See [Memory map](#) section for more information about write cycles.*




Figure 31 Extended Sensor Configuration – CMTMP writing warning




Figure 32 Extended Sensor Configuration – CMTMP Configuration tab

5.4.3 TLx49012 interface configuration detection

The control panel is found in the **Interface Readout** view that displays the TLx49012 volatile memory configuration ([Figure 33](#)). The following parameters are displayed:

- Interface mode
- PWM Frequency (Hz)
- PWM Starting Edge
- Sync Mode
- Sync Edge
- ABZ Mode
- ABZ Initial position pulses
- ABZ Z Mode
- ABZ Pulses
- UVW Pole Pairs




Figure 33 IF Readout view – TLx49012 configuration

5.4.4 Interface selection for multiple interface mode

In dedicated modes, the sensor provides data through multiple interfaces. Those modes are ABZ + PWM or UVW + PWM. Whenever the software detects such a mode, an extra drop down is displayed to select between one of the two. The drop down is populated with the appropriate data based on the detected mode as shown in [Figure 34](#).




Figure 34 IF Readout view – Sensor Interface Selection

5.4.5 TLx49012 data display

During continuous readouts in the **Interface Readout** view, TLx49012 data is decoded and displayed in multiple UI elements.

These graphical elements are automatically reconfigured based on the configuration found in the sensor's internal volatile registers that you have updated, or that the sensor has loaded from the CMT. Data decoding and display is based on the value found in the **if_mode** field of the **usr_config_1_reg** and the sensor's chip variant.

5.4.5.1 TLx49012 data display – SPI mode

Interface readout data display in **SPI Mode** has the following UI elements (Figure 35):

1. Cartesian chart with values from 0 to 360 on the Y axis. Holds 180 samples on the X axis. The chart is updated at 200 Hz
2. Angular gauge for displaying the 0° to 360° angle position of the magnetic field
3. Labels for displaying decimal values for the current angle (degrees) and the raw register values [LSB16].
4. Plotted data can be cleared by clicking the **Clear** button




Figure 35 IF Readout View – TLx49012 display – SPI Mode

5 Using the evaluation software

5.4.5.2 TLx49012 data display – ABZ mode

Interface readout data display in **ABZ Mode** has the following UI elements (Figure 36):

1. Cartesian chart with values from 0 to 360 on the Y axis. Holds 180 samples on the X axis. The chart is updated at 200 Hz
2. Angular gauge for displaying the 0° to 360° angle position of the magnetic field
3. Labels for displaying decimal values for the current angle (degrees) and the counted pulses from the sensor
4. Plotted data can be cleared by clicking the **Clear** button

Note: If the sensor is configured in absolute position mode, the initial pulses will only be sent after a sensor Power-down reset. Stopping and starting the readout after the initial pulses will offer only relative position mode. This means that the angle displayed in the software will depend on the initial position of the magnetic field when the readout is started.




Figure 36 IF Readout view – TLx49012 display – ABZ Mode

5 Using the evaluation software

5.4.5.3 TLx49012 data display – PWM mode

Interface readout data display in the **PWM Mode** has the following UI elements (Figure 37):

1. Cartesian chart with values from 0 to 360 on the Y axis. Holds 180 samples on the X axis. The chart is updated at 200 Hz
2. Angular gauge for displaying the 0° to 360° angle position of the magnetic field
3. Labels for displaying decimal values for the current angle (degrees), duty cycle (%), and how many times an error has been detected
4. Plotted data can be cleared by clicking the **Clear** button. An additional button is present to hide/show the extra charts from (5). Hiding the additional UI elements can significantly improve the viewing experience of the other charts
5. An extra **Step Line Chart** can be visualized in this mode. This chart displays an additional view of the PWM signal from the sensor




Figure 37 Readout View – TLx49012 display – PWM Mode

5 Using the evaluation software

5.4.5.4 TLx49012 data display – UVW mode

Interface readout data display in **UVW Mode** has the following UI elements (Figure 38):

1. Cartesian chart with values from 0 to 360 on the Y axis. Holds 180 samples on the X axis. The chart is updated at 200 Hz
2. Angular gauge for displaying the 0° to 360° angle position of the magnetic field
3. Labels for displaying decimal values for the current angle range (degrees), current UVW pattern, electrical revolutions, and mechanical revolutions
4. Plotted data can be cleared by clicking the **Clear** button. An additional button is present to hide/show the extra charts from (5). Hiding the additional UI elements can significantly improve the viewing experience of the other charts
5. Three extra **Step Line Charts** can be visualized in this mode. These charts display the received states of the UVW data lines from the sensor for an easy visualization of the pattern change

*Note: Due to the way the UVW interface works, the angle cannot be exact. In this mode, the angle is reported as an angular range referenced to the magnet's initial position. The resulting angle reflects the initial condition of the magnet when the **Start** button is selected, because UVW delivers relative position data rather than an absolute angle.*




Figure 38 IF Readout View – TLx49012 display – UVW Mode

5 Using the evaluation software

5.5 SPI readout view

The **SPI Readout** view is accessible by clicking the corresponding button in the software main menu. The open view is shown in [Figure 41](#).

This view displays plots and logs decoded data from the evaluated sensor through the SPI protocol. It also contains additional features and functionalities detailed in the next sections.

Upon accessing this view, the software will check if the sensor is in Test Mode. If the sensor is not, the procedure to enter this mode will automatically be executed.

Attention: *Entering Test Mode requires the sensor to be powered down, resetting any configuration made in the IF Readout view. This does not apply when switching directly from the [Memory map](#) section, as the sensor is put in Test Mode when that view is initialized.*

The **SPI Readout** view functionalities can be divided into the following groups, as highlighted in [Figure 41](#):

1. Readout control
2. Register configuration
3. TLx49012 basic configuration
4. TLx49012 extended configuration
5. Synchronization Trigger
6. LUT registers
7. Readout control
8. TLx49012 SPI data display
9. Sensor data logging




Figure 41 Software usage – SPI Readout view

5 Using the evaluation software

5.5.1 Readout control

The readout control provides a way to start the continuous readout. By clicking the **Start** button, you can start an SPI continuous readout at a fixed frequency of 5000 Hz. The user interface will continuously update with the received data.

The continuous readout supports **In Frame** or **Next Frame** SPI communication schemes with or without **Device Status** clear. This can be changed in the **Readout Control** section of the software.

5.5.2 Register configuration

This window provides advanced control over the raw values of the registers through write and read operations on almost the full address range.

It supports single and continuous readouts with **In Frame** or **Next Frame** SPI communications schemes with or without **Device Status** clear. Fixed 1000 Hz read frequency.

The **Register Control** window has the following UI elements as seen in [Figure 42](#):

1. Cartesian chart with raw register data for continuous readouts
2. Numeric (HEX and DEC) display for the decoded raw SPI frame
3. Device Status explicit bit decoding
4. **Register Address** (HEX) input data is used for all read and write operations
5. **Reg. Write Data** (HEX) input data is used for all write operations to the selected **Register Address**
6. Device Power-On Reset
7. CSV logging with full SPI frame data and explicit bit decoding of the Device Stat

After each write operation, a sensor soft reset from bitmap, read, and GUI update is executed. Bitmap CRC check is disabled.

Attention: ***NO CMTP programming – only bitmap registers.***

Attention: ***It is up to you to select the correct type of SPI scheme for the desired register address. For In-Frame communication, “Register Address” is only limited to the maximum 7-bit value of 127 (0x7F).***

Attention: ***A few registers can be written/read locked depending on unlock password (access rights) and control register configurations (for example, `ifx_config`, `cmtp_word`).***

5 Using the evaluation software



Figure 42 SPI Readout view – Register Control

5.5.3 TLx49012 Basic Configuration

The **Basic Configuration** window offers ease of access to interpretation and configuration of the *angle_pred_reg*, *usr_config_7_reg*, *usr_config_11_reg*, and *ifx_config_9_reg* registers. When the window is initialized, the volatile memory of the TLx49012 is read and interpreted, being transcribed into the UI elements as shown in Figure 43 (4 drop downs and 2 text boxes):

- Angle Base (1)s
- Current Angle (truncated on 15bits) (1)
- Direction (1)
- Dynamic Comp Mode (2)
- Dynamic Comp Enable (2)
- ADC Blank Cycles (3)

In the **Basic Configuration** window, the following operations can be applied using the available buttons (4):

- **Reload:** The values from the internal memory are re-read and the UI elements are updated. A new angle is displayed
- **Write:** Selected configuration (as seen in the window) is written in the sensor. CRC is automatically calculated for the configuration to be written. After the write operation takes place, the sensor is soft-reset, and the registers from the bitmap configuration are re-read, and the values will be reloaded in the UI elements
- **Reset:** The sensor is hard-reset through a power cycle (power off, power on), and the memory is re-read and UI re-populated
- **Close:** The window is closed and the Interface readout view is updated with the new values from the volatile memory

5 Using the evaluation software




Figure 43 SPI Readout view – Basic Configuration

5.5.4 TLx49012 Extended Configuration

The **Extended Configuration** window offers ease of access to interpretation and configuration of the USER, LUT, and CMTF sections of the sensor's memory. For more information, see [Section 5.4.2](#).

5.5.5 Synchronization trigger

The sensor allows different control functions on the IFE pin for ease of use. The function assigned to the IFE pin depends on the user interface and configured setting:

- **SPI:** Latches the measured angle and angular velocity to dedicated synchronization registers
- **ABZ:** Triggers initial position pulses or a reset of the sensor logic
- **UVW:** Triggers a reset of the sensor logic
- **PWM:** Synchronizes the measured angle and continuously provides it via the PWM interface or triggers a reset of the sensor logic

This window has only the capability to send synchronization signals only when the configured interface is SPI. The sensitive edge on the IFE pin can be programmed to:

- Falling edge
- Rising edge (default)
- Falling and Rising edge
- No edge (function deactivated)

The **Synchronization Trigger** window has the following features and UI elements ([Figure 44](#)):

- Synchronized Angle. Available in Raw 14-bit [LSB] and in degrees [°] **(1)**
- Angle Synchronized Status **(1)**
- Angle Read Status **(1)**
- Synchronized Velocity. Available in Raw 14-bit [LSB] **(2)**
- Velocity Synchronized Status **(2)**
- Velocity Read Status **(2)**
- Synchronization Mode. Only mode 0 is active in this window **(3)**

TLx49012 evaluation kit user guide

XENSIV™ angle sensors

5 Using the evaluation software

- Synchronization Edge (3)

In the **Synchronization Trigger** window, the following operations can be applied using the available buttons (4):

- **Trigger:** The trigger signal is sent on the IFE line
- **Read:** The angle and velocity registers are read, and the UI is updated
- **Trigger + Read:** The trigger signal is sent on the IFE line, and the angle and velocity registers are read, and the UI is updated
- **Write:** Selected configuration (as seen in the window) is written in the sensor. CRC is automatically calculated for the configuration to be written. After the write operation takes place, the volatile memory will be re-read, and the values will be reloaded in the UI elements
- **Reset:** The sensor is hard-reset through a power cycle (power off, power on), and the memory is re-read and UI re-populated. **This action resets the Synchronization Edge configuration**




Figure 44 SPI Readout view – Synchronization Trigger, disabled

To use this window, select a **Synchronization edge** from the drop down and write it into the volatile memory using the **Write** button. After this process has been implemented and no issues have been displayed, the **Trigger** and **Trigger + Read** buttons become available.

To read a value, first use the **Trigger** button. This updates the internal register with the captured angle and velocity value. You can then use the **Read** button to request the values that were saved when the trigger signal was sent. A successful operation is shown in [Figure 45](#).

Additionally, you can use the **Trigger+Read** button to send the trigger signal to the sensor and read the value immediately after. This has the same outcome as clicking the **Trigger** and the **Read** button in quick succession.

Clicking the **Trigger** button multiple times before initiating a read operation causes the device to store only the value captured by the last trigger signal; earlier captured values are overwritten. This operation is also reflected in the Status group boxes as shown in [Figure 45](#).




Figure 45 SPI Readout view – Synchronization Trigger, Multiple Trigger signals




Figure 46 SPI Readout view – Synchronization Trigger, normal operation

5 Using the evaluation software

5.5.6 LUT registers

The volatile MPC LUT area of the bitmap can be visualized and modified through the UI of the application in the **Volatile LUT Registers Configuration** window. This method offers automatic CRC recalculation, data change indication, hover-enabled graph data points, and LUT Export and Import into .CSV format.




Figure 47 SPI Readout view – Volatile LUT Registers Configuration

In the **Volatile LUT Registers Configuration** window, the following operations can be applied using the available buttons:

- **Reload:** The values from the registers are re-read and the UI is re-populated
- **Write:** Selected configuration (as seen in the window) is written in the sensor. CRC is automatically calculated for the LUT to be written. After the write operation takes place, the registers will be re-read, and the values will be reloaded in the UI elements
- **Reset:** The sensor is hard-reset through a power cycle (power off, power on), and the memory is re-read and UI re-populated
- **Export as csv:** The values that are currently in the UI are logged and extracted into .CSV format. You will be prompted to enter a comment for the saved file, and upon confirming, the file will be saved in the selected location
- **Import from csv:** This button enables on-demand loading of the LUT values. Clicking this button will prompt you to select a .CSV file. If the file contains invalid data values, the software will reject the input, and no changes will be made. An example of a correctly exported/imported .CSV file is shown in [Figure 48](#)

5 Using the evaluation software

	A	B	C
1	Date	06.11.2025	
2			
3	Comment:		
4			
5			
6	Index	Name	Value[LSB16]
7	0	mpc_lut_data_0	0
8	1	mpc_lut_data_1	4096
9	2	mpc_lut_data_2	8192
10	3	mpc_lut_data_3	12288
11	4	mpc_lut_data_4	16384
12	5	mpc_lut_data_5	20480
13	6	mpc_lut_data_6	24576
14	7	mpc_lut_data_7	28672
15	8	mpc_lut_data_8	32768
16	9	mpc_lut_data_9	36864
17	10	mpc_lut_data_10	40960
18	11	mpc_lut_data_11	45056
19	12	mpc_lut_data_12	49152
20	13	mpc_lut_data_13	53248
21	14	mpc_lut_data_14	57344
22	15	mpc_lut_data_15	61440
23	16	mpc_lut_data_16	0
24	17	mpc_lut_data_17	4096
25	18	mpc_lut_data_18	8192
26	19	mpc_lut_data_19	12288
27	20	mpc_lut_data_20	16384
28	21	mpc_lut_data_21	20480
29	22	mpc_lut_data_22	24576
30	23	mpc_lut_data_23	28672
31	24	mpc_lut_data_24	32768
32	25	mpc_lut_data_25	36864
33	26	mpc_lut_data_26	40960
34	27	mpc_lut_data_27	45056
35	28	mpc_lut_data_28	49152
36	29	mpc_lut_data_29	53248
37	30	mpc_lut_data_30	57344
38	31	mpc_lut_data_31	61440
39	32	lut_word_crc	51143

Figure 48 SPI Readout view – LUT export file example

5.5.7 Readout control

The readout control provides the option of selecting three types of data for the readout based on the selection made in the **Data Selection** drop down (Figure 49):

- Angle & Speed readout:** By selecting the appropriate item and clicking the **Start** button, you can start a SPI continuous readout at fixed frequency of 5000 Hz. The user interface will continuously update with the received data from the sensor's **angle_pred_reg** and **angle_vel_reg** registers
- Vector length readout:** By selecting the appropriate item and then clicking the **Start** button, you can start a SPI continuous readout at fixed frequency of 5000 Hz. The user interface will continuously update with the received data from the sensor's **vec_len_reg** and **vec_len3_reg** registers
- X/Y/SysCal readout:** By selecting the appropriate item and then clicking the **Start** button, you can start a SPI continuous readout at fixed frequency of 1000 Hz. The user interface will continuously update with the received data from the sensor's **x3_spi**, **y3_spi**, **xn_spi** and **yn_spi** registers. In this view, you can observe, after multiple magnet turns, the effects of the system self-calibration results applied to the compensated parameters. This effect is most noticeable when the sensor and magnet are placed in the **Out-Of-Shaft** configuration




Figure 49 SPI Readout view – Readout Data Selection

TLx49012 evaluation kit user guide

XENSIV™ angle sensors

5 Using the evaluation software

There are also two additional options that you can select for the communication to be implemented **In Frame** and to clear device status at every readout. Those options are selected/unselected by the 2 checkboxes as shown in [Figure 50](#).




Figure 50 SPI Readout view – Readout Control

5.5.8 TLx49012 SPI data display

During continuous readouts in the **SPI Readout** view, TLx49012 data is decoded and displayed in multiple UI elements.

These graphical elements are automatically reconfigured based on the type of received data from the sensor and the selection made by you.

5.5.8.1 TLx49012 SPI data display – Angle & Speed

1. Angle & Speed data display in this mode includes the following UI elements ([Figure 51](#))
2. Cartesian chart with fixed Y axis for the calculated angle value in degrees. Holds 300 samples on the X axis. The chart is updated at 500 Hz
3. Angular gauge for displaying calculated angle in degrees
4. Cartesian chart with autoscaling on the Y axis for calculated velocity in RPM. Holds 300 samples on the X axis. The chart is updated at 500 Hz
5. Speed Gauge for displaying the current calculated velocity in RPM.
6. Labels for displaying decimal values for angle in degrees and velocity in RPM.
7. Plotted data can be cleared by clicking the **Clear** button.
8. An additional button is present to hide/show the velocity gauge/charts. Hiding these UI elements can significantly improve the viewing experience of the other charts




Figure 51 SPI Readout view – Angle & Speed view

5.5.8.2 TLx49012 SPI data display – Vector Length

Vector Length data display in this mode includes the following UI elements (Figure 52):

1. Cartesian Chart for Vector Length (value based on X_n/Y_n). Value is displayed raw in [LSB]. Holds 300 samples on the X axis. The chart is updated at 500 Hz
2. Cartesian Chart for Vector Length 3 (value based on X_3/Y_3). Value is displayed raw in [LSB]. Holds 300 samples on the X axis. The chart is updated at 500 Hz
3. Labels for displaying values for Vector Length and Vector Length 3
4. Plotted data can be cleared by clicking the **Clear** button




Figure 52 SPI Readout view – Vector Length

5.5.8.3 TLx49012 SPI data display – X/Y/SysCal

X/Y/SysCal data display in this mode includes the following UI elements (Figure 53):

1. Lissajous scatter plot for X_3 & Y_3 values. Values are displayed in (DEC). Holds 350 samples. The chart is updated at 200 Hz
2. Lissajous scatter plot for X_n & Y_n compensated values. Values are displayed in (DEC). Holds 350 samples. The chart is updated at 200 Hz
3. Labels for displaying values for $X/Y/X_n/Y_n$ /SysCal, vector length limits, and calculated vector length 3
4. Labels for displaying the current SysCal Parameters and the active status
5. Plotted data can be cleared by clicking the **Clear** button. Additional buttons are present that can be used to Zoom into the charts

5 Using the evaluation software




Figure 53 SPI Readout view – Vector Length

5.5.9 Sensor data logging

You have the option to select if the acquired data needs to be logged and extracted in .CSV format. By default, logging is disabled to minimize RAM usage. You can click on the **Logging** button (Figure 54), and if the state is changed to “ON”, the software will save all acquired data in RAM. Note that for protecting RAM usage, it is allowed to store maximum 1.000.000 points, if this limit is reached, a pop-up window will notify you, and data logging will be stopped.

After ending the measurements, you have the following options (Figure 54):

- Discarding acquired data, by clicking the **Discard** button
- Saving acquired data to disk in .CSV format by clicking the **Save** button




Figure 54 Software usage – Data logging control

The .CSV format implemented in this tool use as delimiter as the semicolon sign “;”. If the default separator of the operating system differs, you can use the “column split by delimiter” function of post-processing software (for example, Microsoft Excel).

The exported .CSV file has the following structure:

- **Header:** In this section, the software will log generic data (date, timestamp, sensor name, and user comment)
- **Data:** Each logged line consists of a data bundle containing:
 - Index
 - View Specific Data:
 - **Angle & Speed:** angle reg, device status (DEC), device status (HEX), Data (DEC), Data (HEX), Angle (deg), CRC (DEC), CRC (HEX), angle velocity reg, device status (DEC), device status (HEX),

TLx49012 evaluation kit user guide

XENSIV™ angle sensors

5 Using the evaluation software

Data (DEC), Data (HEX), Velocity (rpm), CRC (DEC), CRC (HEX), OFC, LFOK, DIAG, MAG, SUP, RST, OT, CAL

- **Vector Length:** vec_len_reg, device status (DEC), device status (HEX), Data (DEC), Data (HEX), CRC (DEC), CRC (HEX), vec_len3_reg, device status (DEC), device status (HEX), Data (DEC), Data (HEX), CRC (DEC), CRC (HEX), OFC, LFOK, DIAG, MAG, SUP, RST, OT, CAL
- **X/Y/X3/Y3:** X3 register, device status (DEC), device status (HEX), Data (DEC), Data (HEX), CRC (DEC), CRC (HEX), Y3 register, device status (DEC), device status (HEX), Data (DEC), Data (HEX), CRC (DEC), CRC (HEX), Vector Length 3 (Calculated), Xn (compensated) register, device status (DEC), device status (HEX), Data (DEC), Data (HEX), CRC (DEC), CRC (HEX), Yn (compensated) register, device status (DEC) device status (HEX), Data (DEC), Data (HEX), CRC (DEC), CRC (HEX), SYS CAL ON, SysCal Offset X register, device status (DEC), device status (HEX), Data (DEC), Data (HEX), CRC (DEC), CRC (HEX), SysCal Offset Y register, device status (DEC), device status (HEX), Data (DEC), Data (HEX), CRC (DEC), CRC (HEX), SysCal Ellipticity register, device status (DEC), device status (HEX), Data (DEC), Data (HEX), CRC (DEC), CRC (HEX), SysCal OoS Rotation register, device status (DEC), device status (HEX), Data (DEC), Data (HEX), CRC (DEC), CRC (HEX), OFC, LFOK, DIAG, MAG, SUP, RST, OT, CAL

An example of exported data for the X/Y/X3/Y3 view is shown in [Figure 55](#).

Time										Device Data										X										Y										X3										Y3										...																																							
0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99
Data: 2023-08-01 00:00:00																																																																																																			
Time: 13.42.50																																																																																																			
Sensor: T1490121_00000																																																																																																			
Comment:																																																																																																			
Sample X3 Reg: Device Data: Data1: Data2: Data3: Data4: Data5: Data6: Data7: Data8: Data9: Data10: Data11: Data12: Data13: Data14: Data15: Data16: Data17: Data18: Data19: Data20: Data21: Data22: Data23: Data24: Data25: Data26: Data27: Data28: Data29: Data30: Data31: Data32: Data33: Data34: Data35: Data36: Data37: Data38: Data39: Data40: Data41: Data42: Data43: Data44: Data45: Data46: Data47: Data48: Data49: Data50: Data51: Data52: Data53: Data54: Data55: Data56: Data57: Data58: Data59: Data60: Data61: Data62: Data63: Data64: Data65: Data66: Data67: Data68: Data69: Data70: Data71: Data72: Data73: Data74: Data75: Data76: Data77: Data78: Data79: Data80: Data81: Data82: Data83: Data84: Data85: Data86: Data87: Data88: Data89: Data90: Data91: Data92: Data93: Data94: Data95: Data96: Data97: Data98: Data99: Data100: Data101: Data102: Data103: Data104: Data105: Data106: Data107: Data108: Data109: Data110: Data111: Data112: Data113: Data114: Data115: Data116: Data117: Data118: Data119: Data120: Data121: Data122: Data123: Data124: Data125: Data126: Data127: Data128: Data129: Data130: Data131: Data132: Data133: Data134: Data135: Data136: Data137: Data138: Data139: Data140: Data141: Data142: Data143: Data144: Data145: Data146: Data147: Data148: Data149: Data150: Data151: Data152: Data153: Data154: Data155: Data156: Data157: Data158: Data159: Data160: Data161: Data162: Data163: Data164: Data165: Data166: Data167: Data168: Data169: Data170: Data171: Data172: Data173: Data174: Data175: Data176: Data177: Data178: Data179: Data180: Data181: Data182: Data183: Data184: Data185: Data186: Data187: Data188: Data189: Data190: Data191: Data192: Data193: Data194: Data195: Data196: Data197: Data198: Data199: Data200: Data201: Data202: Data203: Data204: Data205: Data206: Data207: Data208: Data209: Data210: Data211: Data212: Data213: Data214: Data215: Data216: Data217: Data218: Data219: Data220: Data221: Data222: Data223: Data224: Data225: Data226: Data227: Data228: Data229: Data230: Data231: Data232: Data233: Data234: Data235: Data236: Data237: Data238: Data239: Data240: Data241: Data242: Data243: Data244: Data245: Data246: Data247: Data248: Data249: Data250: Data251: Data252: Data253: Data254: Data255: Data256: Data257: Data258: Data259: Data260: Data261: Data262: Data263: Data264: Data265: Data266: Data267: Data268: Data269: Data270: Data271: Data272: Data273: Data274: Data275: Data276: Data277: Data278: Data279: Data280: Data281: Data282: Data283: Data284: Data285: Data286: Data287: Data288: Data289: Data290: Data291: Data292: Data293: Data294: Data295: Data296: Data297: Data298: Data299: Data300: Data301: Data302: Data303: Data304: Data305: Data306: Data307: Data308: Data309: Data310: Data311: Data312: Data313: Data314: Data315: Data316: Data317: Data318: Data319: Data320: Data321: Data322: Data323: Data324: Data325: Data326: Data327: Data328: Data329: Data330: Data331: Data332: Data333: Data334: Data335: Data336: Data337: Data338: Data339: Data340: Data341: Data342: Data343: Data344: Data345: Data346: Data347: Data348: Data349: Data350: Data351: Data352: Data353: Data354: Data355: Data356: Data357: Data358: Data359: Data360: Data361: Data362: Data363: Data364: Data365: Data366: Data367: Data368: Data369: Data370: Data371: Data372: Data373: Data374: Data375: Data376: Data377: Data378: Data379: Data380: Data381: Data382: Data383: Data384: Data385: Data386: Data387: Data388: Data389: Data390: Data391: Data392: Data393: Data394: Data395: Data396: Data397: Data398: Data399: Data400: Data401: Data402: Data403: Data404: Data405: Data406: Data407: Data408: Data409: Data410: Data411: Data412: Data413: Data414: Data415: Data416: Data417: Data418: Data419: Data420: Data421: Data422: Data423: Data424: Data425: Data426: Data427: Data428: Data429: Data430: Data431: Data432: Data433: Data434: Data435: Data436: Data437: Data438: Data439: Data440: Data441: Data442: Data443: Data444: Data445: Data446: Data447: Data448: Data449: Data450: Data451: Data452: Data453: Data454: Data455: Data456: Data457: Data458: Data459: Data460: Data461: Data462: Data463: Data464: Data465: Data466: Data467: Data468: Data469: Data470: Data471: Data472: Data473: Data474: Data475: Data476: Data477: Data478: Data479: Data480: Data481: Data482: Data483: Data484: Data485: Data486: Data487: Data488: Data489: Data490: Data491: Data492: Data493: Data494: Data495: Data496: Data497: Data498: Data499: Data500: Data501: Data502: Data503: Data504: Data505: Data506: Data507: Data508: Data509: Data510: Data511: Data512: Data513: Data514: Data515: Data516: Data517: Data518: Data519: Data520: Data521: Data522: Data523: Data524: Data525: Data526: Data527: Data528: Data529: Data530: Data531: Data532: Data533: Data534: Data535: Data536: Data537: Data538: Data539: Data540: Data541: Data542: Data543: Data544: Data545: Data546: Data547: Data548: Data549: Data550: Data551: Data552: Data553: Data554: Data555: Data556: Data557: Data558: Data559: Data560: Data561: Data562: Data563: Data564: Data565: Data566: Data567: Data568: Data569: Data570: Data571: Data572: Data573: Data574: Data575: Data576: Data577: Data578: Data579: Data580: Data581: Data582: Data583: Data584: Data585: Data586: Data587: Data588: Data589: Data590: Data591: Data592: Data593: Data594: Data595: Data596: Data597: Data598: Data599: Data600: Data601: Data602: Data603: Data604: Data605: Data606: Data607: Data608: Data609: Data610: Data611: Data612: Data613: Data614: Data615: Data616: Data617: Data618: Data619: Data620: Data621: Data622: Data623: Data624: Data625: Data626: Data627: Data628: Data629: Data630: Data631: Data632: Data633: Data634: Data635: Data636: Data637: Data638: Data639: Data640: Data641: Data642: Data643: Data644: Data645: Data646: Data647: Data648: Data649: Data650: Data651: Data652: Data653: Data654: Data655: Data656: Data657: Data658: Data659: Data660: Data661: Data662: Data663: Data664: Data665: Data666: Data667: Data668: Data669: Data670: Data671: Data672: Data673: Data674: Data675: Data676: Data677: Data678: Data679: Data680: Data681: Data682: Data683: Data684: Data685: Data686: Data687: Data688: Data689: Data690: Data691: Data692: Data693: Data694: Data695: Data696: Data697: Data698: Data699: Data700: Data701: Data702: Data703: Data704: Data705: Data706: Data707: Data708: Data709: Data710: Data711: Data712: Data713: Data714: Data715: Data716: Data717: Data718: Data719: Data720: Data721: Data722: Data723: Data724: Data725: Data726: Data727: Data728: Data729: Data730: Data731: Data732: Data733: Data734: Data735: Data736: Data737: Data738: Data739: Data740: Data741: Data742: Data743: Data744: Data745: Data746: Data747: Data748: Data749: Data750: Data751: Data752: Data753: Data754: Data755: Data756: Data757: Data758: Data759: Data760: Data761: Data762: Data763: Data764: Data765: Data766: Data767: Data768: Data769: Data770: Data771: Data772: Data773: Data774: Data775: Data776: Data777: Data778: Data779: Data780: Data781: Data782: Data783: Data784: Data785: Data786: Data787: Data788: Data789: Data790: Data791: Data792: Data793: Data794: Data795: Data796: Data797: Data798: Data799: Data800: Data801: Data802: Data803: Data804: Data805: Data806: Data807: Data808: Data809: Data810: Data811: Data812: Data813: Data814: Data815: Data816: Data817: Data818: Data819: Data820: Data821: Data822: Data823: Data824: Data825: Data826: Data827: Data828: Data829: Data830: Data831: Data832: Data833: Data834: Data835: Data836: Data837: Data838: Data839: Data840: Data841: Data842: Data843: Data844: Data845: Data846: Data847: Data848: Data849: Data850: Data851: Data852: Data853: Data854: Data855: Data856: Data857: Data858: Data859: Data860: Data861: Data862: Data863: Data864: Data865: Data866: Data867: Data868: Data869: Data870: Data871: Data872: Data873: Data874: Data875: Data876: Data877: Data878: Data879: Data880: Data881: Data882: Data883: Data884: Data885: Data886: Data887: Data888: Data889: Data890: Data891: Data892: Data893: Data894: Data895: Data896: Data897: Data898: Data899: Data900: Data901: Data902: Data903: Data904: Data905: Data906: Data907: Data908: Data909: Data910: Data911: Data912: Data913: Data914: Data915: Data916: Data917: Data918: Data919: Data920: Data921: Data922: Data923: Data924: Data925: Data926: Data927: Data928: Data929: Data930: Data931: Data932: Data933: Data934: Data935: Data936: Data937: Data938: Data939: Data940: Data941: Data942: Data943: Data944: Data945: Data946: Data947: Data948: Data949: Data950: Data951: Data952: Data953: Data954: Data955: Data956: Data957: Data958: Data959: Data960: Data961: Data962: Data963: Data964: Data965: Data966: Data967: Data968: Data969: Data970: Data971: Data972: Data973: Data974: Data975: Data976: Data977: Data978: Data979: Data980: Data981: Data982: Data983: Data984: Data985: Data986: Data987: Data988: Data989: Data990: Data991: Data992: Data993: Data994: Data995: Data996: Data997: Data998: Data999: Data1000: Data1001: Data1002: Data1003: Data1004: Data1005: Data1006: Data1007: Data1008: Data1009: Data1010: Data1011: Data1012: Data1013: Data1014: Data1015: Data1016: Data1017: Data1018: Data1019: Data1020: Data1021: Data1022: Data1023: Data1024: Data1025: Data1026: Data1027: Data1028: Data1029: Data1030: Data1031: Data1032: Data1033: Data1034: Data1035: Data1036: Data1037: Data1038: Data1039: Data1040: Data1041: Data1042: Data1043: Data1044: Data1045: Data1046: Data1047: Data1048: Data1049: Data1050: Data1051: Data1052: Data1053: Data1054: Data1055: Data1056: Data1057: Data1058: Data1059: Data1060: Data1061: Data1062: Data1063: Data1064: Data1065: Data1066: Data1067: Data1068: Data1069: Data1070: Data1071: Data1072: Data1073: Data1074: Data1075: Data1076: Data1077: Data1078: Data1079: Data1080: Data1081: Data1082: Data1083: Data1084: Data1085: Data1086: Data1087: Data1088: Data1089: Data1090: Data1091: Data1092: Data1093: Data1094: Data1095: Data1096: Data1097: Data1098: Data1099: Data1100: Data1101: Data1102: Data1103: Data1104: Data1105: Data1106: Data1107: Data1108: Data1109: Data1110: Data1111: Data1112: Data1113: Data1114: Data1115: Data1116: Data1117: Data1118: Data1119: Data1120: Data1121: Data1122: Data1123: Data1124: Data1125: Data1126: Data1127: Data1128: Data1129: Data1130: Data1131: Data1132: Data1133: Data1134: Data1135: Data1136: Data1137: Data1138: Data1139: Data1140: Data1141: Data1142: Data1143: Data1144: Data1145: Data1146: Data1147: Data1148: Data1149: Data1150: Data1151: Data1152: Data1153: Data1154: Data1155: Data1156: Data1157: Data1158: Data1159: Data1160: Data1161: Data1162: Data1163: Data1164: Data1165: Data1166: Data1167: Data1168: Data1169: Data1170: Data1171: Data1172: Data1173: Data1174: Data1175: Data1176: Data1177: Data1178: Data1179: Data1180: Data1181: Data1182: Data1183: Data1184: Data1185: Data1186: Data1187: Data1188: Data1189: Data1190: Data1191: Data1192: Data1193: Data1194: Data1195: Data1196: Data1197: Data1198: Data1199: Data1200: Data1201: Data1202: Data1203: Data1204: Data1205: Data1206: Data1207: Data1208: Data1209: Data1210: Data1211: Data1212: Data1213: Data1214: Data1215: Data1216: Data1217: Data1218: Data1219: Data1220: Data1221: Data1222: Data1223: Data1224: Data1225: Data1226: Data1227: Data1228: Data1229: Data1230: Data1231: Data1232: Data1233: Data1234: Data1235: Data1236: Data1237: Data1238: Data1239: Data1240: Data1241: Data1242: Data1243: Data1244: Data1245: Data1246: Data1247: Data1248: Data1249: Data1250: Data1251: Data1252: Data1253: Data1254: Data1255: Data1256: Data1257: Data1258: Data1259: Data1260: Data1261: Data1262: Data1263: Data1264: Data1265: Data1266: Data1267: Data1268: Data1269: Data1270: Data1271: Data1272: Data1273: Data1274: Data1275: Data1276: Data1277: Data1278: Data1279: Data1280: Data1281: Data1282: Data1283: Data1284: Data1285: Data1286: Data1287: Data1288: Data1289: Data1290: Data1291: Data1292: Data1293: Data1294: Data1295: Data1296: Data1297: Data1298: Data1299: Data1300: Data1301: Data1302: Data1303: Data1304: Data1305: Data1306: Data1307: Data1308: Data1309: Data1310: Data1311: Data1312: Data1313: Data1314: Data1315: Data1316: Data1317: Data1318: Data1319: Data1320: Data1321: Data1322: Data1323: Data1324: Data1325: Data1326: Data1327: Data1328: Data1329: Data1330: Data1331: Data1332: Data1333: Data1334: Data1335: Data1336: Data1337: Data1338: Data1339: Data1340: Data1341: Data1342: Data1343: Data1344: Data1345: Data1346: Data1347: Data1348: Data1349: Data1350: Data1351: Data1352: Data1353: Data1354: Data1355: Data1356: Data1357: Data1358: Data1359: Data1360: Data1361: Data1362: Data1363: Data1364: Data1365: Data1366: Data1367: Data1368: Data1369: Data1370: Data1371: Data1372: Data1373: Data1374: Data1375: Data1376: Data1377: Data1378: Data1379: Data1380: Data1381: Data1382: Data1383: Data1384: Data1385: Data1386: Data1387: Data1388: Data1389: Data1390: Data1391: Data1392: Data1393: Data1394: Data1395: Data1396: Data1397: Data1398: Data1399: Data1400: Data1401: Data1402: Data1403: Data1404: Data1405: Data1406: Data1407: Data1408: Data1409: Data1410: Data1411: Data1412: Data1413: Data1414: Data1415: Data1416: Data1417: Data1418: Data1419: Data1420: Data1421: Data1422: Data1423: Data1424: Data1425: Data1426: Data1427: Data1428: Data1429: Data1430: Data1431: Data1432: Data1433: Data1434: Data1435: Data1436: Data1437: Data1438: Data1439: Data1440: Data1441: Data1442: Data1443: Data1444: Data1445: Data1446: Data1447: Data1448: Data1449: Data1450: Data1451: Data1452: Data1453: Data1454: Data1455: Data1456: Data1457: Data1458: Data1459: Data1460: Data1461: Data1462: Data1463: Data1464: Data1465: Data1466: Data1467: Data1468: Data1469: Data1470: Data1471: Data1472: Data1473: Data1474: Data1475: Data1476: Data1477: Data1478: Data1479: Data1480: Data1481: Data1482: Data1483: Data1484: Data1485: Data1486: Data1487: Data1488: Data1489: Data1490: Data1491: Data1492: Data1493: Data1494: Data1495: Data1496: Data1497: Data1498: Data1499: Data1500: Data1501: Data1502: Data1503: Data1504: Data1505: Data1506: Data1507: Data1508: Data1509: Data1510: Data1511: Data1512: Data1513: Data1514: Data1515: Data1516: Data1517: Data1518: Data1519: Data1520: Data1521: Data1522: Data1523: Data1524: Data1525: Data1526: Data1527: Data1528: Data1529: Data1530: Data1531: Data1532: Data1533: Data1534: Data1535: Data1536: Data1537: Data1538: Data1539: Data1540: Data1541: Data1542: Data1543: Data1544: Data1545: Data1546: Data1547: Data1548: Data1549: Data1550: Data1551: Data1552: Data1553: Data1554: Data1555: Data1556: Data1557: Data1558: Data1559: Data1560: Data1561: Data1562: Data1563: Data1564: Data1565: Data1566: Data1567: Data1568: Data1569: Data1570: Data1571: Data1572: Data1573: Data1574: Data1575: Data1576: Data1577: Data1578: Data1579: Data1580: Data1581: Data1582: Data1583: Data1584: Data1585: Data1586: Data1587: Data1588: Data1589: Data1590: Data1591: Data1592: Data1593: Data1594: Data1595: Data1596: Data1597: Data1598: Data1599: Data1600: Data1601: Data1602: Data1603: Data1604: Data1605: Data1606: Data1607: Data1608: Data1609: Data1610: Data1611: Data1612: Data1613: Data1614: Data1615: Data1616: Data1617: Data1618: Data1619: Data1620: Data1621: Data1622: Data1623: Data1624: Data1625: Data1626: Data1627: Data1628: Data1629: Data1630: Data1631: Data1632: Data1633: Data1634: Data1635: Data1636: Data1637: Data1638: Data1639: Data1640: Data1641: Data1642: Data1643: Data1644: Data1645: Data1646: Data1647: Data1648: Data1649: Data1650: Data1651: Data1652: Data1653: Data1654: Data1655: Data1656: Data1657: Data1658: Data1659: Data1660: Data1661: Data1662: Data1663: Data1664: Data1665: Data1666: Data1667: Data1668: Data1669: Data1670: Data1671: Data1672: Data1673: Data1674: Data1675: Data1676: Data1677: Data1678: Data1679: Data1680: Data1681: Data1682: Data1683: Data1684: Data1685: Data1686: Data1687: Data1688: Data1689: Data1690: Data1691: Data1692: Data1693: Data1694: Data1695: Data1696: Data1697: Data1698: Data1699: Data1700: Data1701: Data1702: Data1703: Data1704: Data1705: Data1706: Data1707: Data1708: Data1709: Data1710: Data1711: Data1712: Data1713: Data1714: Data1715: Data1716: Data1717: Data1718: Data1719: Data1720: Data1721: Data1722: Data1723: Data1724: Data1725: Data1726: Data1727: Data1728: Data1729: Data1730: Data1731: Data1732: Data1733: Data1734: Data1735: Data1736: Data1737: Data1738: Data1739: Data1740: Data1741: Data1742: Data1743: Data1744: Data1745: Data1746: Data1747: Data1748: Data1749: Data1750: Data1751: Data1752: Data1753: Data1754: Data1755: Data1756: Data1757: Data1758: Data1759: Data1760: Data1761: Data1762: Data1763: Data1764: Data1765: Data1766: Data1767: Data1768: Data1769: Data1770: Data1771: Data1772: Data1773: Data1774: Data1775: Data1776: Data1777: Data1778: Data1779: Data1780: Data1781: Data1782: Data1783: Data1784: Data1785: Data1786: Data1787: Data1788: Data1789: Data1790: Data1791: Data1792: Data1793: Data1794: Data1795: Data1796: Data1797: Data1798: Data1799: Data1800: Data1801: Data1802: Data1803: Data1804: Data1805: Data1806: Data1807: Data1808: Data1809: Data1810: Data1811: Data1812: Data1813: Data1814: Data1815: Data1816: Data1817: Data1818: Data1819: Data1820: Data1821: Data1822: Data1823: Data1824: Data1825: Data1826: Data1827: Data1828: Data1829: Data1830: Data1831: Data1832: Data1833: Data1834: Data1835: Data1836: Data1837: Data1838: Data1839: Data1840: Data1841: Data1842: Data1843: Data1844: Data1845: Data1846: Data1847: Data1848: Data1849: Data1850: Data1851: Data1852: Data1853: Data1854: Data1855: Data1856: Data1857: Data1858: Data1859: Data1860: Data1861: Data1862: Data1863: Data1864: Data1865: Data1866: Data1867: Data1868: Data1869: Data1870: Data1871: Data1872: Data1873: Data1874: Data1875: Data1876: Data1877: Data1878: Data1879: Data1880: Data1881: Data1882: Data1883: Data1884: Data1885: Data1886: Data1887: Data1888: Data1889: Data1890: Data1891: Data1892: Data1893: Data1894: Data1895: Data1896: Data1897: Data1898: Data1899: Data1900: Data1901: Data1902: Data1903: Data1904: Data1905: Data1906: Data1907: Data1908: Data1909: Data1910: Data1911: Data1912: Data1913: Data1914: Data1915: Data1916: Data1917: Data1918: Data1919: Data1920: Data1921: Data1922: Data1923: Data1924: Data1925: Data1926: Data1927: Data1928: Data1929: Data1930: Data1931: Data1932: Data1933: Data1934: Data1935: Data1936: Data1937: Data1938: Data1939: Data1940: Data1941: Data1942: Data1943: Data1944: Data1945: Data1946: Data1947: Data1948: Data1949: Data1950: Data1951: Data1952: Data1953: Data1954: Data1955: Data1956: Data1957: Data1958: Data1959: Data1960: Data1961: Data1962: Data1963: Data1964: Data1965: Data1966: Data1967: Data1968: Data1969: Data1970: Data1971: Data1972: Data1973: Data1974: Data1975: Data1976: Data1977: Data1978: Data1979: Data1980: Data1981: Data1982: Data1983: Data1984: Data1985: Data1986: Data1987: Data1988: Data1989: Data1990: Data1991: Data1992: Data1993: Data1994: Data1995: Data1996: Data1997: Data1998: Data1999: Data2000: Data2001: Data2002: Data2003: Data2004: Data2005: Data2006: Data2007: Data2008: Data2009: Data2010: Data2011: Data2012: Data2013: Data2014: Data2015: Data2016: Data2017: Data2018: Data2019: Data2020: Data2021: Data2022: Data2023: Data2024: Data2025: Data2026: Data2027: Data2028: Data2029: Data2030: Data2031: Data2032: Data2033: Data2034: Data2035: Data2036: Data2037: Data2038: Data2039: Data2040: Data2041: Data2042: Data2043: Data2044: Data2045: Data2046: Data2047: Data2048: Data2049: Data2050: Data2051: Data2052: Data2053: Data2054: Data2055: Data2056: Data2057: Data2058: Data2059: Data2060: Data2061: Data2062: Data2063: Data2064: Data2065: Data2066: Data2067: Data2068: Data2069: Data2070: Data2071: Data2072: Data2073: Data2074: Data2075: Data2076: Data2077: Data2078: Data2079: Data2080: Data2081: Data2082: Data2083: Data2084: Data2085: Data2086: Data2087: Data2088: Data2089: Data2090: Data2091: Data2092: Data2093: Data2094: Data2095: Data2096: Data2097: Data2098: Data2099: Data2																																																																																																			

Figure 55 Data Logging example – Exporting X/Y/X3/Y3 view data in .CSV format

5 Using the evaluation software

5.6 Memory map

The **Memory Map** view is accessible by clicking the corresponding button in the software main menu. The open view is shown in [Figure 56](#).

This view implements various sensor internal memory operations, strictly for the TLx49012 sensor. It also contains additional features and functionalities detailed in the next sections.

The **Memory Map** view reads and displays the CMTTP memory and the internal registers as bitmaps. The internal registers lose their content at power down and are loaded from the CMTTP at power up.

Upon accessing this view, the software will check if the sensor is in Test Mode. If the sensor is not, the procedure to enter this mode will automatically be executed.

Attention: *Entering Test Mode requires the sensor to be powered down, resetting any configuration made before, unless the sensor is already in Test Mode.*

The memory of the sensor is displayed as a collection of memory lines, each memory line being comprised of multiple memory bitfields. The user can select any memory line or bitfield and view detailed information by clicking on it.

The **Memory Map** view functionalities and features can be divided into the following groups, highlighted in [Figure 56](#):

1. Memory bitmap display
2. Drop down for selecting the memory zone to be read/written
3. Button for reloading selected memory
4. CRC check for CMTTP memory. The software calculates the CRC of the CMTTP memory and compares it with the one written. In case of a mismatch an error is shown

Attention: *For virgin blocks, it is normal to have a CRC error as all fuses are “intact”.*

5. Hexadecimal and decimal decoding for selected memory bitfield or line
6. Selected bitfield information
7. Display for CMTTP left programming cycles
8. Buttons for writing the information into the registers and performing a power-on reset
9. Buttons for exporting/importing the selected memory zone into/from a .CSV file. In the case of importing a .CSV file, the file will be checked and in the case of corruption or missing values or invalid data, it will be rejected, and no change will be reflected in the actual Memory Map

TLx49012 evaluation kit user guide

XENSIV™ angle sensors

5 Using the evaluation software




Figure 56 Software usage – Memory Map view

Note: All configurable parameters have tooltips, which hold relevant information for proper understanding of their use case.

5.6.1 Memory map zones

The **Memory Map** view offers viewing capabilities of most of the SPI registers. Those registers range from basic configuration registers such as USER configuration registers and LUT registers, to specific Infineon registers and CMTP registers.

5.6.1.1 Configurable zone

With default access the user can read all registers, however writing access is blocked to most registers. The available registers for writing are the **USER_CONFIG_REGISTERS** and **LUT_REGISTERS** zones. Access to these registers provides the user with default configuration options.

To write in any field, you can either select to write to the whole address line or individual fields. This change only happens with the software and does not reflect on the sensor's internal memory or CMTP memory. When you are OK with the changes, you can use the **Write memory** button to write the current selected zone into the memory of the sensor with the values that are currently displayed in the software. Clicking the button will prompt you to confirm the changes. The CRC that protects the changed fields will automatically be re-calculated by the software and written in the correct field. After the write operation takes place, the sensor is soft-reset, and the registers from the bitmap configuration are re-read, and the values will be reloaded in the UI elements.

The software will additionally check if the values have been updated and will return to you whether the operation is completed successfully or it has failed.

5.6.1.2 LUT zone

The **Memory Map** view offers a way to change the contents of the volatile memory of the sensor and view the effects it has on the operation of the sensor. The LUT of the sensor can be viewed by clicking the LUT_REGISTERS selection in the drop down (2) as shown in Figure 56. The values stored in the LUT within the internal memory are not accessible all at once. Instead, an indexing approach is used to access these values.

To select the starting LUT entry, write the desired index to the “mpc_lut_idx” bitfield at Address 56 (see Figure 58), then click the **Write** button to open the selection window (see Figure 57). In this window, click **Index** to apply the update. The LUT value at the selected index displays in the “mpc_lut_data_0” bitfield at Address 58, and the next entries follow in index order, with the value at index+1 shown in “mpc_lut_data_1”, the value at index+2 in “mpc_lut_data_2”, and so on.

If you need to program LUT contents directly rather than refresh the readout mapping, select **Data** in the same window. This option writes values from the **Memory Map** window into the mapped LUT registers of the sensor. After using the **Data** button to modify LUT entries, you can click the **Index** button to refresh the mapping and verify the updated sequence in the “mpc_lut_data_x” fields beginning at the chosen index.




Figure 57 Software usage – Write selection for LUT




Figure 58 Software usage – LUT Registers

5 Using the evaluation software

Note: When an index or a sequential offset exceeds the final LUT entry, the mapping wraps around to the first entry. This ensures continuous readout across the LUT boundaries and prevents writing data to locations that you did not intend to change.

5.6.1.3 CMTTP zone

The sensor features a non-volatile memory (NVM) also known as the customer multi-time programmable (CMTTP) memory, which stores application-specific configuration settings and look-up table (LUT) correction values. This memory allows users to customize the sensor behavior to suit their specific needs. The CMTTP memory can be programmed with user-specific data that is kept even when the sensor is powered down. However, this memory can only be programmed for a finite number of times indicated in the software in the left panel of the **Memory Map** view whenever the CMTTP zone is selected. Once those programming cycles have run out, that part of the memory remains unchangeable and cannot be reprogrammed further.

It is recommended, before programming the sensor's non-volatile CMTTP memory, first modify the registers through volatile means and confirm it is the needed configuration. Once the target configuration is identified, the sensor can be fused with the corresponding bitmap values. This process can be done through the **Extended Sensor Configuration**, or through the steps shown in [Section 5.4.2](#).

5.6.2 Non-volatile memory programming

The NVM programming features are available in the **Memory Map** view that can be accessed through the main menu of the sensor. Programming the CMTTP is possible, in this version of the software, through two memory views, namely:

- CMTTP view
- USER_CONFIG_REGISTERS view

The CMTTP/NVM memory of the sensor can be grouped into blocks, based on the information they contain, each protected by CRC. The block identification can be found under the "Block ID" column in the left programming cycles as seen in (7) of [Figure 56](#) and are assigned as such:

- LUT: Block 0
- USER configuration: Block 1
- IFX configuration: Block 2

You can only write Block 0 and 1 for a limited number of times, Block 2 being fused from the factory. A virgin CMTTP line is read as 0xFFFF. Configurations in the CMTTP must be manually done by selecting the bitfield or line and writing the desired values in the control textbox (5) as shown in [Figure 56](#). Reserved or unused bitfields must be set to zero. Alternatively, the CMTTP can be imported via the **Import from csv** button. This automatically checks and loads a .CSV file from you. This .CSV file is first checked and rejected if any problems arise. You can get .CSV files by exporting them from this menu, or from the **CMTTP Configuration** tab from the **Extended Sensor Configuration** window.

Write the CMTTP memory with the data by clicking the **Write Memory** button (8) as shown in [Figure 56](#). This will recalculate the CRC for each block. You will be prompted to select which part of the CMTTP to be written as seen in [Figure 59](#). Software checks available write cycles for each line and for each CRC of each block, in case of any inconsistencies the operation is aborted.




Figure 59 Software usage – CMTMP writing selection

5.6.2.1 NVM programming using converted USER data

Alternatively, you can choose to convert the USER_CONFIG_REGISTERS memory map into usable data for the CMTMP.

To achieve this, all configurations must be manually done by selecting the bitfield or line and writing the desired values into the control textbox or automatically loading those values via a .CSV file. The yellow **Write CMTMP** button (1) at the bottom of the view as shown in Figure 60 starts the conversion and writing process. This, however, does not fuse the entire CMTMP memory, only the blocks that contain the user configurations (That have Block ID 1). The CRC is also automatically recalculated at every step of the process.

Note: This is the recommended and less error prone method to configure the USER block of the CMTMP (starting from the default values).




Figure 60 Software usage – USER_CONFIG_REGISTERS conversion into CMTMP

6 Related resources

- Webpage: [XENSIV™ angle sensors](#)
- Infineon Developer Community: [XENSIV™ angle sensors](#) forum
- [XENSIV™ TLx49012 Angle Sensor Evaluation Kit](#)

Appendices

A Appendix 1 – Hardware revision history

Table 4 Hardware revision history

Hardware version	Description of changes
V1.1	Initial version of hardware
V1.2	Minor silkscreen modifications
V1.3	Added PCB silkscreen markings for the TLI49012 variant

References

References

- [1] Infineon Technologies AG: *XENSIV™ TLE49012-S0001 angle sensor datasheet*; [Available online](#)

Glossary

Glossary

AMR

anisotropic magnetoresistance (AMR)

CMTF

customer multi-time programmable memory (CMTF)

CPU

central processing unit (CPU)

CRC

cyclic redundancy check (CRC)

PSIB

position sensors interface board (PSIB)

CSV

comma-separated values (CSV)

DC

direct current (DC)

EEPROM

electrically erasable programmable read-only memory (EEPROM)

ESD

electrostatic discharge (ESD)

GMR

giant magnetoresistance (GMR)

GUI

graphical user interface (GUI)

I²C

inter-integrated circuit (I²C)

IDC

Infineon Developer Center (IDC)

ISaR

Infineon Sample Request (ISaR)

LED

light-emitting diode (LED)

LUT

look-up table (LUT)

MCU

microcontroller unit (MCU)

MPC

multipoint calibration (MPC)

Glossary

NVM

non-volatile memory (NVM)

PC

personal computer (PC)

PCB

printed circuit board (PCB)

RAM

random access memory (RAM)

SMT

surface mount technology (SMT)

TMR

tunneling magnetoresistance (TMR)

UI

user interface (UI)

USB

universal serial bus (USB)

Revision history

Revision history

Document revision	Date	Description of changes
1.00	2026-07-21	Initial release

Trademarks

All referenced product or service names and trademarks are the property of their respective owners.

Edition: 2026-07-21

Published by
Infineon Technologies AG
Am Campeon 1-15
85579 Neubiberg, Germany

© 2026 Infineon Technologies AG.
All rights reserved

Do you have a question about this document?
Email: erratum@infineon.com

Document reference:
UG104826

Important Notice

This evaluation board, demonstration board, reference board or kit and any related documentation ("Evaluation Board") is sold or provided and delivered by Infineon Technologies AG and its affiliates ("Infineon"). Evaluation Boards are part of Infineon's non-serial products.

This Evaluation Board is delivered to customer "AS IS", without any warranty (whether express or implied) or liability of Infineon of any kind, including but without limitation any warranty of merchantability, fitness for a particular purpose or non-infringement. These limitations and exclusions shall not apply in case of Infineon's willful misconduct or in any other case where liability is mandatory at law.

This Evaluation Board shall only be used by customer for test purposes and not for series production. However, the Evaluation Board shall not to be used for reliability testing. The Evaluation Board is exclusively intended for technically qualified and skilled customer representatives. The Evaluation Board shall not be used in any way where a failure of the Evaluation Board, or any consequences of the use thereof, can reasonably be expected to result in personal injury. Evaluation Boards may not comply with CE or similar standards (including without limitation the EMC Directive 2004/EC/108 and the EMC Act) and may not fulfill other requirements of the country in which they are operated by the customer. The customer shall ensure that each Evaluation Board will be handled in a way which is compliant with all relevant requirements and standards in the country in which it is operated. Software and associated documentation and materials included or referenced in the Evaluation Board ("Software") is owned by Infineon and is protected by and subject to worldwide patent protection, worldwide copyright laws, and international treaty provisions. Therefore, you may use this Software only as provided in the license agreement accompanying the software package from which you obtained this Software.

If no license agreement applies, then any use, reproduction, modification, translation, or compilation of this Software is prohibited without the express written permission of Infineon. Unless otherwise expressly agreed with Infineon, this Software is provided to customer "AS IS", without any warranty (whether express or implied) or liability of Infineon of any kind, including but without limitation any warranty of merchantability, fitness for a particular purpose or non-infringement.

These limitations and exclusions shall not apply in case of Infineon's willful misconduct or in any other case where liability is mandatory at law. Infineon reserves the right to make changes to the Software without notice. You are responsible for properly designing, programming, and testing the functionality and safety of your intended application of the Software, as well as complying with any legal requirements related to its use. Infineon does not guarantee that the Software will be free from intrusion, data theft or loss, or other breaches ("Security Breaches"), and Infineon shall have no liability arising out of any Security Breaches. The Software shall not be used in any way where a failure of the Evaluation Board or any consequences of the use thereof, can reasonably be expected to result in personal injury.

Safety & Operating Instructions:

Customer shall check the Evaluation Board for any physical damage which may have occurred during transport. If customer detects any damages or defects in the Evaluation Board, customer shall not connect the Evaluation Board to a power source. Customer shall contact Infineon for further support. If customer observes unusual operating behavior during the evaluation process, customer shall immediately shut off the power supply to the Evaluation Board and consult Infineon for support.

Customer shall not touch the Evaluation Board during operation and keep a safe distance.

Customer shall not touch the Evaluation Board after disconnecting the power supply, several components may still store electrical voltage and can discharge through physical contact. Several parts, like heat sinks and transformers, may still be very hot. Allow the components to cool before touching or servicing.

The electrical installation must be completed in accordance with the appropriate safety requirements.