

Infineon Mobile Robot (IMR) power distribution

DEMO_IMR_PWR_V1 board

About this document

Scope and purpose

This document provides a comprehensive functional description and user guide for the DEMO_IMR_PWR_V1 demonstration board. Both hardware and software are shown and explained in detail with additional flowcharts where necessary. Furthermore, a basic quick-start guide is provided for the intended use as the Infineon Mobile Robot (IMR) main processor.

Intended audience

This document is intended for design engineers, technicians, and developers of electronic systems.

Infineon components featured

- [XMC1404-F064X0200 AA](#): XMC™ 32-bit Microcontrollers with Arm® Cortex®-M0 with focus on low-cost embedded control applications
- [IRS25411SPBF](#): High-voltage, high-frequency buck controller
- [XDPE12254C-0000](#): XDP™ 4+1 phase dual-loop digital multiphase controller
- [TDA21490](#): OptiMOS™ integrated power stage, reliable voltage regulator
- [ISC080N10NM6](#): OptiMOS™ 6 power MOSFET
- [BTS71033-6ESA](#): SPI power controller, six high-side switches with diagnostics and protection functions
- [TLF1963TE](#): Low dropout voltage of 340 mV; adjustable output voltage from 1.21 V to input voltage
- [TLS208D1EJV33](#): 3.3 V fixed linear voltage regulator
- [TLE9351BVSJ](#): High-speed automotive CAN transceiver (CAN and CAN FD)

Important notice

Important notice

“Evaluation Boards and Reference Boards” shall mean products embedded on a printed circuit board (PCB) for demonstration and/or evaluation purposes, which include, without limitation, demonstration, reference and evaluation boards, kits and design (collectively referred to as “Reference Board”).

Environmental conditions have been considered in the design of the Evaluation Boards and Reference Boards provided by Infineon Technologies. The design of the Evaluation Boards and Reference Boards has been tested by Infineon Technologies only as described in this document. The design is not qualified in terms of safety requirements, manufacturing, and operation over the entire operating temperature range or lifetime.

The Evaluation Boards and Reference Boards provided by Infineon Technologies are subject to functional testing only under typical load conditions. Evaluation Boards and Reference Boards are not subject to the same procedures as regular products regarding returned material analysis (RMA), process change notification (PCN) and product discontinuation (PD).

Evaluation Boards and Reference Boards are not commercialized products, and are solely intended for evaluation and testing purposes. In particular, they shall not be used for reliability testing or production. The Evaluation Boards and Reference Boards may therefore not comply with CE or similar standards (including but not limited to the EMC Directive 2004/EC/108 and the EMC Act) and may not fulfill other requirements of the country in which they are operated by the customer. The customer shall ensure that all Evaluation Boards and Reference Boards will be handled in a way, which is compliant with the relevant requirements and standards of the country in which they are operated.

The Evaluation Boards and Reference Boards as well as the information provided in this document are addressed only to qualified and skilled technical staff, for laboratory usage, and shall be used and managed according to the terms and conditions set forth in this document and in other related documentation supplied with the respective Evaluation Board or Reference Board.

It is the responsibility of the customer’s technical departments to evaluate the suitability of the Evaluation Boards and Reference Boards for the intended application, and to evaluate the completeness and correctness of the information provided in this document with respect to such application.

The customer is obliged to ensure that the use of the Evaluation Boards and Reference Boards does not cause any harm to persons or third-party property.

The Evaluation Boards and Reference Boards and any information in this document is provided "as is" and Infineon Technologies disclaims any warranties, express or implied, including but not limited to warranties of noninfringement of third-party rights and implied warranties of fitness for any purpose, or for merchantability.

Infineon Technologies shall not be responsible for any damages resulting from the use of the Evaluation Boards and Reference Boards and/or from any information provided in this document. The customer is obliged to defend, indemnify, and hold Infineon Technologies harmless from and against any claims or damages arising out of or resulting from any use thereof.

Infineon Technologies reserves the right to modify this document and/or any information provided herein at any time without further notice.

Safety precautions

Safety precautions

Note: Please note the following warnings regarding the hazards associated with development systems.

Table 1 Safety precautions

	<p>Warning: The DC link potential of this board is up to 1000 VDC. When measuring voltage waveforms by oscilloscope, high-voltage differential probes must be used. Failure to do so may result in personal injury or death.</p>
	<p>Warning: The evaluation or reference board contains DC bus capacitors, which take time to discharge after removal of the main supply. Before working on the drive system, wait 5 minutes for capacitors to discharge to safe voltage levels. Failure to do so may result in personal injury or death. Darkened display LEDs are not an indication that capacitors have discharged to safe voltage levels.</p>
	<p>Warning: The evaluation or reference board is connected to the grid input during testing. Hence, high-voltage differential probes must be used when measuring voltage waveforms by an oscilloscope. Failure to do so may result in personal injury or death. Darkened display LEDs are not an indication that capacitors have discharged to safe voltage levels.</p>
	<p>Warning: Remove or disconnect power from the drive before you disconnect or reconnect wires, or perform maintenance work. Wait five minutes after removing power to discharge the bus capacitors. Do not attempt to service the drive until the bus capacitors have discharged to zero. Failure to do so may result in personal injury or death.</p>
	<p>Caution: The heat sink and device surfaces of the evaluation or reference board may become hot during testing. Hence, necessary precautions are required while handling the board. Failure to comply may cause injury.</p>
	<p>Caution: Only personnel familiar with the drive, power electronics and associated machinery should plan, install, commission and subsequently service the system. Failure to comply may result in personal injury and/or equipment damage.</p>
	<p>Caution: The evaluation or reference board contains parts and assemblies sensitive to electrostatic discharge (ESD). Electrostatic control precautions are required when installing, testing, servicing or repairing the assembly. Component damage may result if ESD control procedures are not followed. If you are not familiar with electrostatic control procedures, refer to the applicable ESD protection handbooks and guidelines.</p>
	<p>Caution: A drive that is incorrectly applied or installed can lead to component damage or reduction in product lifetime. Wiring or application errors such as undersizing the motor, supplying an incorrect or inadequate AC supply, or excessive ambient temperatures may result in system malfunction.</p>
	<p>Caution: The evaluation or reference board is shipped with packing materials that need to be removed prior to installation. Failure to remove all packing materials that are unnecessary for system installation may result in overheating or abnormal operating conditions.</p>

Table of contents

About this document	1
Important notice	2
Safety precautions	3
Table of contents	4
1 Introduction	5
1.1 Mobile robot general description	5
1.2 IMR description.....	5
1.3 Demo board description	6
1.4 Card edge header	7
2 Hardware	9
2.1 Input supply voltage	9
2.2 5 V and 3.3 V linear regulator circuits	9
2.3 Multiphase buck converter	10
2.4 Power controller.....	12
2.5 Current measurement.....	12
2.6 CAN ID selector	13
2.7 Microcontroller unit	13
3 Software	16
3.1 Software description and flowchart.....	16
3.2 Multiphase buck converter message structure.....	18
3.3 Power controller message structure	20
3.4 CAN communication	21
4 Quick start guide	23
4.1 Equipment	23
4.1.1 XMC™ Link isolated debug probe	23
4.1.2 USB005 USB dongle	23
4.1.3 PowerClient GUI	24
4.1.3.1 Activating the PowerClient license.....	24
4.1.3.2 Connecting the multiphase buck controller	25
4.1.3.3 Loading the system file to PowerClient	25
4.1.4 Import the ModusToolbox™ project.....	28
4.2 Update libraries and build the application	30
4.3 CAN node identification	30
5 Bill of materials (BOM)	32
References	35
Glossary	36
Revision history	37
Disclaimer	38

Introduction

1 Introduction

1.1 Mobile robot general description

Mobile robots are now common in applications from logistics, warehouse centers, production sites, hospitals, restaurants, schools, and as last-mile package-delivery vehicles. On a high level, mobile robots are of two main types:

- **Automated guided vehicles (AGV):** “Fixed” vehicles that follow predefined paths using lasers, barcodes, radio waves, vision sensors, or magnetic tapes for navigation
- **Autonomous mobile robots (AMR):** “Not fixed”, and do not need external paths as these use autonomous mapping, localization, navigating, and obstacle avoidance by using sensors

Usually, the robots are battery-powered where the voltage level depends on the size and weight characteristics.

1.2 IMR description

The board described in this document is primarily targeted to be used in combination with the Infineon Mobile Robot (IMR). The IMR is a comprehensive robotic platform intended to be used with a wide variety of different boards (sensors, motor control, wireless communication, battery management, etc.).




Figure 1 Isometric view of the IMR

The overall target of the IMR is to provide a demonstration platform for autonomous service robot functionalities using Infineon components.

Introduction




Figure 2 Overview of the IMR with the board described in this document highlighted in red

1.3 Demo board description

The DEMO_IMR_PWR_V1 board serves as a specialized modular power distribution (PD) solution designed to easily integrate with the IMR via the card-edge connector available on the IMR motherboard (see [IMR structural boards user guide](#)). The XMC1404 series Arm® Cortex®-M0 MCU on the board controls the operation of the multiphase buck converter and power controller, and reads current measurements at the output. The board is powered by the IRS25411SPBF buck converter, which processes input voltages up to 100 V and provides a 12 V output. This output powers the four power stages of TDA21490.

After the initial step-down conversion, a TLF1963TE linear regulator regulates the 12 V down to 5 V. This regulation is required to provide the VDD and VCC supplies of the TDA21490 integrated power stage and the TLE9351VSJ CAN transceiver. In addition, the TLS208D1EJV33 linear regulator regulates the 5 V supply voltage down to 3.3 V. This voltage supports the following:

- XMC1404 MCU
- BTS71033-6ESA power controller
- XDP12254C-0000 digital dual-rail 4+1 phase controller




Figure 3 DEMO_IMR_PWR_V1 board top view

1.4 Card edge header

The main interface to the IMR is a card edge header on the bottom of the board, as [Figure 4](#) shows; it has 18 pins on the top and bottom sides, so in total 36 pins.



Figure 4 Card edge header - top view (18 pins symmetrical, top and bottom)

The selected counterpart for the card edge header is the EBC18DCWN-S371 board-to-board receptacle connector from Sullins Connector Solutions. Because the CAN interface (CAN_H and CAN_L) is used for all communication, these are the only interface pins required in addition to power connections, as [Table 2](#) shows.

Introduction

Table 2 Pinout of power distribution board slot on the IMR motherboard with the thick row lines marking polarizing key positions

PIN	Function	PIN	Function
A1	CAN_L	B1	–
A2	CAN_H	B2	GND
A3	Reserved (for CAN_FD_L)	B3	Reserved (for CAN_FD_L)
A4	Reserved (for CAN_FD_H)	B4	Reserved (for CAN_FD_H)
A5	GND	B5	GND
A6	GND	B6	GND
A7	Battery voltage (48 V nominal)	B7	Battery voltage (48 V nominal)
A8	Battery voltage (48 V nominal)	B8	Battery voltage (48 V nominal)
A9	–	B9	–
A10	–	B10	–
A11	–	B11	–
A12	GND	B12	GND
A13	5V_OUT6 (for motor drive 1)	B13	5V_OUT6 (for motor drive 1)
A14	5V_OUT5 (for motor drive 2)	B14	5V_OUT5 (for motor drive 2)
A15	5V_OUT4 (for regular slot inside)	B15	5V_OUT4 (for regular slot inside)
A16	5V_OUT3 (for regular slot middle)	B16	5V_OUT3 (for regular slot middle)
A17	5V_OUT2 (for regular slot outside)	B17	5V_OUT2 (for regular slot outside)
A18	5V_OUT1 (for sensor and LEDs boards)	B18	5V_OUT1 (for sensor and LEDs boards)

2 Hardware

This chapter describes the most important hardware parts of the DEMO_IMR_PWR_V1 board.

2.1 Input supply voltage

The IRS25411SPBF high-voltage, high-frequency buck controller handles the 48 V supply voltage from batteries. This device is a time-delayed hysteretic synchronous step-down regulator. The output voltage is detected via a voltage divider, which is fed back to the IFB pin and compared with an internal high-precision bandgap reference voltage ($V_{IFBTH} = 500 \text{ mV}$). The gate driver outputs (HO and LO of the IC) change state when V_{IFB} rises above and falls below V_{IFBTH} . To prevent shoot-through, a fixed dead-time of 140 ns is provided, which is caused by overlapping the switching transitions of MOSFETs [1].

This step-down regulator IC is designed for constant-voltage regulation for an input voltage of up to 100 V and generates an output voltage of 12 V. The OptiMOS™ 6 ISC080N10NM6 MOSFETs used have an $R_{DS(on)} = 8.05 \text{ m}\Omega$, drain-source voltage (V_{DS}) = 100 V, and a drain current (I_D) = 75 A [2].




Figure 5 IRS25411SPBF voltage regulated synchronous buck converter

2.2 5 V and 3.3 V linear regulator circuits

A TLF1963TE linear voltage regulator is used to provide the required 5 V voltage for additional devices on the board. The 3.3 V voltage for the XMC1404 MCU, power controller, ADC converter etc. is also provided by the TLS208D1EJV33 post regulator.

The TLF1963TE LDO has a very low dropout voltage of 340 mV and is suitable for an output current of up to 1.5 A. The output voltage is adjustable; however, in this application, it is designed for an output voltage of 5 V. The input voltage range can be up to 20 V [4].

TLS208D1EJV33 is selected for ICs with lower V_{CC} . This LDO regulates the 5 V input voltage to a fixed 3.3 V output voltage with an accuracy of $\pm 2 \%$. It supports a static output current of 800 mA and has a very low current consumption (typically 90 μA) [3].

Hardware




Figure 6 Left-side 5 V and on the right-side 3.3 V linear regulator

2.3 Multiphase buck converter

The XDPE12254C-0000 digital multiphase regulator is used in combination with the OptiMOS™ TDA21490 power stage to smooth the residual ripple on the output side and to manage load transients. This regulator is a digital 4+1 phase controller with two rails; only one of the rails with four phases is used in the current application. The phases can be configured so that they can be added or removed autonomously. Command and monitoring functions are controlled via the PMBus®/I2C interface, which supports dynamic voltage identification (DVID) at 10 mV/steps, power states (PS), VR data, and operating register requests [5].

The TDA21490 power stage contains a low quiescent current synchronous buck-gate driver IC packaged together with high-side and low-side MOSFETs. This integration optimizes the operation of the power stage and increases its overall performance. The input voltage range is 4.25 V to 16 V and the output voltage range is 0.25 V to 5.5 V. Several protective functions such as overcurrent protection, thermal shutdown, and phase fault detection are integrated [6].




Figure 7 XDP12254C-0000 multiphase controller with four power stages TDA21490

Infineon Mobile Robot (IMR) power distribution

DEMO_IMR_PWR_V1 board

Hardware

The actual output voltage range is from 0.2 V to 3.04 V, but the feedback path has been changed. A voltage divider was placed between AVSEN and AVREF (see Figure 8). A 200 Ω resistor is placed on the AVSEN track, while a 68 Ω resistor is placed between AVSEN and AVREF. In this configuration, it is possible to obtain an output voltage of 5 V. It is also necessary to make a small change in the software, but this is described later in the Software section.




Figure 8 Voltage divider between AVSEN and AVREF to get 5 V output voltage

2.4 Power controller

The BTS71033-6ESA SPI power controller switches the six output channels OFF or ON; this device is a high-side switch that offers diagnostic and protective functions, and provides six output channels with three outputs at 1.5 A (in channel 0, 4 and 5) and three outputs at 3 A (in channel 1 to 3). Each channel can be switched ON/OFF via the SPI interface. The minimum operating voltage is 4.1 V, and the maximum operating voltage is 28 V. See Figure 9 for the circuit diagram [7].

It is also possible to switch the channels from 0-3 ON and OFF via the IN0 to IN3 pins with the GPIO pins of XMC1404.




Figure 9 BTS71033-6ESA SPI power controller with six channels

2.5 Current measurement

The output current of each channel is measured with the integrated current sensing of the BTS71033-6ESA. With the IS pin, the analog signal is transferred to the ADC of the XMC1404-F064X0200 AA. The selection of the channel is done via software.

2.6 CAN ID selector

The following dip switch has been implemented to uniquely identify each card connected via the CAN bus. Each pin is pulled up via a 20 kΩ resistor and therefore provides an inverted logic that must be taken into account when reading the pin via the XMC1404 microcontroller. The DIP switch for the power board must be configured as shown in [Table 3](#).

Table 3 DIP switch S1 – CAN node identifier logic and pin assignment

CAN ID Bit	ID8	ID7	ID6	ID5	ID4	ID3	ID2	ID1
XMC™ pin	P2_6	P2_7	P2_8	P2_9	P2_10	P2_11	P2_12	P2_13
DIP Switch	0	0	0	0	0	0	0	PWR[0]




Figure 10 CAN node ID circuit with 8-pin DIP switch

2.7 Microcontroller unit

The main controller on this board is the XMC1404 F064X0200 AA MCU. This device is a 32-bit microcontroller with Arm® Cortex®-M0 with focus on low-cost embedded control applications [8].

[Table 4](#) shows only the main connection assignment for the power distribution board.

Table 4 XMC1404-F064X0200 AA main pin assignment overview

Port number	Pin name	Description
P0_0	MISO_BTS	MISO pin from BTS71033-6ESA
P0_1	MOSI_BTS	MOSI pin from BTS71033-6ESA
P0_3	SCLK_BTS	Clock pin from BTS71033-6ESA
P0_4	CS_BTS	Chip Select pin from BTS71033-6ESA
P0_6	AVREN_XDP	Active HIGH Output Enable input from XDPE12254C
P0_7	AVRRDY_XDP	Voltage regulator “Ready” output signal from XDPE12254C
P0_14	SWD	Single bidirectional data pin, debug interface
P0_15	SWCLK	Clock signal to target CPU, debug interface
P1_7	FAULT1_XDP	Multi-purpose pin configurable as FAULT1, or PICAL from XDPE12254C

Infineon Mobile Robot (IMR) power distribution

DEMO_IMR_PWR_V1 board



Hardware

Port number	Pin name	Description
P1_8	XMC_LHI	Limp Home Input pin from BTS71033-6ESA
P2_1	IMON_XDP	Current monitoring from XDPE12254C
P2_2	ADC_BTS	Analog pin from BTS71033-6ESA for current measurement
P2_3	PINALERT_XDP	Multi-purpose pin configurable as PINALRT#, PCRTIT#, LPM#, or Fast OC Warning from XDPE12254C
P2_4	VR_HOT_XDP	Active LOW external temperature indicator from XDPE12254C
P2_6	CAN_ID8	CAN node identification pin 8
P2_7	CAN_ID7	CAN node identification pin 7
P2_8	CAN_ID6	CAN node identification pin 6
P2_9	CAN_ID5	CAN node identification pin 5
P2_10	CAN_ID4	CAN node identification pin 4
P2_11	CAN_ID3	CAN node identification pin 3
P2_12	CAN_ID2	CAN node identification pin 2
P2_13	CAN_ID1	CAN node identification pin 1
P3_3	SDA_XDP	SDA pin from XDPE12254C I2C interface
P3_4	SCL_XDP	SCL pin from XDPE12254C I2C interface
P4_0	LED_GREEN	Status LED (green) for XMC1404
P4_1	LED_RED	Status LED (red) for XMC1404
P4_2	STB	Standby input pin from TLE9351BVSJ
P4_4	IN3_BTS	Input pin 3 from BTS71033-6ESA to activate Output Channel 3
P4_5	IN2_BTS	Input pin 2 from BTS71033-6ESA to activate Output Channel 2
P4_8	CAN_RXD	CAN receive pin from TLE9351BVSJ
P4_9	CAN_TXD	CAN transmit pin from TLE9351BVSJ
P4_10	IN1_BTS	Input pin 1 from BTS71033-6ESA to activate Output Channel 1
P4_11	INO_BTS	Input pin 0 from BTS71033-6ESA to activate Output Channel 0

Hardware




Figure 11 XMC1404-F064X0200 AA microcontroller

3 Software

This chapter focuses on the software of the power distribution board in more detail and how to set up and run.

3.1 Software description and flowchart

The initialization process commences with the configuration of peripheral devices using settings derived from the ModusToolbox™, which are stored in the project repository. The overall process is illustrated in the flowchart shown in [Figure 12](#). This is followed by the comprehensive initialization of all devices on the board, in tandem with the state machine. During this phase, various parameters are set, including the current measurement configuration and the power controller's error restart behavior.

Upon completion of the initialization, the program enters the main while loop, where it defaults to the STATE_IDLE state. In this idle state, the program executes a series of checks to verify the operational readiness of the multiphase buck converter and power controller and set both green and red LEDs to be OFF. Additionally, it monitors for fault occurrences. If an error is detected, the program transitions to the STATE_RESET state otherwise, it proceeds to the STATE_RUN state.

In the run state, the program retrieves current measurement values, component states, and error status. It also switches ON the green LED to indicate that the board is functional and currently it enables all output channels. If an error or warning is encountered, the program first clears the error by transitioning to the STATE_RESET state and then re-reads the values. This STATE_RESET is indicated by the green LED that starts to go OFF. If the error persists for ten consecutive occurrences, the state shifts from STATE_RESET to STATE_STOP, which disables all output channels and therefore results in a complete system shutdown. In the STATE_STOP, the red LED will light up to indicate something is wrong with the board.

To reset the persistent errors which cause the system to be in STATE_STOP, the user can simply disconnect and reconnect the power supply. If the error persists, a more in-depth analysis is required. To facilitate this, the user must enter debug mode and step through the program incrementally. Alternatively, the error may be indicative of a hardware issue.

Additionally, during the operation in STATE_RUN, the red LED will blink at a slow rate (currently set at 1 Hz) indicating CAN message transmission for the output current of all 6 switchable outputs. If a CAN message has been received, it will switch off the red LED very shortly, and then the red LED control will be taken over again by the CAN message transmission. However, if the red LED starts to be ON permanently, STATE_STOP may have been entered.




Figure 12 Flowchart of the power distribution system

3.2 Multiphase buck converter message structure

The communication protocol of the multiphase buck converter is power management bus revision 1.3 (PMBus®). This is an open-standard protocol based on I2C interface. The data formats used for this application of the PMBus® is as follows:

- Send Byte
- Read/Write Byte
- Read/Write Word

Write type: XMC1404 sends data to XDPE12254C

The initial stage of the transaction involves sending a start bit, followed by the 7-bit slave address, and concluding with a write bit to signify a write operation. If the slave acknowledges the address by sending an ACK signal, the host proceeds to transmit the 8-bit command. This is then followed by a stop condition, marking the end of the command transmission.

Read type: XDPE12254C sends data to XMC1404

To initiate a read transaction, it begins with a normal I2C write transaction, where the slave address is sent along with a write bit. This can be confusing for those new to I2C, as a write bit is used to initiate a read command. The second byte contains the command code, which specifies the data to be retrieved.

Next, a repeated start condition is sent, followed by the slave address and a read bit. This signals the device to return the requested data corresponding to the command code. The slave then transmits the requested byte value.

Here is where the process may seem unusual: the host does not acknowledge (NACK) the received data byte. This may be confusing at first, but it is a deliberate design choice to indicate that the host has finished requesting data. If the host were to NACK the data during the transaction, the slave would stop transmitting data and would not trigger a Clock Mode Lock (CML) fault.

The following section outlines the various protocols involved in this application. Specifically, the slave address used in this context is 0xB0, which corresponds to a resistance value of 49.9 kΩ. Additionally, the command code refers to the specific register of interest that is being targeted.

Note:

- **S:** Start bit
- **P:** Stop bit
- **Ack:** Acknowledge bit
- **Nack:** Not acknowledge bit
- **W:** Write bit
- **R:** Read bit

1-8: The number above the fields indicates the length in bits

: Driven by XMC1404 (Master)

: Driven by XDPE12254C (Multiphase Buck Controller)

Send Byte: This protocol is used to send the CLEAR_FAULTS command. This command clears all faults, which have been set to the multiphase buck converter.




Figure 13 Send Byte

Write Byte: This protocol is used to send a single byte data to the multiphase buck controller. The 8-bit data byte will be sent to the specific register (command code).




Figure 14 Write Byte

Write Word: This protocol is used to send two bytes to the multiphase buck controller.



Figure 15 Write Word

Read Byte: The read byte protocol is used to read out a one byte data from the multiphase buck converter.




Figure 16 Read Byte

Read Word: The read word protocol is used to read out two bytes from the multiphase buck converter.




Figure 17 Read Word

It is important to know the bit order, which is used for the PMBus® protocol. The most significant bit (MSB) is bit '7' and the least significant bit (LSB) is bit '0' as shown in Figure 18.




Figure 18 Bit order

The whole PMBus® library can be downloaded at the Infineon website by inserting [PMBus® Library](#) into the search window or click on the link. Here the detailed documentation for the PMBus® is included under the file *Doc*. The user can also visit [\[9\]](#) and [\[10\]](#) for further information on PMBus®.

3.3 Power controller message structure

The serial peripheral interface (SPI) is used to communicate with the power controller (BTS71033-6ESA). The SPI is a synchronous serial communication protocol that enables full-duplex data transfer between devices. This interface utilizes four signal lines to facilitate communication [\[7\]](#):

- SO (Serial Output): Carries data from the slave device to the master device
- SI (Serial Input): Carries data from the master device to the slave device
- SCLK (Serial Clock): Provides the clock signal that governs the data transfer rate
- CSN (Chip Select): Acts as a control signal to initiate and terminate data transfer

The data transfer process in SPI [\[7\]](#) is as follows:

1. The falling edge of CSN indicates the start of a data transfer cycle
2. Data is transmitted over the SI and SO lines at the rate determined by the SCLK signal
3. The slave device samples the incoming data on the SI line at the falling edge of SCLK
4. The slave device shifts out data on the SO line at the rising edge of SCLK
5. Each data transfer cycle must be terminated by a rising edge of CSN

To ensure data integrity, a modulo 8 counter is employed to guarantee that data is only transferred in multiples of 8 bits. This mechanism prevents incomplete data transfers and maintains data consistency [\[7\]](#).




Figure 19 SPI signals [\[7\]](#)

SPI Communication: Understanding the relationship between SI and SO Lines

Figure 19 illustrates the correlation between the SI and SO line content during SPI communication between the microcontroller (μC) and the BTS71033-6ESA device [7].

SI Line: Command frames from the microcontroller

The SI line carries the command frames sent by the microcontroller to the BTS71033-6ESA device. These command frames initiate specific actions or requests for data from the device [7].

SO Line: Response frames from the BTS71033-6ESA

The SO line carries the response frames sent by the BTS71033-6ESA device back to the microcontroller. These response frames are generated based on the command frames received from the microcontroller in the previous transmission cycle [7].

SPI Protocol: Command-response mechanism

The SPI protocol operates on a command-response principle, where the response to a command frame is only provided during the next transmission cycle triggered by the microcontroller. This means that the BTS71033-6ESA device does not respond immediately to a command frame. Instead, it waits for the next transmission cycle to send its response [7].

Decoding response frames

The response frames from the BTS71033-6ESA device can be decoded into specific formats depending on the type of command frame sent by the microcontroller. For write commands, the responses are deterministic and can be decoded into STDDIAG or WRNDIAG frames. However, for read commands, the previous transmission cycle must be considered when decoding the response frame [7].




Figure 20 SPI Protocol [7]

For more information, see the BTS71033-6ESA [datasheet](#) [7].

3.4 CAN communication

Currently the PD board is set to transmit the output current of each switchable 5 V channel regularly. Output current of all 6 channels are currently broadcast every 1 second. Additionally, the board is set to receive a CAN message containing enable or disable message for each switchable 5 V channel. Table 5 shows the CAN messages relevant for this board. For every physical signal contained in the data portion, the decoding description is given in italics:

- U/S: Unsigned/Signed
- Factor: Factor with which the value in the CAN data has to be multiplied to arrive at the physical value
- Unit: The unit of the signal

All signals use Big Endianness (“Motorola” convention) for their byte order.

The DIP switch setting on the board is used to differentiate between the PD board located in the front and in the back of the IMR. DIP switch 1 = 0 indicates the front board while DIP switch 1 = 1 indicates the back board. From this setting, each board determines an individual CAN ID for OUTPUT_CURRENT and SET (disable or enable).

Table 5 CAN messages for PD board

Command	ID	Byte #								Description	Rate
		0	1	2	3	4	5	6	7		
PD_CH1TO3_ OUTPUT_CURRENT (front back)	0x280 0x281	Output Current CH1 U, mA		Output Current CH2 U, mA		Output Current CH3 U, mA				Output current of each channel from 1 to 3	1 Hz
PD_CH4TO6_ OUTPUT_CURRENT (front back)	0x290 0x291	Output Current CH4 U, mA		Output Current CH5 U, mA		Output Current CH6 U, mA				Output current of each channel from 1 to 3	1 Hz
PD_CHANNEL_SET (front back)	0x300 0x301	CH1	CH2	CH3	CH4	CH5	CH6			Disable (=0) / Enable (=1) each channel	On demand

4 Quick start guide

4.1 Equipment

To flash the XMC1404 and the XDPE12254C-0000 the following equipment will be used:

- [XMC™](#) link isolated debug probe
- [USB005](#) USB dongle – interface between GUI and multiphase controller

The USB005 is used to configure the XDPE12254C-0000.

4.1.1 XMC™ Link isolated debug probe

The software for the power distribution board was developed utilizing the DAVE™ Integrated Development Environment (IDE). This IDE is available for download at no cost from the [Infineon website](#). Programming and debugging are facilitated through the XMC™ Link isolated debug probe, as depicted in [Figure 21](#). To establish a connection, the DEMO_IMR_PWR_V1 board is linked to the debug probe via the smaller 1.27 mm pitch ribbon cable and the 10-pin box header X1 (note that the larger ribbon cable is not utilized in this setup). It is essential to note that an additional external power supply is required when employing an isolated debugging probe.



Figure 21 XMC™ Link isolated debug probe [\[11\]](#)

4.1.2 USB005 USB dongle

To initiate the configuration process of the multiphase buck converter, it is necessary to utilize the PowerClient GUI. To establish a connection between the Power Distribution board and the PC, the [USB005](#) dongle (see [Figure 22](#)) is required. Notably, the programmer derives its power from the USB port, eliminating the need for an external power supply. Simply connect a USB cable between your PC and the programmer to complete the setup. The next section provides a step-by-step guide on how to download the PowerClient GUI and configure the multiphase buck controller.




Figure 22 USB005 overview

4.1.3 PowerClient GUI

To begin, you need to download and install the [PowerClient](#) GUI on your system. This is a crucial step to access the program's features.

4.1.3.1 Activating the PowerClient license

After successfully installing the PowerClient GUI, you need to insert an activation license to run the program. [Figure 23](#) shows how to activate the license.




Figure 23 PowerClient GUI activation license

The license for the PowerClient GUI is located in the following file part under *Libraries/PMBus/Config_Files/PowerClient_license.txt*.

Also, an initial xsf file (*PMBus_XDPE12254C_Config.xsf*) is located in this folder. This file serves as the configuration file for the multiphase buck controller.

4.1.3.2 Connecting the multiphase buck controller

To establish a connection with the multiphase buck controller, it is essential to utilize the USB005 dongle. Consequently, the cable should be connected to the 3-pin header in such a manner that the black cable is linked to the GND pin, as illustrated in [Figure 24](#) and [Figure 25](#).




Figure 24 Connection between power distribution board and USB005




Figure 25 Pin header to program the digital multiphase controller

4.1.3.3 Loading the system file to PowerClient

1. Navigate to the **File** menu and select the **Load System File...**

Quick start guide




Figure 26 Load System File

2. Select the corresponding configuration file, specifically *PMBus_XDPE12254C_Config.xsf*, and click **Open**. Once the file is loaded, you will notice that black dots are highlighted, indicating that the GUI is currently in offline mode
3. To switch to online mode, click on the yellow-highlighted **Offline** window located at the bottom of the screen
This action will toggle the GUI to online mode, and the black highlighted dots will subsequently change to green highlighted dots, signifying the transition. A **GuiDeviceSync** window will appear




Figure 27 Switching from Offline to Online

Quick start guide

4. In the **GuiDeviceSync** window, click **Write to Device 0xB0**

You now have the option to customize the multiphase buck controller to suit your specific requirements




Figure 28 GUI device synchronization

To customize the multiphase buck controller, navigate through the buttons at the top bar of the PowerClient GUI, as illustrated in [Figure 29](#).




Figure 29 How to configure the multiphase buck converter

Quick start guide

5. After the tuning the multiphase buck controller is complete, save the updated configuration file to the Non-Volatile Memory (NVM) by navigating to the **File** menu and select **Save Registers to NVM**

A **Saving to Memory** window will appear, displaying the number of times you can store or restore the configuration file to the Non-Volatile Memory (NVM), with a maximum of 27 instances




Figure 30 Save configuration file to NVM (non-volatile memory)

6. Click **Upload** to program the multiphase buck controller permanently, storing the configuration file in the NVM

With the configuration file successfully uploaded to the NVM, the PowerClient GUI is no longer required, and the multiphase buck converter can now operate independently. If any adjustments or modifications are needed for the multiphase buck controller, you can simply revisit the PowerClient GUI to make the necessary changes.

4.1.4 Import the ModusToolbox™ project

To import the software into the ModusToolbox™, navigate to the **File** menu, select **Import**, choose the **ModusToolbox™** and then click **Import Existing Application In-Place**.




Figure 31 Import Project into ModusToolbox™ IDE

Once the project has been successfully imported into the ModusToolbox™, its contents can be located in the **C/C++ Projects** tab, as illustrated in the following figure.

The *main.c* file contains the primary source code, while the **Libraries** folder houses additional subfolders, which in turn contain the *.c* and *.h* files specific to the BTS71033-6ESA, CAN, PMBus®, and State Machine components, in addition to the ADC driver for current measurement and SPI driver to connect the XMC™ 1404 microcontroller and BTS71033-6ESA.




Figure 32 ModusToolbox™ Project tree

4.2 Update libraries and build the application

In ModusToolbox™, generic libraries are located in *mtb_shared* folder and it is sometimes necessary to update the libraries of the project prior to building it.

To update the libraries of the project, **right click on the project folder** and select **ModusToolbox™** followed by **Library Manager**, depending on the current version, as shown in [Figure 33](#). In the Library Manager window, click **Update** and when the update is done and successful, the window can be closed (see [Figure 34](#)).




Figure 33 Updating libraries of the project via Library Manager




Figure 34 Libraries update process and result summary

When the libraries are updated, the project can now be cleaned and compiled to allow the program to be flashed to the microcontroller.

Under the **Quick Panel of ModusToolbox™**, click **Clean Application** followed by **Build Application** to compile the software.

To flash the compiled result, go to **Launches** section and click **IMR_XMC1404_PD Program (JLink)** while ensuring that the XMC™ Link programmer is connected to the SWD connector of the board and the board is powered separately.

4.3 CAN node identification

Before using the board in a system e.g., IMR, it is essential to set the unique ID of the CAN node. This is accomplished using the 8-pin DIP switch S1, which was previously described in the hardware section. Each switch pin is connected to the XMC1404 microcontroller, with a 20 kΩ pull-up resistor to 3.3 V. Notably, the

Quick start guide

switch pins operate with inverted logic, where the ON state corresponds to a logic low and the OFF state corresponds to a logic high on the XMC1404 side.




Figure 27 CAN ID 8-pin DIP Switch selection

Example: This example describes the result of the following switch position on the CAN node identifier module.

Table 7 DIP switch S1 – board identifier example

CAN ID Bit	Pin 8 – MSB	Pin 7	Pin 6	Pin 5	Pin 4	Pin 3	Pin 2	Pin 1 – LSB
Switch number	8	7	6	5	4	3	2	1
Switch position	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON
PD ID	0	0	0	0	0	0	0	1

This example DIP switch configuration sets the CAN node identifier for the DEMO_IMR_PWR_V1 board as [1] and together with the CAN message IDs that are shown in Table 5, particular message identifiers are clearly specified and this helps all boards in the system to communicate well in the CAN bus.

5 Bill of materials (BOM)

Table 6 Bill of materials

Designator	Manufacturer	Part number	Quantity	Value
C60, C63, C64, C65, C66, C68, C69, C76, C77, C83, C84, C85, C86, C92, C93, C94, C95, C103, C104, C109, C110, C111, C112, C124, C211	Würth Elektronik	885012206126	25	1µF, 50VDC
C53, C54	TDK Corporation	C1608C0G1H080D080AA	2	8pF
C2, C3, C4, C5, C6, C7, C70	Würth Elektronik	885012206089	7	10nF, 50VDC
C116	Würth Elektronik	885012107014	1	10µF, 16VDC
C55, C72, C73, C74, C75, C79, C80, C81, C82, C96, C97, C98, C99, C100, C101, C102, C105, C106, C107, C108, C117, C210	Würth Elektronik	885012106031	22	10µF, 25VDC
C11	Würth Elektronik	885012209028	1	10µF, 25VDC
C90, CFLT	Würth Elektronik	885012206091	2	22nF, 50VDC
C10, C91	Würth Elektronik	865060857005	2	47µF, 100V
C56, C57, C58, C59, C61, C62, C212, C213	Würth Elektronik	885012206095	8	100nF, 50VDC
CBOOT	Würth Elektronik	885012207098	1	100nF, 50VDC
C115	Würth Elektronik	885012207128	1	100nF, 100VDC
C67, C71, C87, C88, C113, C114, C125	Würth Elektronik	885012206125	7	220nF, 50VDC
C1, C78, C89	Würth Elektronik	885012006059	3	220pF, 50VDC
D5	Vishay	BZX584C3V3-V-G-08	1	3.3V Vz
DCLAMP	Diodes Incorporated	DDZ9701-7	1	14V
D1, D2, D3, D4	Infineon Technologies	BAS52-02V	4	45V
D9	ROHM Semiconductors	RB068MM100TFTR	1	100V/2A
D8	Würth Elektronik	150060GS55040	1	Green
D7	Würth Elektronik	150060RS55040	1	Red
G3	Infineon Technologies	XDPE12254C-0000	1	XDPE12254C-0000
G4	Infineon Technologies	TLF1963TE	1	TLF1963TE
G5	Infineon Technologies	TLS208D1EJV33	1	TLS208D1EJV33
L5, L6, L7, L8	Würth Elektronik	744325330	4	3.3uH, 16.6A
L1	Würth Elektronik	74439370220	1	22uH, 8A

Infinion Mobile Robot (IMR) power distribution

DEMO_IMR_PWR_V1 board



Bill of materials (BOM)

Designator	Manufacturer	Part number	Quantity	Value
P1	Würth Elektronik	61300311121	1	
Q1, Q2	Infineon Technologies	ISC080N10NM6	2	ISC080N10NM6
R50, R51, R57, R58	Vishay	CRCW06030000Z0EB	4	0R
RS2	Vishay	CRCW08051K00FKEAHP	1	1k
R47, R149	Vishay	CRCW06031K00FK	2	1k
R43, R44, R65	Yageo	RC0603FR-071KL	3	1k
R46, R48, R55, R56	Vishay	CRCW06031R00FK	4	1R
R1, R9, R10, R11, R12, R13	Yageo	RC0603FR-071K2L	6	1.2k
RS1	Vishay	RCS08053K00FKEA	1	3.00k
R3, R4, R5, R6, R7, R8, R14	Yageo	RC0603FR-074K7L	7	4.7k
R17	Vishay	CRCW06037K50FK	1	7.5k
R15, R16	Yageo	RC0603FR-0710KL	2	10k
RGH, RGL	Yageo	RC0603FR-0710RL	2	10R
R64	Yageo	RC0603FR-0712KL	1	12k
R45	Vishay	CRCW060313K0FK	1	13k
R41, R42	Bourns	CAT16A-2002F4LF	2	20k
R63	Yageo	RC0603FR-071KL	1	24k
R61	Vishay	CRCW060337K4FK	1	37.4k
R150	Yageo	RC0603FR-0747RL	1	47R
R52	Vishay	CRCW060349K9FK	1	49.9k
R153	Vishay	CRCW060368R0FK	1	68R
RFLT	Yageo	AC0603FR-072KL	1	100
R49	Vishay	CRCW0603200RFK	1	200R
R2	TE Connectivity	CRGQ0603F470R	1	470R
R40	Vishay	CRCW0603510RFK	1	510R
R39	Yageo	RC0603FR-07120RL	1	DNP
S1	Würth Elektronik	416131160808	1	416131160808
U1	Infineon Technologies	BTS71033-6ESA	1	BTS71033-6ESA
U5	Infineon Technologies	XMC1404-F064X0200 AA	1	IFX_XMC1404-F064X0200 AA
U6	Infineon Technologies	TLE9351BVSJ	1	TLE9351BVSJ
U7, U8, U9, U10	Infineon Technologies	TDA21490	4	TDA21490
U11	Infineon Technologies	IRS25411SPBF	1	IRS25411SPBF
X1	Sullins	EBC18DCWN-S371-Card	1	EBC18DCWN-S371-Card
X2	-	3220-10-0100-00	1	3220-10-0100-00
Y1	ECS Inc	ECS-200-8-33Q-RES	1	20MHz

Infineon Mobile Robot (IMR) power distribution

DEMO_IMR_PWR_V1 board



Bill of materials (BOM)

Designator	Manufacturer	Part number	Quantity	Value
	Infineon Technologies	USB005 dongle	1	USB005

References

- [1] Infineon Technologies AG: *Datasheet (2029-02-08): IRS25411S datasheet. V2.0.0; [Available online](#)*
- [2] Infineon Technologies AG: *Datasheet (2023-02-07): ISC080N10NM6 datasheet. V2.2; [Available online](#)*
- [3] Infineon Technologies AG: *Datasheet (2015-02-26): TLS208D1EJV33 datasheet. V1.0; [Available online](#)*
- [4] Infineon Technologies AG: *Datasheet (2012-11-08): TLE1963TE datasheet. V1.0; [Available online](#)*
- [5] Infineon Technologies AG: *Datasheet (2021-07-15): XDPE12254C datasheet. V1.0; [Available online](#)*
- [6] Infineon Technologies AG: *Datasheet (2020-12-01): TDA21490 datasheet. V1.0; [Available online](#)*
- [7] Infineon Technologies AG: *Datasheet (2021-03-23): BTS71033-6ESA datasheet. V1.10; [Available online](#)*
- [8] Infineon Technologies AG: *Datasheet (2017-11): XMC1400 AA-Step datasheet. V1.4; [Available online](#)*
- [9] *Power Management Bus; [Available online](#)*
- [10] Infineon Technologies AG: *Power Management Bus (PMBus[®]) slave with XMC[™]. (2016.09-09); [Available online](#)*
- [11] Infineon Technologies AG: *Datasheet (2015-12-11): XMC[™] Link Data Sheet. V1.0; [Available online](#)*

Glossary

IMR

Infineon Mobile Robot

PD

power distribution

Revision history

Document revision	Date	Description of changes
V 1.0	2024-06-03	Initial release
V.2.0	2025-07-30	Updated software and quick start guide sections

Trademarks

All referenced product or service names and trademarks are the property of their respective owners.

Edition 2025-07-30

Published by

Infineon Technologies AG

81726 Munich, Germany

© 2025 Infineon Technologies AG.

All Rights Reserved.

Do you have a question about this document?

Email: erratum@infineon.com

Document reference

UG132031

Warnings

Due to technical requirements products may contain dangerous substances. For information on the types in question please contact your nearest Infineon Technologies office.

Except as otherwise explicitly approved by Infineon Technologies in a written document signed by authorized representatives of Infineon Technologies, Infineon Technologies' products may not be used in any applications where a failure of the product or any consequences of the use thereof can reasonably be expected to result in personal injury.