

3300 W 54 V bi-directional phase-shift full-bridge with 600 V CoolMOS™ CFD7 and XMC™ graphical user interface

EVAL_3K3W_BIDI_PSF

About this document

Scope and purpose

This document is a getting-started guide to the Graphical User Interface (GUI) for the 3300 W bi-directional Phase-Shift Full-Bridge (PSFB) DC-DC converter ([EVAL_3K3W_BIDI_PSF](#)). The Infineon components required to follow this guide are as follows:

- EVAL_3K3W_BIDI_PSF: Infineon Technologies AG system solution for a 3300 W bi-directional DC-DC converter achieving 98 percent efficiency in buck mode and 97 percent in boost mode. The converter has telecom-level output, realized by a PSFB topology block with bi-directional capability.
- XMC™ Link: Isolated debug probe for all XMC™ microcontrollers ([KIT_XMC_LINK_SEGGER_V1](#)). The debug probe is based on SEGGER J-Link debug firmware, which enables use with DAVE™ and all common third-party compiler/IDEs (Altium Limited, Atollic, ARM/KEIL, IAR Systems, iSystem, Rowley Associates) known from the wide ARM® ecosystem.



Figure 1 3300 W bi-directional PSFB



Figure 2 XMC™ Link isolated debug probe

Table of contents

About this document.....	1
Table of contents.....	2
1 Getting started	3
1.1 Connecting to the converter with XMC™ Link	3
1.2 Launching the GUI.....	4
2 Setting up parameters	7
2.1 Output voltage adjustment.....	7
2.2 Enable/disable protections.....	8
3 Converter monitoring	9
3.1 Sense monitoring	9
3.2 Status monitoring	9
4 Browser	11
5 References	12
Revision history.....	13

Getting started

1 Getting started

1.1 Connecting to the converter with XMC™ Link

XMC™ Link is an isolated debug probe for all XMC™ microcontrollers. The debug probe is based on SEGGER J-Link debug firmware, which enables use with DAVE™ and all major third-party compiler/IDEs known from the wide ARM® ecosystem.

The XMC™ Link can be connected to the XMC™ target microcontroller by either of the debug connectors:

- 10-pin Cortex™ debug connector (2 x 5 pin, 0.05 inch, 1.27 mm)
- Eight-pin XMC™ MCU debug connector (2 x 4 pin, 0.1 inch, 2.54 mm), which supports communication between a PC/laptop and target XMC™ device via virtual COM port (UART-to-USB bridge).

Table 1 Pin-out of the eight-pin XMC™ MCU debug connector

Pin	Function	Pin name
1	SC	Serial wire clock (P0.15 P1.2)
2	SD	Serial wire data (P0.14 P1.3)
3	+	Power supply 2.5 V to 5.5 V (VDD)
4	0	Ground (VSS)
5	0	Ground (VSS)
6	+	Power supply 2.5 V to 5.5 V (VDD)
7	TX (PC to TX)	Transmission line of PC/laptop, receive line of XMC™ device (optional)
8	RX (PC to RX)	Receive line of PC/laptop, transmission line of XMC™ device (optional)

To operate the XMC™ Link, installation of the J-Link driver is required.

1. Please download the latest version from <https://www.segger.com/jlink-software.html> and install it on your PC/laptop. Note: The J-Link driver is also part of the typical installation of DAVE™ and third-party tools supporting SEGGER J-Link.
2. Connect XMC™ Link with your PC/laptop using the Micro USB cable.
3. A proper connection and installation of the J-Link driver is indicated by a constantly illuminated debug LED.
4. Connect your XMC™ target board with XMC™ Link using one of the enclosed cables (Figure 3).

XMC™ Link is powered from the Micro USB plug and typically draws about 70 mA. The on-board voltage regulator IFX54441LDV33 generates the required 3.3 V for the XMC4200 microcontroller out of the 5 V USB voltage.

However, the debug probe is not designed to provide power for the target device. The target application must power the isolated part of the debugger. The isolated side the XMC™ Link draws a few mA of current from the target application (in this case the 3300 W 54 V bi-directional converter).

Note: The converter side of the XMC™ Link is powered by the internal auxiliary bias. The auxiliary bias requires at least 100 V at the input of the converter to start up.

Getting started




Figure 3 XMC™ Link connection to the control card

1.2 Launching the GUI

Download the software and launch the GUI application (Figure 4). A splash screen appears where the user can select the so-called basic view (Figure 5) by clicking on the “Basic” button.

Note: The advanced view is only available on request. Please contact your sales representative.

Name	Date modified	Type	Size
info	27.11.2018 12:40	File folder	
FTD2XX_NET.dll	07.11.2018 15:22	Application extens...	72 KB
FTD2XX_NET	07.11.2018 15:22	XML Document	108 KB
Infineon.Comm.dll	14.12.2018 10:27	Application extens...	14 KB
Microsoft.VisualBasic.PowerPacks.Vs.dll	26.07.2012 20:41	Application extens...	264 KB
SMPS_GUI	15.01.2019 10:05	Application	886 KB

Figure 4 GUI execution file

Getting started



Figure 5 Splash screen with selection of GUI versions

While the advanced view allows the parametrization of many of the converter parameters (Figure 6), the basic view is mostly intended for monitoring the sensed values and status of the converter (Figure 7), with the exception of the output voltage set-point, which can be adjusted in both versions.




Figure 6 GUI advanced view

3300 W 54 V bi-directional phase-shift full-bridge with 600 V CoolMOS™ CFD7 and XMC™ graphical user interface



Getting started




Figure 7 3300 W bi-directional PSFB

Note: The warning message "Link lost" in Figure 7 indicates that the connection to the converter is broken. Please check the cabling and retry to re-establish the link with the button "Connect", if it does not re-establish automatically.

Setting up parameters

2 Setting up parameters

2.1 Output voltage adjustment

The nominal output voltage of the converter can be adjusted within the range of 53 V to 59.8 V. Select the new voltage setting by typing in the “Buck output voltage” text field (Figure 8). After typing follow the GUI indications:

1. Click the “Send” button (Figure 8). The new output voltage setting is updated into the controller card but it will be lost when the converter turns off.
2. Click the “Store” button (Figure 9). The new output voltage setting is stored in the Flash memory of the controller card; it won’t be lost after the converter turns off.
3. The storing function takes some time, during which the GUI is disabled. A “Storing” message appears during that time (Figure 10).




Figure 8 Use the “Send” button after modifying a parameter to actually update it in the controller




Figure 9 Use the “Store” button to permanently store new parameters in the Flash memory of the controller

3300 W 54 V bi-directional phase-shift full-bridge with 600 V CoolMOS™ CFD7 and XMC™ graphical user interface



Setting up parameters




Figure 10 The user interface confirms the parameters are being stored with the message “Storing”

Note: The “Store” button is only enabled while the converter is not running. Use the “Off” button to turn it off, then store the parameters, then use the “On” button to resume converter operation.

2.2 Enable/disable protections

In the so-called basic view it's only possible to enable/disable the “fan detection” protection. When the box is checked (Figure 11) the converter's controller can detect a faulty fan (fan not spinning), and stop the converter to protect it from possible thermal stress.

Note: The fan is often supplied externally in some efficiency measurements, with the controller of the fan tachometer sensing lines disconnected. In that scenario the protection can be disabled while the user should ensure proper air flow.




Figure 11 User interface view in buck mode converter operation

Converter monitoring

3 Converter monitoring

3.1 Sense monitoring

The GUI monitors some of the sensed controller values, which are separated into three main blocks (Figure 12):

- Converter input: the input current is estimated from a current sensing transformer placed before the high-voltage primary-side full-bridge; the input voltage is measured with a precision safety-isolated amplifier; the input power is estimated out of the current and voltage measurements.
- Converter output: the output current of the converter is measured through shunts placed in the return path; the output voltage of the converter is measured before the current sense shunts (there is a certain voltage drop along the load range); the output power is estimated out of the current and voltage measurements.
- Converter temperature: the temperature of the converter is measured at two points:
 - Ambient temperature is estimated out of the XMC™ 4200 integrated die temperature sensor.
 - Internal temperature of the converter is measured with a NTC sensor glued to the main transformer, the hottest spot of the converter.




Figure 12 GUI view in boost mode converter operation

3.2 Status monitoring

The status panel is divided into two main columns: status and faults (Figure 7). Flags in the “Status” group indicate a normal running mode (several of the flags can be activated at the same time):

- Enabled: the converter is enabled to start whenever the input and/or output voltages fall within the allowed ranges. If the converter is forced off by the GUI it won’t start up.
- Soft-start: the converter is ready to go through the soft-start sequence.
- Burst: the converter is running in so-called burst mode (very light or no load).
- Sync_mode_2: synchronous rectifiers are activated.
- Sync_mode_1: synchronous rectifiers are activated in so-called Discontinuous Conduction Mode (DCM).
- Sync_diodes: synchronous rectifiers are deactivated (light load).

Converter monitoring

Flags in the “Faults” group indicate an abnormal condition, which has caused or will cause the converter to come to a halt (with the exception of the temperature warning, which still permits the converter to run):

- Off or UVLO: the converter is not running because of an unspecified reason: input and/or output voltages out of range, forced off by the GUI, or latched up by any protection.
- Hiccup: the converter is running in so-called hiccup mode. The load current is above the maximum with the converter trying to re-start but stopping again. The converter will resume to a normal state if the load decreases within the valid range.
- Soft-start fail: the converter detected an abnormal condition during the soft-start sequence and latched up.
- UV/OV: the converter detected the output voltage going out of the valid range (above or under) and latched up.
- Fan fail: the converter didn't detect the fan spinning and latched up.
- Over-temp: the internal temperature of the converter rose above the maximum. The converter latched up.
- Temp. warning: the internal temperature is high, but still within the allowed range. The converter still runs in this mode.

4 Browser

The panel on the right-hand side is an embedded web browser where the user can navigate through additional related content (Figure 13). Use the “Home” button to come back to the initial converter page.




Figure 13 The right-hand panel of the GUI is an embedded web browser, which links to additional help content

References

5 References

- [1] “3300 W 54 V bi-directional phase-shift full-bridge with 600 V CoolMOS™ CFD7 and XMC™”,
[AN 1809 PL52 1809 081412](#)
- [2] “800 W ZVS phase-shift full-bridge evaluation board. Using 600 V CoolMOS™ CFD7 and digital control by XMC4200”, [AN 201709 PL52 027](#)
- [3] “1400 W ZVS phase-shift full-bridge evaluation board. Using 600 V CoolMOS™ CFD7 and digital control by XMC4200”, [AN 201711 PL52 003](#)

Revision history

Major changes since the last revision

Page or reference	Description of change

Other Trademarks

All referenced product or service names and trademarks are the property of their respective owners.

Edition 2019-04-01

Published by

Infineon Technologies AG

81726 Munich, Germany

© 2019 Infineon Technologies AG.

All Rights Reserved.

Do you have a question about this document?

Email: erratum@infineon.com

Document reference

UM_1904_PL52_1904_131911

IMPORTANT NOTICE

The information contained in this application note is given as a hint for the implementation of the product only and shall in no event be regarded as a description or warranty of a certain functionality, condition or quality of the product. Before implementation of the product, the recipient of this application note must verify any function and other technical information given herein in the real application. Infineon Technologies hereby disclaims any and all warranties and liabilities of any kind (including without limitation warranties of non-infringement of intellectual property rights of any third party) with respect to any and all information given in this application note.

The data contained in this document is exclusively intended for technically trained staff. It is the responsibility of customer's technical departments to evaluate the suitability of the product for the intended application and the completeness of the product information given in this document with respect to such application.

For further information on the product, technology, delivery terms and conditions and prices please contact your nearest Infineon Technologies office (www.infineon.com).

WARNINGS

Due to technical requirements products may contain dangerous substances. For information on the types in question please contact your nearest Infineon Technologies office.

Except as otherwise explicitly approved by Infineon Technologies in a written document signed by authorized representatives of Infineon Technologies, Infineon Technologies' products may not be used in any applications where a failure of the product or any consequences of the use thereof can reasonably be expected to result in personal injury.