



PSoC DEVELOPMENT BOARD SELF TEST



1

- Remove the PSoC Development Board from the kit package.



2

- Connect the AC power supply adapter.




3

- After the self-test, read the success message on the LCD screen.


Download and install the PSoC Creator™ IDE, PSoC Programmer, Kit Design Files, Documentation, and Examples from www.cypress.com/CY8CKIT-001

PSoC DEVELOPMENT BOARD SELF TEST



PSoC CY8C38 Family Processor Module

PSoC CY8C58LP Family Processor Module



For the latest information on this kit, visit www.cypress.com/CY8CKIT-001

