

QUICK START GUIDE

HYPERRAM™ self-refresh DRAM (PSRAM) Evaluation Kit

EVAL-S27KL0642

Get started

1. Register your kit by scanning the QR code on the box or go to softwaretools.infineon.com
2. Connect it to any host platform that supports HYPERBUS™ interface

www.infineon.com/hyperram



- Connects to any host platform (MCU/SoC), which supports HYPERBUS™ with 3.3 V I/Os

For more information, please visit:
www.infineon.com/hyperram

Document number: 002-42707 Rev. **
Date: 02/2026

Published by Infineon Technologies AG
Am Campeon 1-15, 85579 Neubiberg Germany

All rights reserved. © 2026
Infineon Technologies AG