Product Name	XMC™ Flasher
Release Version	1.1.1
Type Of Release*	Productive
Name of the Supplier	Infineon Technologies AG
Mode of Release	Infineon Server
Date of Release	5-Mar-18

1 Installation Requirements 2

2 Installation 3

3 Usage Examples 4

* All types of releases named as Alpha, Beta, Release Candidate and Patch are not intended to be used for production code.

1 Installation Requirements

- Oracle JAVA™ JRE 1.8.0_72 or higher
  http://www.oracle.com/technetwork/java/javase/downloads/index.html
- Segger JLINK software 5.12 or higher
  https://www.segger.com/jlink-software.html

1 Windows 7 or higher

2 Installation Procedure

1) Install Oracle Java8 JRE. If it is not yet installed in your system.
It can be downloaded from http://www.oracle.com/technetwork/java/javase/downloads/index.html

2) Install the latest Segger JLink software.
It can be downloaded from https://www.segger.com/jlink-software.html
Note: This is already present if you have already installed DAVE(TM)

3) Extract the folder XMC™ Flasher to the preferred location.

3 Usage Examples

3.1 UI interface

Double click on XMCFlasher.jar

3.2 Command prompt

3.2.1 Show all options

XMCFlasher.bat -help

3.2.2 List all device names

XMCFlasher.bat -listdevices

3.2.3 Program file

XMCFlasher.bat –p myprogram.hex –device XMC4500-1024

3.2.4 Erase flash memory

XMCFlasher.bat –erase –device XMC4500-1024