

hitex DEVELOPMENT TOOLS

Hitex Development Tools GmbH

Hitex Germany

– Head Quarters –
Greschbachstr. 12
76229 Karlsruhe
Germany

☎ +049-721-9628-0
Fax +049-721-9628-149
E-mail: Sales@hitex.de
WEB: www.hitex.de

Hitex UK

Warwick University
Science Park
Coventry CV47EZ
United Kingdom

☎ +44-24-7669-2066
Fax +44-24-7669-2131
E-mail: Info@hitex.co.uk
WEB: www.hitex.co.uk

Hitex USA

2062 Business Center Drive
Suite 230
Irvine, CA 92612
U.S.A.

☎ 800-45-HITEX (US only)
☎ +1-949-863-0320
Fax +1-949-863-0331
E-mail: Info@hitex.com
WEB: www.hitex.com

About this Readme

In order to keep you up-to-date on the latest developments and changes relating to our products, we provide this Readme file. For more information on the current software versions or hardware revisions as well as our updating service, please do not hesitate to contact your local Hitex representative.

R E A D M E

Product	EasyKit-XC800
Release Date	2008-04-02
Version	HiTOP V5.20 (Build No. 05.20.0416)

Contents

1 Loading a New Project for a Different Derivative 2

2 XC800 Support 2

1 Loading a New Project for a Different Derivative

When loading a project B (using derivative B) directly after closing project A (using derivative A), HiTOP does not load the project B SFR file setting, but the project A SFR file.

When closing project B, the project B SFR setting will be changed to the project A SFR setting.

To prevent this malfunction, proceed as follows after closing project A:

Either

- execute the **System > Connect command**, and in the **Controller selection dialog** select derivative B, then load project B via the **Project > Open** command,

or

- close HiTOP, restart it and load project B via the **Project > Open** command.

Both solutions will load project B with the correct derivative B SFR file setting.

2 XC800 Support

With this HiTOP release, the following derivatives are supported:

- XC866
- XC878
- XC886
- XC888