

J4
J5
RoHS
MICROPHONE
LEFT
MICROPHONE
RIGHT
U6
U7
U8
CAM1_DP3
CAM1_DN3
CAM1_DP0
CAM1_DN0
CAM1_DP1
CAM1_DN1
CAM1_CKP
CAM1_CKN
CAM1_DP2
CAM1_DN2