

ModusToolbox™ Sensor Designer tool user guide

ModusToolbox™ CAPSENSE™ and Multi-Sense Pack
Sensor Designer tool version 1.30.0

About this document

[A newer revision of this document may be available on the web here.](#)

Scope and purpose

The Sensor Designer tool is a standalone software tool included with the ModusToolbox™ software. The tool is used to create and configure Liquid Level and Button sensor designs.

Intended audience

This document helps application developers understand how to use the Sensor Designer tool as part of a ModusToolbox™ application.

Document conventions

Convention	Explanation
Bold	Emphasizes heading levels, column headings, menus and sub-menus
<i>Italics</i>	Denotes file names and paths.
Monospace	Denotes APIs, functions, interrupt handlers, events, data types, error handlers, file/folder names, directories, command line inputs, code snippets
File > New	Indicates that a cascading sub-menu opens when you select a menu item

Abbreviations and definitions

The following define the abbreviations and terms used in this document:

- Application – One or more projects related to each other.
- CAD – computer-aided design
- CAPSENSE™ sigma-delta – self-capacitance sensing method
- CAPSENSE – capacitive sensing
- Configurator – A GUI-based tool used to configure a resource.
- DXF – drawing exchange format
- ISX – inductive sensing method
- Liquid Level sensor – A sensor that consists of several electrodes and is designed for the liquid level calculation.
- PCB – printed circuit board
- PSOC™ – programmable system-on-chip

Reference documents

Refer to the following documents for more information as needed:

- [ModusToolbox™ tools package user guide](#)
- [CAPSENSE™ Configurator user guide](#)
- [CAPSENSE™ Tuner user guide](#)
- [Eclipse IDE for ModusToolbox™ user guide](#)
- [VS Code for ModusToolbox™ user guide](#)

Table of contents

	About this document	1
	Table of contents	2
1	Overview	3
2	Launch the Sensor Designer tool	4
2.1	VS Code and Eclipse IDE	4
2.2	Executable	4
3	Quick start	5
4	GUI description	6
5	Liquid Level tab	8
5.1	Sensor configuration	8
5.2	Sensor verification	10
6	Button tab	12
6.1	Input parameters	12
6.2	Output parameters	14
6.3	Illustration of DXF design	14
6.4	Illustration of CAD design	15
7	Version changes	16
	Revision history	17
	Disclaimer	18

1 Overview

1 Overview

The Sensor Designer tool generates sensor drawings in the *.dxf file format to be imported into PCB layouts. The tool interface contains the parameters description and illustrative images of the sensor drawings. You can add multiple [Liquid Level tab](#) and [Button tab](#) tabs to generate data for the sensor. The tool is supported on Windows, Linux, and macOS.

The screenshot displays the Sensor Designer tool interface, organized into several functional areas:

- File Menu:** Includes File, Edit, View, and Help.
- Tab Management:** Shows active tabs 'Liquid_Level0' and 'Button0'.
- SENSOR CONFIGURATION:**
 - General:** Sensor height (100.00 mm), Sensor width (35.00 mm), Liquid (Ungrounded), Ground offset (0.50 mm).
 - Extended sensor height:** Sensor bottom offset (0.00 mm), Total height (100.00 mm).
 - Front layer:** Number of electrodes (8), Electrode width (15.25 mm), Ground width (7.38 mm), Edge shift (4.56 mm), Sensing pad gap (0.50 mm), Sensor-ground gap (2.00 mm), Electrode height (11.77 mm), Tilt (14.43 mm).
 - Back layer:** Trace width (0.30 mm), Trace gap (0.70 mm), Via holes pad (0.70 mm).
 - Foam detection:** PCB type (Rigid), Core material relative permittivity (4.70), PCB material (FR4), Core material thickness (1.00 mm).
- Front and back layer design:** A detailed diagram showing the sensor's cross-section with labels for Sensor width, Sensor height, Tilt, Via hole, Ground offset, Electrode height, Sensor-ground gap, Sensing pad gap, level 0, Edge shift, Electrodes, Ground width, Shield, Via holes pad, Trace gap, and Trace width.
- PCB stackup:** A diagram showing the layers: Front solder mask, Front layer, Core, Back layer, and Back solder mask, with a label for Core material thickness.
- Overlay stack-up:** A table listing overlay parameters:

Overlay name	Relative permittivity	Thickness, mm	Liquid capacitance, fF (>350 fF)
Overlay 0	3	4	601
- Overlays between sensor and liquid:** A diagram showing the sensor and liquid interface with labels for liquid, overlay 1, overlay 2, overlay 3, and overlay.
- Generate DXF:** A green button to export the design.
- SENSOR VERIFICATION:** A section for checking the design.
- Notice List:** A table for tracking issues:

Fix	Description	Location
Ready		

2 Launch the Sensor Designer tool

2 Launch the Sensor Designer tool

There are several ways to launch the Sensor Designer tool, and those ways depend on the application, and how you use the various tools.

2.1 VS Code and Eclipse IDE

VS Code and Eclipse have tools to launch the Sensor Designer tool from within an open application. Refer to the applicable user guide for more details:


- [VS Code for ModusToolbox™ user guide](#)
- [Eclipse IDE for ModusToolbox™ user guide](#)

2.2 Executable

You can launch the Sensor Designer tool GUI by running its executable as appropriate for your operating system. By default, it is installed here:

<install_dir>/ModusToolbox/packs/ModusToolbox-Multi-Sense-Pack/tools/sensor-designer-tool

When opened this way, the Sensor Designer tool GUI opens blank without any information.



3 Quick start

3 Quick start

This section provides a simple workflow for how to use the Sensor Designer tool.

1. [Launch the Sensor Designer tool.](#)
2. Create a new or open an existing sensor configuration to edit it.
3. Edit the configuration.
4. Generate a Liquid Level or Button sensor drawing.
5. Save the configuration.
6. Click the **Generate DXF** button to generate a *.dxf file to the specified directory. Then, import the file to the CAD software.

4 GUI description

4 GUI description

Menus

- **File**
 - **New** – Creates a new file with new configuration.
 - **Open...** – Opens a specified *.mtbsensor configuration file. The current configuration file, if any, will be closed. If there are unsaved changes, a dialog opens asking to save or not.
 - **Close** – Closes the current configuration file.
 - **Save** – Saves the current configuration file.
 - **Save As...** – Saves the existing file under a different name.
 - **Open in System Explorer** – This opens your computer’s file explorer tool to the folder that contains the *.mtbsensor configuration file.
 - **Recent files** – Shows recent files that you can open directly.
 - **Exit** – Closes the tool. You will be prompted to save any pending changes.
- **Edit**
 - **Undo** – Undoes the last action or sequence of actions.
 - **Redo** – Redoes the last undone action or sequence of undone actions.
- **View**
 - **Notice List** – Hides or shows the Notice List pane. The pane displays by default.
 - **Toolbar** – Hides or shows the Toolbar.
 - **Reset View** – Resets the view to the default.
- **Help**
 - **View Help** – Opens this document.
 - **About Sensor Designer tool** – Opens the About box for version information, with links to open <https://www.infineon.com> and the current session log files of the application.

Toolbar

The toolbar contains common commands from the **File** and **Edit** menus. Use the check box under the **View** menu to show or hide the toolbar.



Sensor tabs


The [Liquid Level tab](#) and [Button tab](#) sensor tabs represent the relevant sensor configuration. A tab contains a set of parameters to configure the settings of a sensor drawing pattern and generate it to the *.dxf file.

The tab name is provided as the default name for the generated *.dxf file.



Select sensor

To create new tab configuration, click **New** on the **File** menu. It will display the "Select sensor" dialog.



4 GUI description

- **Sensor type** – **Liquid Level** or **Button**.
- **Sensing method** – **CSD** for **Liquid Level**, **ISX** for **Button**.

Move actions

- To add a tab for a new level, click the green (+) button to display the "Select sensor" dialog.
- To remove a tab, click the red (-) button.
- To rename the sensor, double-click its name.
- To change the tabs order, left-click a tab name and drag it to the preferred position.

5 Liquid Level tab

5 Liquid Level tab

The **Liquid Level** tab is used to design a liquid level sensor for the preferred application requirements and generate a *.dxf file.

SENSOR CONFIGURATION

General

Sensor height: 120.00 mm
 Sensor width: 35.00 mm
 Liquid: Ungrounded
 Ground offset: 0.50 mm

Extended sensor height

Sensor bottom offset: 13.00 mm
 Total height: 133.00 mm

Front layer

Number of electrodes: 10
 Electrode width: 15.25 mm
 Ground width: 7.38 mm
 Edge shift: 4.83 mm
 Sensing pad gap: 0.50 mm
 Sensor ground gap: 2.00 mm
 Electrode height: 12.56 mm
 Tilt: 15.45 mm

Back layer

Trace width: 0.30 mm
 Trace gap: 0.70 mm
 Via holes pad: 0.70 mm

Foam detection

PCB type: Rigid
 Core material relative permittivity: 5.70
 PCB material: FR4
 Core material thickness: 1.00 mm
 Enable foam detection analysis for the selected sensor design

Front and back layer design

PCB stackup

Front solder mask
 Front layer
 Core material thickness
 Back layer
 Back solder mask

SENSOR VERIFICATION

Overlay stack-up

Overlay name	Relative permittivity	Thickness, mm	Liquid capacitance, fF (>350 fF)
Overlay 0	3	4	214
Overlay 1	3	4	
Overlay 2	3	4	

Overlays between sensor and liquid

Liquid
 Overlay thickness
 Overlay 0
 Possible overlay 1
 Possible overlay 2
 Possible overlay 3
 Sensor

Core material thickness value range: 0.01 to 5

Commands

- **Restore Defaults** – Restores parameters values on the current tab to their default values.
- **Copy All** – Click this button to copy the list of input and output parameters to the system clipboard as plain text.

5.1 Sensor configuration

General

General

Sensor height: 100.00 mm
 Sensor width: 35.00 mm
 Liquid: Ungrounded
 Ground offset: 0.50 mm

- **Sensor height** – The height (mm) of the sensor measurable stack-up. The range – 30.00-422.5, default – 100.00.
- **Sensor width** – The width (mm) of the entire sensor stack-up. The range – 20.00-60.00, default – 35.00.
- **Liquid** – Select whether the liquid is Ungrounded or Grounded. Default – Ungrounded.
- **Ground offset** – The spacing gap (mm) between the outer ground traces and the edge of the sensor area. The range – 0.5-15, default – 0.50.

5 Liquid Level tab

Extended sensor height

The extended sensor height improves the accuracy near the bottom of calculated levels.



- **Sensor bottom offset** – The height of the measurement offset. The range – 0-99.99, default – 12.00.
- **Total height** – Read-only. The total height of the sensor.

Front layer

Select the relevant check box to use the parameter as an input parameter.



- **Number of electrodes** – The total number of electrodes. The range – 3-32.
- **Electrode width** – The horizontal width (mm) of each electrode. The range – 1-59.99.
- **Ground width** – Read-only. The width (mm) of the ground traces.
- **Edge shift** – Read-only. The edge shift (mm) area on the top and bottom electrodes. This value can be negative.
- **Sensing pad gap** – The space (mm) between the electrodes. The range – 0.1-10.
- **Sensor-ground gap** – The horizontal space (mm) between the electrodes and neighboring ground traces. The range – 0.1-10.
- **Electrode height** – Read-only. The height (mm) of an electrode when measured at a single point on the horizontal axis.
- **Tilt** – Read-only. The distance (mm) between the highest and lowest points of the tilted edge of an electrode.


Back layer



- **Trace width** – The width (mm) of the trace, which connects some segment of the Liquid Level sensor with the connector. The range – 0.1-10, default – 0.30.
- **Trace gap** – The distance (mm) between adjacent trace widths. The range – 0.1-10, default – 0.70.
- **Via holes pad** – The diameter (mm) of through-hole pads for each sensor between the front and back layer. The range – 0.1-10, default – 0.70.

5 Liquid Level tab

Illustration of front and back layer design parameters



Foam detection

Enables the foam detection analysis for the selected sensor design.

Foam detection

PCB type: Rigid


PCB material: FR4

Core material relative permittivity: 4.70

Core material thickness: 1.00 mm
 ●

- **PCB type** – The PCB technology used for the sensor: Rigid, Flex, Other.
- **Core material relative permittivity** – The relative permittivity of the PCB core material. The range – 2-10, default – 4.70.
- **PCB material** – The PCB base material used for the sensor. Available: FR4, FR5, Getek, Rogers4350, Teflon, Polyimide, Polyester, Polyethylene Naphthalate, Liquid Crystal Polymer, Arylon.
- **Core material thickness** – The thickness (mm) of the PCB core material between the conductive layers. The range – 0.01-5, default – 1.00.

Illustration of PCB stackup



Generate DXF

Click this button to generate a *.dxf file of the calculated liquid level sensor to a specified file location.

Generate DXF

5.2 Sensor verification

Overlay stack-up

Overlay name	Relative permittivity	Thickness, mm	Liquid capacitance, fF (>350 fF)
Overlay 0	3	4	601 ●

5 Liquid Level tab

Toolbar


- To add an overlay, click the "plus" icon.
- To remove an overlay, click the "cross" icon.
- To move an overlay up/down, use the arrows.

Verification parameters table

- **Overlay name** – The name of an overlay stack-up.
- **Relative permittivity** – Relative permittivity of the overlayer/stack-up material.
- **Thickness, mm** – The thickness of an overlay stack-up.
- **Liquid capacitance, fF (>350fF)** – The guarding value of calculated sensor capacitance depending on the sensor design and amount of added liquid. In short, the sensor capacitance caused by added liquid. This parameter must exceed 350fF. The sign in the executive button and a message in the Notice List will be displayed to the indicated inefficient design.

Note: *When the value is below 350fF, you can still generate a *.dxf file but the sensor may have low performance.*


Illustration of overlays between sensor and liquid



6 Button tab

6 Button tab

The **Button** tab is used to design an inductive sensing coil and its parameters for the preferred application requirements and generate a *.dxf file.



Commands

- **Restore Defaults** – Restores parameters values on the current tab to their default values.
- **Copy All** – Click this button to copy the list of input and output parameters to the system clipboard as plain text.

6.1 Input parameters

The **Input parameters** include **Overlay**, **Sensor**, and **PCB** parameters.

Note:

The first output parameter will always be the same parameter, which is locked (lock icon) in the **Input parameters** section. Lock the relevant parameter by double-clicking its unlocked icon (unlock icon). Only one parameter can be locked at a time.

6 Button tab

Overlay parameters

Overlay parameters

Number of buttons:

Button shape:

Button height: mm

Button width: mm

Overlay metal:

Overlay metal thickness: mm

- **Number of buttons** – The number of buttons in the specified widget. Default – 1.
- **Button shape** – Circular.
- **Button diameter (mm)** – The range is 8-28, default – 20.
- **Overlay metal ¹⁾** – Stainless Steel, Aluminum. Default – Stainless Steel.
- **Overlay metal thickness (mm)** – The thickness of the specified overlay. The range is 0.2-0.5, default – 0.30.
 - Stainless Steel – The range is 0.2-0.5, default – 0.30.
 - Aluminum – The range is 0.25-0.5, default – 0.30.

Sensor parameters

Sensor parameters

Coil shape:

Cavity thickness/airgap: mm

Minimum SNR: times

- **Coil shape** – Circular.
- **Cavity thickness/airgap (mm)** – The gap between the overlay and the sensor coil. The range is 0.3-7. Default – 1.10.
- **Minimum SNR (times)** – The minimum SNR required for the sensor optimum performance. The range is 1-40.

PCB parameters

PCB parameters

Trace width and space (Mil):

Number of layers:

PCB isolator/dielectric material thickness (mm)

Cu1-Cu2:


- **Trace width and space (Mil)** – The minimum sensor PCB trace width for generating output parameters. Select from: 3.5, 4.0, 5.0, or 7.0. Default – 5.
- **Number of layers** – The number of Cu layers. Select from: 1, 2 or 4. Default – 2.
- **PCB isolator/dielectric material thickness (mm)** – Enabled for more than 1 layer. The thickness of PCB Isolator or dielectric material used between Cu layers.
 - For 2 layers, Cu1-Cu2, select from: 0.24, 0.4, 1.0, 1.2. Default – 0.24.
 - For 4 layers, the spaces between the layers are fixed: 0.24 – 1.0 – 0.24.

¹ Titanium, Copper – not supported for this release.

6 Button tab



Generate DXF

Click this button to generate a *.dxf file of the calculated button sensor to a specified file location.



This button is disabled if the calculated value is beyond the allowed range and the first field of the **Output parameters** indicates that.

6.2 Output parameters

The first output parameter will always be the same parameter, which is locked  in the Input parameters section. Lock the relevant parameter by double-clicking its unlock  icon .

Output parameters	
Minimum SNR:	35.5
Calculated SNR required for optimum-working sensor	Deflection (µm): 11.7
	D _{IN} (mm): 1.0
	D _{OUT} (mm): 15.0
Button-to-button spacing (mm):	5.0
Minimum force required (N):	3.0
Maximum sensor frequency (MHz):	2.88
Estimated sensor inductance (µH):	10.7
Number of turns:	28
Via size (Mil):	24
Via space (Mil):	8

Note: Only one parameter can be locked at a time.

- **Button height and width, Button diameter, Minimum SNR (times), Overlay metal thickness, and Cavity thickness/airgap** – The calculated value of a specified parameter.
- **Deflection (µm)** – The overlay deflection for the minimum force applied to trigger the sensor to achieve the calculated or specified SNR.
- **D_{IN} (mm)** – The sensor-coil inner diameter/diagonal.
- **D_{OUT} (mm)** – The sensor-coil outer diameter/diagonal. Always – 75 % of the referred button size.
- **Button-to-button spacing (mm)** – The minimum spacing between buttons.
- **Minimum force required (N)** – The minimum sensor-activation force to achieve the calculated or specified SNR. Always – 3 N.
- **Maximum sensor frequency (MHz)** – The maximum sensor-drive frequency.
- **Estimated sensor inductance (µH)** – The estimated effective sensor coil inductance. The estimate is based on the number of coil turns, trace width, PCB layers, PCB layers spacing.
- **Number of turns** – The number of coil turns per each layer.
- **Via size (Mil)** – The diameter of the through-hole pad in the multi-layer PCB.
- **Via space (Mil)** – Spacing between through-hole pads and coil wire in the multi-layer PCB.


6.3 Illustration of DXF design

Displays the calculated structure of a designed sensor array.

6 Button tab


Sensor coil

The illustrative image of a sensor coil.



Stack-up

The illustrative image of a DXF Stack-up.




6.4 Illustration of CAD design

Displays the calculated mechanical structure of a designed button.


Mechanicals

The illustrative image of the buttons' placement.



Stack-up

The illustrative image of the CAD stack-up.



7 Version changes

7 Version changes

Version	Change descriptions
1.0	New tool.
1.10	Improved ISX Button tab design and calculation Unified Liquid Level and ISX Button tabs behavior
1.20	Updated Liquid Level sensor dimensions. Updated GUI style.
1.21	Restricted Coil Shape to the Circular option for ISX Button sensors. Added core material estimation for the foam rejection feature.
1.30	Added the extended sensor height feature. Renamed "foam rejection" to "foam detection".

Revision history

Revision history

Revision	Date	Description
**	2025-02-12	New document.
*A	2025-03-04	Updated to version 1.10.
*B	2025-10-06	Updated to version 1.20.
*C	2026-04-14	Updated to version 1.21.
*D	2026-05-22	Updated to version 1.30.

Trademarks

All referenced product or service names and trademarks are the property of their respective owners.

Edition 2026-05-22

Published by

Infineon Technologies AG

81726 Munich, Germany

© 2026 Infineon Technologies AG

All Rights Reserved.

Do you have a question about any aspect of this document?

Email: erratum@infineon.com

Document reference

IFX-the1750203462653

Important notice

The information contained in this application note is given as a hint for the implementation of the product only and shall in no event be regarded as a description or warranty of a certain functionality, condition or quality of the product. Before implementation of the product, the recipient of this application note must verify any function and other technical information given herein in the real application. Infineon Technologies hereby disclaims any and all warranties and liabilities of any kind (including without limitation warranties of non-infringement of intellectual property rights of any third party) with respect to any and all information given in this application note.

The data contained in this document is exclusively intended for technically trained staff. It is the responsibility of customer's technical departments to evaluate the suitability of the product for the intended application and the completeness of the product information given in this document with respect to such application.

Warnings

Due to technical requirements products may contain dangerous substances. For information on the types in question please contact your nearest Infineon Technologies office.

Except as otherwise explicitly approved by Infineon Technologies in a written document signed by authorized representatives of Infineon Technologies, Infineon Technologies' products may not be used in any applications where a failure of the product or any consequences of the use thereof can reasonably be expected to result in personal injury.