

# Getting started with TRAVEO™ T2G family MCUs in ModusToolbox™

## About this document

### Scope and purpose

This application note helps you explore the TRAVEO™ T2G family MCU architecture and development tools and shows you how to create your first project using the Eclipse IDE for ModusToolbox™ software. This application note also guides you to more resources available online to accelerate your learning about TRAVEO™ T2G family MCU.

### Intended audience

This document is intended for users who are new to TRAVEO™ T2G family MCU and ModusToolbox™ software.

### Associated part family

[CYT4BF MCU](#)

[CYT2BL MCU](#)

[CYT4DN MCU](#)

### Software version

[ModusToolbox™ software](#) 3.5 or above.

---

**Table of contents****Table of contents**

<b>About this document</b> .....	1
<b>Table of contents</b> .....	2
<b>1</b> <b>Introduction</b> .....	4
<b>2</b> <b>Development ecosystem</b> .....	7
2.1 TRAVEO™ T2G family MCU resources .....	7
2.2 Firmware/application development .....	7
2.2.1 Choosing an IDE .....	7
2.2.2 ModusToolbox™ software .....	7
2.2.3 TRAVEO™ T2G family MCU software resources .....	9
2.2.3.1 Configurators .....	9
2.2.3.2 Library management for TRAVEO™ T2G family MCU .....	9
2.2.3.3 Software development for TRAVEO™ T2G family MCU .....	9
2.3 Support for other IDEs .....	11
2.4 FreeRTOS support with ModusToolbox™ .....	11
2.5 Programming/debugging .....	12
2.6 TRAVEO™ T2G family MCU development kits .....	12
<b>3</b> <b>Device features</b> .....	13
3.1 CYT4BF series .....	13
3.2 CYT2BL series .....	15
3.3 CYT4DN series .....	17
<b>4</b> <b>My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ software</b> ..	21
4.1 Prerequisites .....	21
4.1.1 Hardware .....	21
4.1.2 Software .....	21
4.2 Using these instructions .....	21
4.3 About the design .....	21
4.4 Part 1: Create a new application .....	22
4.5 Part 2: View and modify the design .....	24
4.6 Part 3: Write firmware .....	27
4.6.1 Firmware flow .....	27
4.7 Part 4: Build the application .....	35
4.8 Part 5: Program the device .....	36
4.9 Part 6: Test your design .....	38
<b>5</b> <b>How to use the Qt Design Studio</b> .....	41
<b>6</b> <b>Summary</b> .....	42
<b>References</b> .....	43
<b>Glossary</b> .....	44

---

## Table of contents

<b>Revision history</b> .....	45
<b>Disclaimer</b> .....	46

---

## 1 Introduction

### 1 Introduction

The TRAVEO™ T2G family MCU device is a microcontroller targeted at automotive applications. The TRAVEO™ T2G family CYT4BF MCU integrates the following features on a single chip:

- Up to two 350 MHz 32-bit Arm® Cortex®-M7 CPUs each with the following:
  - Single-cycle multiply
  - Single-/double-precision floating point unit (FPU)
  - 16 KB data cache, 16 KB instruction cache
  - Memory protection unit (MPU)
  - 16-KB instruction and 16-KB data tightly-coupled memory (TCM)
- 100 MHz 32-bit Arm® Cortex® M0+ CPU with single-cycle multiply and MPU
- Programmable analog and digital peripherals
- Up to 8384 KB of code flash with an additional, up to 256 KB of work flash and an internal SRAM of up to 1024 KB
- TRAVEO™ T2G family CYT4BF MCU is suitable for a variety of power-sensitive applications such as the following:
  - Body control module (BCM)
  - Gateway
  - Infotainment
  - Lighting
  - Network sound system

The TRAVEO™ T2G family CYT2BL MCU integrates the following features on a single chip:

- Up to 160 MHz 32-bit Arm® Cortex®-M4F CPUs each with the following:
  - Single-cycle multiply
  - Single-precision/double-precision floating point unit (FPU)
  - Memory protection unit (MPU)
- 100 MHz 32-bit Arm® Cortex® M0+ CPU with single-cycle multiply and MPU
- Programmable analog and digital peripherals
- Up to 4160 KB of code flash with an additional, up to 128 KB of work flash and an internal SRAM of up to 512 KB
- CYT2BL MCU is suitable for a variety of power-sensitive applications such as the following:
  - Body control module (BCM)
  - Heating, ventilation, and air conditioning (HVAC)
  - Lighting

The TRAVEO™ T2G family CYT4DN MCU integrates the following features on a single chip:


- 2D and 2.5D (perspective warping, 3D effects) graphics engine
- Up to two 320 MHz 32-bit Arm® Cortex®-M7 CPUs each with the following:
  - Single-cycle multiply
  - Single-precision/double-precision floating point unit (FPU)
  - 16 KB data cache, 16 KB instruction cache
  - Memory protection unit (MPU)
  - 64 KB instruction and 64 KB data tightly-coupled memory (TCM)
- 100 MHz 32-bit Arm® Cortex® M0+ CPU with single-cycle multiply and MPU
- Programmable analog and digital peripherals

## 1 Introduction

- Up to 6336 KB of code flash with an additional, up to 128 KB of work flash, and an internal SRAM of up to 640 KB
- TRAVEO™ T2G family CYT4DN MCU is suitable for a variety of power-sensitive applications such as the following:
  - Automotive instrument cluster
  - Head-up displays (HUD)
  - Hybrid instrument cluster
  - Virtual instrument cluster

The [ModusToolbox™ software environment](#) supports TRAVEO™ T2G family MCU application development with a set of tools for configuring the device, setting up the peripherals, and complementing your projects with world-class middleware. See the [Infineon](#) GitHub repo for the BSP for KIT\_T2G-B-H\_EVK/KIT\_T2G-B-H\_LITE/KIT\_T2G-B-E\_LITE/KIT\_T2G-C-2D-6M\_LITE, libraries for popular functionality like device firmware upgrade (DFU) and emWin, and a comprehensive array of example applications to get you started.

[Figure 1](#) illustrates an application-level block diagram for a real-world use case using a TRAVEO™ T2G family MCU.



**Figure 1 Application-level block diagram using TRAVEO™ T2G family MCU**

TRAVEO™ T2G family MCU is a highly capable and flexible solution. For example, the real-world use case in [Figure 1](#) takes advantage of the following features:

- A buck converter for ultra-low-power operation
- An analog front-end (AFE) within the device to condition and measure sensor outputs such as temperature sensor
- Serial Communication Blocks (SCBs) to interface with multiple digital sensors such as motion sensors
- Programmable digital logic (smart I/O) and peripherals (Timer Counter PWM or TCPWM) to drive the motor and LEDs respectively
- Up to 10 CAN FD channels with increased data rate (up to 8 Mbps) supports all the requirement of CAN FD specification V1.0 for non-ISO CAN FD
- Up to two 10/100/1000 Mbps Ethernet MAC interfaces conforming to IEEE-802.3az supports MII/RMII/RGMII/AVB/PTP PHY interfaces
- Product security features managed by CM0+ CPU and application features executed by CM7 CPUs

[Table 1](#) provides an overview of the product line.

---

## 1 Introduction

**Table 1** TRAVEO™ T2G family MCU product line

Device series	Details
TRAVEO™ T2G CYT4BF series	Triple-core architecture: 350 MHz Arm® Cortex®-M7 and 100 MHz Cortex®-M0+ 8 MB flash, 1 MB RAM Packages: 176 TEQFP, 272/320 BGA
TRAVEO™ T2G CYT2BL series	Two-core architecture: 160 MHz Arm® Cortex®-M4F and 100 MHz Cortex®-M0+ 4 MB flash, 512 KB RAM Packages: 64/80/100/144/176 LQFP
TRAVEO™ T2G CYT4DN series	Triple-core architecture: 320 MHz Arm® Cortex®-M7 and 100 MHz Cortex®-M0+ 6 MB flash, 640 KB RAM 2D and 2.5D graphics engine, 4096 KB Video RAM Package: 327 BGA

**Note:** All features are not available in all the devices in a product line. For more details, see the [Device datasheets](#).

This application note introduces you to the capabilities of the TRAVEO™ T2G family MCU, gives an overview of the development ecosystem, and gets you started with a simple “Hello World” application wherein you learn to use the TRAVEO™ T2G family MCU. Additionally, provides how to create the application from an empty starter application, but the completed design is available as a [code example for ModusToolbox™ on GitHub](#).

For hardware design considerations, see [References](#).

---

## 2 Development ecosystem

# 2 Development ecosystem

## 2.1 TRAVEO™ T2G family MCU resources

The 32-bit TRAVEO™ T2G Arm® Cortex® Microcontroller webpage contains wealth of data that will assist you in selecting the right TRAVEO™ T2G device and quickly and effectively integrate it into your design. For a comprehensive list of TRAVEO™ T2G family MCU resources, see [References](#). The following is an abbreviated list of resources for the TRAVEO™ T2G family MCUs.

- Overview: [TRAVEO™ T2G family MCU webpage](#)
- Product selectors: [TRAVEO™ T2G CYT4BF/CYT2BL/CYT4DN](#) series MCU
- [Device datasheets](#) describe and provide electrical specifications for each device family
- [Application notes](#) and [code examples](#) cover a broad range of topics, from basic to advanced
- [References](#) provide detailed descriptions of the architecture and registers in each device family
- Development tools: [KIT\\_T2G-B-H\\_EVK](#)/[KIT\\_T2G-B-H\\_LITE](#)/[KIT\\_T2G-B-E\\_LITE](#)/[KIT\\_T2G\\_C-2D-6M\\_LITE](#)
- Technical support: [TRAVEO™ T2G family community forum](#), [knowledge base articles](#)

## 2.2 Firmware/application development

For application development with the TRAVEO™ T2G family MCUs, use the ModusToolbox™ development platform. ModusToolbox™ software includes configuration tools, low-level drivers, middleware libraries, operating system support, and other packages for creating MCU.

### 2.2.1 Choosing an IDE

ModusToolbox™ software, the latest-generation toolset, includes the Eclipse IDE and is therefore supported across Windows, Linux, and macOS platforms. The Eclipse IDE for ModusToolbox™ is integrated with quick launchers for tools and design configurators in the Quick Panel. Third-party IDEs supported by ModusToolbox™ include Visual Studio Code, Arm® MDK (μVision), and IAR Embedded Workbench. The associated hardware and middleware configurators also work on all three host operating systems.

Use ModusToolbox™ to take advantage of the power and extensibility of an Eclipse-based IDE.


### 2.2.2 ModusToolbox™ software

ModusToolbox™ is a collection of tools and software that provides an immersive development experience for creating converged MCUs and allows you to integrate our devices into your existing development methodology. To achieve this goal, ModusToolbox™ leverages popular third-party ecosystems such as FreeRTOS and Arm® Mbed OS, and adds specific features for security.

Eclipse IDE for ModusToolbox™ is a multi-platform development environment that supports application configuration and development.

[Figure 2](#) shows a high-level view of the tools/resources included in the ModusToolbox™ software. For a more in-depth overview of the ModusToolbox™ software, see the [ModusToolbox™ user guide](#).

## 2 Development ecosystem



**Figure 2 ModusToolbox™ software**

The ModusToolbox™ installer includes the design configurators and tools, and the build system infrastructure. The build system infrastructure includes the new project creation wizard that can be run independent of the Eclipse IDE, the make infrastructure, and other tools.

All the ModusToolbox™ development flows depend on the provided low-level resources. These include:

- **Board support packages (BSP)** – A BSP is the layer of firmware containing board-specific drivers and other functions. The board support package is a set of libraries that provide APIs to initialize the board and provide access to board level peripherals. It includes low-level resources such as Peripheral Driver Library (PDL) for TRAVEO™ T2G family MCU and has macros for board peripherals. It uses the HAL to configure the board. Custom BSPs can be created to enable support for end-application boards. See the “Board Support Packages” section in the [ModusToolbox™ user guide](#) for more information
- **Hardware Abstraction Layer (HAL)** – HAL provides a high-level interface to configure and use hardware blocks on MCUs. It is a generic interface that can be used across multiple product families. The focus on ease-of-use and portability means that the HAL does not expose all the low-level peripheral functionality. The HAL wraps the lower-level drivers (such as TRAVEO™ T2G family PDL) and provides a high-level interface to the MCU. The interface is abstracted to work on any MCU. This helps you write application firmware independent of the target MCU

The HAL can be combined with platform-specific libraries (such as TRAVEO™ T2G family PDL) within a single application. You can leverage the HAL's simpler and more generic interface for most of an application, even if one portion requires finer-grained control

**Note:** The CYT4DN series does not support HAL for application code.

- **Peripheral Driver Library (PDL)** – The PDL integrates the device header files, startup code, and peripheral drivers into a single package. The PDL supports the TRAVEO™ T2G family MCU device family. The drivers abstract the hardware functions into a set of easy-to-use APIs. These are fully documented in the PDL API Reference

The PDL reduces the need to understand register usage and bit structures, thus easing software development for the extensive set of peripherals in the TRAVEO™ T2G family MCU series. You configure the driver for your application, and then use API calls to initialize and use the peripheral

- Extensive middleware libraries that provides specific capabilities to an application. All the middleware is delivered as libraries and via GitHub repositories

## 2 Development ecosystem

### 2.2.3 TRAVEO™ T2G family MCU software resources

The TRAVEO™ T2G family MCU software includes driver and middleware configurators to get you started developing firmware with TRAVEO™ T2G family MCU. It contains configurators, drivers, libraries, middleware, various utilities, Makefiles, and scripts. It also includes relevant drivers, middleware, and examples for use with industrial applications. You may use any or all tools in any environment you prefer.

#### 2.2.3.1 Configurators

ModusToolbox™ software provides graphical applications called configurators that make it easier to configure a hardware block. For example, instead of having to search through all the documentation to configure a serial communication block as a UART with a desired configuration, open the appropriate configurator and set the baud rate, parity, and stop bits. After saving the hardware configuration, the tool generates the C code to initialize the hardware with the desired configuration.

Configurators are independent of each other, but they can be used together to provide flexible configuration options. They can be used standalone, in conjunction with other tools, or within a complete IDE. Configurators are used for:

- Setting options and generating code to configure drivers
- Setting up connections such as pins and clocks for a peripheral
- Setting options and generating code to configure middleware

The following configurators are available for TRAVEO™ T2G family MCU applications:

- **Device Configurator:** Sets up the system (platform) functions and the basic peripherals (for example, UART, Timer, and PWM)
- **QSPI Configurator:** Configures the external memory and generates the required code
- **Smart I/O Configurator:** Configures the smart I/O

Each of these configurators creates their own files (e.g., `design.cyqspi` for QSPI). The configurator files (`design.modus` or `design.cyqspi`) are usually provided with the BSP. The files are copied into the application when an application is created based on a BSP. Additionally, you can create custom device configurator files for an application and override the BSP-provided devices.

#### 2.2.3.2 Library management for TRAVEO™ T2G family MCU

With the release of ModusToolbox™ v3.5, applications can optionally share board support packages (BSPs) and libraries. If needed, different applications can use different versions of the same BSP or library. The file types associated with libraries using this flow have a `.mtb` extension.

Section [My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ software](#) of this document describes creating a new application using this flow.

For more information on ModusToolbox™ flow, see the [Library Manager user guide](#) located at `<install_dir> / ModusToolbox/tools_<version>/library-manager/docs/library-manager.pdf`.

#### 2.2.3.3 Software development for TRAVEO™ T2G family MCU

Significant source code and tools are provided to enable software development for TRAVEO™ T2G family MCUs. You use tools to specify how you want to configure the hardware, generate code for that purpose which you use in your firmware, and include various middleware libraries for additional functionality, like FreeRTOS. This source code makes it easier to develop the firmware for supported devices. It helps you quickly customize and build firmware without the need to understand the register set.

In the ModusToolbox™ environment, you use configurators to configure either the device or a middleware library, such as QSPI functionality.

## 2 Development ecosystem

The TRAVEO™ T2G family MCU Peripheral Driver Library code is delivered as the [mtb-pdl-cat1](#) library. Middleware is delivered as separate libraries for each feature/function.

Whether you use the Eclipse IDE, a third-party IDE, or the command line, firmware developers who wish to work at the register level should see the driver source code from the PDL. The PDL includes all the device-specific header files and startup code you need for your project. It also serves as a reference for each driver. Because the PDL is provided as source code, you can see how it accesses the hardware at the register level.

Some devices do not support particular peripherals. The PDL is a superset of all the drivers for any supported device. This superset design means:

- All API elements needed to initialize, configure, and use a peripheral are available
- The PDL is useful across various TRAVEO™ T2G family MCU devices, regardless of available peripherals
- The PDL includes error checking to ensure that the targeted peripheral is present on the selected device

This enables the code to maintain compatibility across products of the TRAVEO™ T2G family MCU family as long as the peripherals are available. A device header file specifies the peripherals that are available for a device. If you write the code that attempts to use an unsupported peripheral, you will get an error at compile time. Check the datasheet for the specific device to ensure that the peripheral is supported before writing the code to use that peripheral.

As shown in [Figure 3](#), with the Eclipse IDE for ModusToolbox™ software, you can:

1. Choose a board support package (BSP)
2. Create a new application based on a list of starter applications, filtered by kit
3. Add middleware
4. Develop your application firmware using the HAL or PDL for TRAVEO™ T2G family MCU

**Note:** *The CYT4DN series does not support HAL for application code.*

## 2 Development ecosystem




Figure 3

Eclipse IDE for ModusToolbox™ resources and middleware

### 2.3 Support for other IDEs

You can develop a firmware for TRAVEO™ T2G family MCUs using your favorite IDE such as [IAR Embedded Workbench](#) or [Visual Studio Code](#).

ModusToolbox™ configurators are standalone tools that can be used to set up and configure TRAVEO™ T2G family MCU resources and other middleware components without using the Eclipse IDE. The device configurator and middleware configurator use the design.x files within the application workspace. You can then point to the generated source code and continue developing firmware in your IDE.

If there is a change in the device configuration, edit the design.x files using the configurators and regenerate the code for the target IDE. It is recommended that you generate resource configurations using the configuration tools provided with ModusToolbox™ software.


### 2.4 FreeRTOS support with ModusToolbox™

Adding native FreeRTOS support to a ModusToolbox™ application project is like adding any library or middleware. You can import the FreeRTOS middleware into your application by using the Library Manager.

## 2 Development ecosystem

Select the application project and click the **Library Manager** link in the **Quick Panel**. Select **freertos** from the **Libraries > TRAVEO™ T2G family MCU Middleware** dialog, as shown in [Figure 4](#).

The .mtb file pointing to the FreeRTOS middleware is added to the application project. The middleware content is also downloaded and placed inside the corresponding folder called freertos. To continue working with FreeRTOS, follow the steps in the Quick Start section of [FreeRTOS documentation](#).



**Figure 4** Import FreeRTOS middleware in ModusToolbox™ application

## 2.5 Programming/debugging

All TRAVEO™ T2G family MCU kits have a KitProg3 onboard programmer or debugger. It supports Cortex® Microcontroller Software Interface Standard-Debug Access Port (CMSIS-DAP). See the [KitProg3 user guide](#) for details.

The Eclipse IDE requires KitProg3 and uses the [OpenOCD](#) protocol for debugging TRAVEO™ T2G family MCU applications. Additionally, it supports GDB debugging using industry-standard probes like the [Segger J-Link](#). ModusToolbox™ includes the fw-loader command-line tool to update and switch the KitProg firmware from KitProg2 to KitProg3.

## 2.6 TRAVEO™ T2G family MCU development kits

### • Development kits

- TRAVEO™ T2G Body High Evaluation Kit ([KIT\\_T2G-B-H\\_EVK](#))
- TRAVEO™ T2G Body High Lite Kit ([KIT\\_T2G-B-H\\_LITE](#))
- TRAVEO™ T2G Body Entry Lite Kit ([KIT\\_T2G-B-E\\_LITE](#))
- TRAVEO™ T2G Cluster 2D 6M Lite Kit ([KIT\\_T2G\\_C-2D-6M\\_LITE](#))


For the complete list of kits for the TRAVEO™ T2G family MCU along with the shield modules, see the above microcontroller kits page.

## 3 Device features

### 3 Device features

TRAVEO™ T2G family MCU product lines have extensive feature sets. For more information, see [References](#).

#### 3.1 CYT4BF series



**Figure 5 CYT4BF MCU block diagram**

#### • CPU subsystem

- Two 350 MHz Arm® Cortex®-M7 CPUs and one 100 MHz Arm® Cortex®-M0+ CPU
- Inter-processor communication supported in hardware
- Three DMA controllers

#### • Integrated memories

- Up to 8384 KB of code flash with an additional 256 KB work flash
- Up to 1024 KB of SRAM selectable retention granularity

#### • Cryptography engine

- Supports Enhanced Secure Hardware Extension (eSHE) and Hardware Security Module (HSM)
- Secure boot and authentication
- AES: 128-bit blocks, 128-/192-/256-bit keys
- 3DES: 64-bit blocks, 64-bit key
- Vector unit supporting asymmetric key cryptography such as Rivest-Shamir-Adleman (RSA) and Elliptic Curve (ECC)
- SHA-1/2/3: SHA-512, SHA-256, SHA-160 with variable-length input data
- CRC: supports CCITT CRC-16 and IEEE-802.3 CRC-32
- True random number generator (TRNG) and pseudo random number generator (PRNG)
- Galois/Counter Mode (GCM)

#### • Safety for application

- Memory protection unit (MPU)

## 3 Device features

- Shared memory protection unit (SMPU)
- Peripheral protection unit (PPU)
- Watchdog timer (WDT)
- Multi-counter watchdog timer (MCWDT)
- Low-voltage detector (LVD)
- Brown-out detection (BOD)
- Over-voltage detection (OVD)
- Clock supervisor (CSV)
- Hardware error correction (SECDED ECC) on all safety-critical memories (SRAM, flash, TCM)
- **Low-power 2.7 V to 5.5 V operation**
  - Low-power active, Sleep, Low-power Sleep, DeepSleep, and Hibernate modes for fine-grained power management
  - Configurable options for robust BOD
- **Wakeup**
  - Up to two pins to wake from Hibernate mode
  - Up to 220 GPIO pins to wake from Sleep modes
  - Event Generator, SCB, Watchdog Timer, RTC alarms to wake from DeepSleep modes
- **Clocks**
  - Internal main oscillator (IMO)
  - Internal low-speed oscillator (ILO)
  - External crystal oscillator (ECO)
  - Watch crystal oscillator (WCO)
  - Phase-locked loop (PLL)
  - Frequency-locked loop (FLL)
- **Communication interfaces**
  - Up to 10 CAN FD channels
  - Up to 11 runtime-reconfigurable SCB channels, each configurable as I<sup>2</sup>C, SPI, or UART
  - Up to two 10/100/1000 Mbps Ethernet MAC interfaces conforming to IEEE-802.3az
- **External memory interface**
  - One SPI (single, dual, quad, or octal) or HYPERBUS™ interface
  - On-the-fly encryption and decryption
  - Execute in place (XIP) from external memory
- **SDHC interface**
  - One Secure Digital High Capacity (SDHC) interface supporting embedded MultiMediaCard (eMMC), Secure digital (SD), or SDIO (Secure digital input/output)
  - Data rates up to SD High-Speed 50 MHz, or eMMC 52 MHz DDR
- **Audio interface**
  - Three Inter-IC Sound (I2S) interfaces (based on the NXP I2S bus specification) for connecting digital audio devices
  - I2S, left-justified, or Time Division Multiplexed (TDM) audio formats
  - Independent transmit or receive operation, each in master or slave mode

## 3 Device features

### • Timers

- Up to 102 blocks of 16-bit and 16 blocks of 32-bit Timer/Counter Pulse-Width Modulator (TCPWM)
- Up to 16 Event Generation (EVTGEN) timers supporting cyclic wakeup from DeepSleep

### • Real-time clock (RTC)

- Year/Month/Date, Day-of-week, Hour:Minute:Second fields
- 12-hour and 24-hour formats
- Automatic leap-year correction

### • I/O

- Up to 240 programmable I/Os
- Three I/O types: GPIO\_STD/GPIO\_ENH/HSIO\_STD

### • Smart I/O

- Up to five smart I/O blocks, which can perform Boolean operations on signals going to and from I/Os
- Up to 36 I/Os (GPIO\_STD) supported

### • Programmable analog

- Three SAR A/D converters with up to 99 external channels (96 I/Os + 3 I/Os for motor control)
- Each ADC supports 12-bit resolution and sampling rates of up to 1 Msps
- Each ADC also supports six internal analog inputs
- Each ADC supports addressing of external multiplexers
- Each ADC has a sequencer supporting autonomous scanning of configured channels
- Synchronized sampling of all ADCs for motor-sense applications

## 3.2 CYT2BL series




Figure 6 CYT2BL MCU block diagram

### • CPU subsystem

- 160 MHz Arm® Cortex®-M4F CPU and one 100 MHz Arm® Cortex®-M0+ CPU

## 3 Device features

- Inter-processor communication supported in hardware
- Three DMA controllers
- **Integrated memories**
  - Up to 4160 KB of code flash with an additional 128 KB work flash
  - Up to 512 KB of SRAM selectable retention granularity
- **Cryptography engine**
  - Supports Enhanced Secure Hardware Extension (eSHE) and Hardware Security Module (HSM)
  - Secure boot and authentication
  - AES: 128-bit blocks, 128-/192-/256-bit keys
  - 3DES: 64-bit blocks, 64-bit key
  - Vector unit supporting asymmetric key cryptography such as Rivest-Shamir-Adleman (RSA) and Elliptic Curve (ECC)
  - SHA-1/2/3: SHA-512, SHA-256, SHA-160 with variable-length input data
  - CRC: supports CCITT CRC-16 and IEEE-802.3 CRC-32
  - True random number generator (TRNG) and pseudo random number generator (PRNG)
  - Galois/Counter Mode (GCM)
- **Safety for application**
  - Memory protection unit (MPU)
  - Shared memory protection unit (SMPU)
  - Peripheral protection unit (PPU)
  - Watchdog timer (WDT)
  - Multi-counter watchdog timer (MCWDT)
  - Low-voltage detector (LVD)
  - Brown-out detection (BOD)
  - Over-voltage detection (OVD)
  - Clock supervisor (CSV)
  - Hardware error correction (SECDED ECC) on all safety-critical memories (SRAM, flash)
- **Low-power 2.7 V to 5.5 V operation**
  - Low-power active, Sleep, Low-power Sleep, DeepSleep, and Hibernate modes for fine-grained power management
  - Configurable options for robust BOD
- **Wakeup**
  - Up to two pins to wake from Hibernate mode
  - Up to 152 GPIO pins to wake from Sleep modes
  - Event Generator, SCB, Watchdog Timer, RTC alarms to wake from DeepSleep modes
- **Clocks**
  - Internal main oscillator (IMO)
  - Internal low-speed oscillator (ILO)
  - External crystal oscillator (ECO)
  - Watch crystal oscillator (WCO)
  - Phase-locked loop (PLL)
  - Frequency-locked loop (FLL)

## 3 Device features

### • Communication interfaces

- Up to 8 CAN FD channels
- Up to 8 runtime-reconfigurable SCB channels, each configurable as I<sup>2</sup>C, SPI, or UART
- Up to 12 independent LIN channels
- Up to four CXPI channels with data rate up to 20 kbps

### • Timers

- Up to 75 blocks of 16-bit and 8 blocks of 32-bit Timer/Counter Pulse-Width Modulator (TCPWM)
- Up to 11 Event Generation (EVTGEN) timers supporting cyclic wakeup from DeepSleep

### • Real-time clock (RTC)

- Year/Month/Date, Day-of-week, Hour:Minute:Second fields
- 12-hour and 24-hour formats
- Automatic leap-year correction

### • I/O

- Up to 152 programmable I/Os
- Two I/O types: GPIO\_STD/GPIO\_ENH

### • Smart I/O

- Up to five smart I/O blocks, which can perform Boolean operations on signals going to and from I/Os
- Up to 36 I/Os (GPIO\_STD) supported

### • Programmable analog

- Three SAR A/D converters with up to 67 external channels (64 I/Os + 3 I/Os for motor control)
- Each ADC supports 12-bit resolution and sampling rates of up to 1 Msps
- Each ADC also supports six internal analog inputs
- Each ADC supports addressing of external multiplexers
- Each ADC has a sequencer supporting autonomous scanning of configured channels
- Synchronized sampling of all ADCs for motor-sense applications

## 3.3 CYT4DN series




Figure 7

CYT4DN MCU block diagram

## 3 Device features

### • Graphics subsystem

- Supports 2D and 2.5D (perspective warping, 3D effects) graphics rendering
- 40-bit for internal processing (RGBA 10-bit per color channel)
- 24-bit for interfaces (RGB 8-bit per color channel)
- 4096 KB of embedded video RAM memory (VRAM)
- Up to two video output interfaces supporting two displays
- One capture engine for video input processing for ITU 656 or parallel RGB/YUV or MIPI CSI-2 input
- Display warping on-the-fly for HUD applications
- Direct video feed through from capture to display interface with graphics overlay
- Composition engine for scene composition from display layers
- Display engine for video timing generation and display functions
- Drawing engine for acceleration of vector graphics rendering
- Command sequencer for setup and control of the rendering process
- Supports graphics rendering without frame buffers (on-the-fly to both displays)
- Dual-channel FPD-Link interface for up to Wide-HD resolution video output
- JPEG decoder

### • Sound subsystem

- Four time-division multiplexing (TDM) interfaces
- Two pulse-code modulation-pulse width modulation (PCM-PWM) interfaces
- Up to five sound generator (SG) interfaces
- Two PCM audio stream mixers with five input streams
- One audio digital-to-analog converter (DAC)

### • CPU subsystem

- Two 320 MHz Arm® Cortex®-M7 CPUs and one 100 MHz Arm® Cortex®-M0+ CPU
- Inter-processor communication supported in hardware
- Three DMA controllers

### • Integrated memories

- Up to 6336 KB of code flash with an additional 128 KB work flash
- Up to 640 KB of SRAM selectable retention granularity

### • Cryptography engine

- Supports Enhanced Secure Hardware Extension (eSHE) and Hardware Security Module (HSM)
- Secure boot and authentication
- AES: 128-bit blocks, 128-/192-/256-bit keys
- 3DES: 64-bit blocks, 64-bit key
- Vector unit supporting asymmetric key cryptography such as Rivest-Shamir-Adleman (RSA) and Elliptic Curve (ECC)
- SHA-1/2/3: SHA-512, SHA-256, SHA-160 with variable-length input data
- CRC: Supports CCITT CRC-16 and IEEE-802.3 CRC-32
- True random number generator (TRNG) and pseudo random number generator (PRNG)
- Galois/Counter Mode (GCM)

### • Safety for application

- Memory protection unit (MPU)
- Shared memory protection unit (SMPU)

## 3 Device features

- Peripheral protection unit (PPU)
- Watchdog timer (WDT)
- Multi-counter watchdog timer (MCWDT)
- Low-voltage detector (LVD)
- Brown-out detection (BOD)
- Over-voltage detection (OVD)
- Clock supervisor (CSV)
- Hardware error correction (SECDED ECC) on all safety-critical memories (SRAM, flash, TCM)
- **Low-power 2.7 V to 5.5 V operation**
  - Low-power active, Sleep, Low-power Sleep, DeepSleep, and Hibernate modes for fine-grained power management
  - Configurable options for robust BOD
- **Wakeup**
  - Up to 10 pins to wake from Hibernate mode
  - Up to 81 GPIO pins to wake from Sleep modes
  - Event generator, SCB, watchdog timer, and RTC alarms to wake from DeepSleep modes
- **Clocks**
  - Internal main oscillator (IMO)
  - Internal low-speed oscillator (ILO)
  - External crystal oscillator (ECO)
  - Watch crystal oscillator (WCO)
  - Phase-locked loop (PLL)
  - Frequency-locked loop (FLL)
  - Low-power external crystal oscillator (LPECO)
- **Communication interfaces**
  - Up to 4 CAN FD channels
  - Up to 12 runtime-reconfigurable SCB channels, each configurable as I<sup>2</sup>C, SPI, or UART
  - Up to 2 independent LIN channels
  - Up to 2 CXPI channels with data rate up to 20 kbps
- **Timers**
  - Up to 50 blocks of 16-bit and 32 blocks of 32-bit Timer/Counter Pulse-Width Modulator (TCPWM)
  - Up to 12 blocks of 16-bit counters optimized for motor-control operations (equivalent to 6 stepper motor-control (SMC) channels with ZPD and slew rate control capability)
  - Up to 16 Event Generation (EVTGEN) timers supporting cyclic wakeup from DeepSleep
- **Real-time clock (RTC)**
  - Year/Month/Date, Day-of-week, Hour:Minute:Second fields
  - 12-hour and 24-hour formats
  - Automatic leap-year correction
- **I/O**
  - Up to 168 programmable I/Os
  - Seven I/O types: GPIO\_STD/GPIO\_ENH/GPIO\_SMC/HSIO\_STD/HSIO\_STDLN/HSIO\_ENH/HSIO\_ENH\_PDIFF

## 3 Device features

- **Smart I/O**

- One smart I/O blocks, which can perform Boolean operations on signals going to and from I/Os
- Up to 8 I/Os (GPIO\_STD) supported

- **Programmable analog**

- One SAR A/D converter with up to 48 external channels
- Each ADC supports 12-bit resolution and sampling rates of up to 1 Msps
- Each ADC also supports six internal analog inputs
- Each ADC supports addressing of external multiplexers
- Each ADC has a sequencer supporting autonomous scanning of configured channels

## 4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...

### 4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ software

This section provides the following:

- Demonstrates how to build a simple design based on TRAVEO™ T2G family MCU and program it on to the development kit
- Provides detailed steps that make it easy to learn TRAVEO™ T2G family MCU design techniques and how to use the Eclipse IDE for ModusToolbox™ software

#### 4.1 Prerequisites

Before you get started, ensure that you have the appropriate development kit for your TRAVEO™ T2G family MCU product line, and have installed the required software. You also need Internet access to the GitHub repositories during project creation.

##### 4.1.1 Hardware

The design is developed for **TRAVEO™ T2G family evaluation kit**. However, you can build the projects for other development kits. See the [Using these instructions](#) section.

##### 4.1.2 Software

[ModusToolbox™](#) 3.5 or above

After installing the software, see the [ModusToolbox™ user guide](#) to get an overview of the software.

**Note:** For a list of known issues, see `mt_release_notes.pdf` included with the ModusToolbox™ installation. The default location of this file is `<user-home>/ModusToolbox/docs_3.5`.

#### 4.2 Using these instructions

These instructions are grouped into several sections. Each section is devoted to a phase of the application development workflow. The major sections are:

- [Part 1: Create a new application](#)
- [Part 2: View and modify the design](#)
- [Part 3: Write firmware](#)
- [Part 4: Build the application](#)
- [Part 5: Program the device](#)
- [Part 6: Test your design](#)

This design is developed for the **TRAVEO™ T2G family MCU Evaluation Kit**. You can use other supported kits to test this example by selecting the appropriate kit while creating the application.

#### 4.3 About the design

This design uses the TRAVEO™ T2G family MCU to execute two tasks: UART communication and LED control.

After device reset, this code example uses the UART to print a “Hello World” message to the serial port stream, and starts blinking the user LED on the kit. When you press the **Enter** key on the serial console, the blinking is paused or resumed.

---

## 4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...

### 4.4 Part 1: Create a new application

This section takes you on a step-by-step guided tour of the new application process. It uses the ‘Empty App’ starter application and guides you through the design development stages, and programming.


If you are familiar with developing projects with ModusToolbox™, you can use the ‘Hello World’ starter application directly. It is a complete design, with all the firmware written for the supported kits. You can walk through the instructions and observe how the steps are implemented in the code example.

If you start from scratch and follow all the instructions in this application note, you can use the code example as a reference while following the instructions.

Launch Eclipse IDE for ModusToolbox™ to get started. Note that Eclipse IDE for ModusToolbox™ software needs access to the internet to successfully clone the starter application onto your machine. The following shows the CYT4BF project as an example.

#### 1. Select a new workspace

At launch, Eclipse IDE for ModusToolbox™ presents a dialog to choose a directory for use as the workspace directory. The workspace directory is used to store workspace preferences and development artifacts. You can choose an existing empty directory by clicking the **Browse** button, as [Figure 8](#) shows. Alternatively, you can type in a directory name to be used as the workspace directory along with the complete path, and the Eclipse IDE will create the directory for you.




**Figure 8** Select a directory as the workspace

#### 2. Create a new ModusToolbox™ application

- Click **New Application** in the Start group of the Quick Panel
- Alternatively, you can choose **File > New > ModusToolbox™ Application**, as shown in [Figure 9](#)

The Eclipse IDE for ModusToolbox™ Application window appears.

## 4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...




**Figure 9** Create a new ModusToolbox™ application

### 3. Select a target TRAVEO™ T2G family MCU evaluation kit

ModusToolbox™ speeds up the development process by providing BSPs that set various workspace/project options for the specified development kit in the new application dialog.

- In the **Choose Board Support Package (BSP)** dialog, choose the **Kit Name** that you have. The steps that follow use **KIT\_T2G-B-H\_EVK**. See [Figure 10](#) for help with this step
- Click **Next**




**Figure 10** Choose the target hardware

- In the **Starter Application** dialog, select **Getting Started > Empty App** starter application, as [Figure 11](#) shows

## 4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...

- d. In the **Name** field, type in a name for the application, such as **Hello\_World**. You can choose to leave the default name if you prefer
- e. Click **Create** to create the application, as shown in [Figure 11](#). Wait for the Project Creator to automatically close once the project is successfully created



**Figure 11** Choose the starter application

You have successfully created a new ModusToolbox™ application for a TRAVEO™ T2G family MCU.

The BSP uses CYT4BFBCH as the default device that is mounted on the TRAVEO™ T2G family MCU evaluation kit. If you are using custom hardware based on a TRAVEO™ T2G family MCU, or a different TRAVEO™ T2G family MCU part number, see the “Creating your Own BSP” section in the [ModusToolbox™ user guide](#).

## 4.5 Part 2: View and modify the design


[Figure 12](#) shows the ModusToolbox™ Project Explorer interface displaying the structure of the application project.

TRAVEO™ T2G family CYT4BF MCU consist of three cores: one CM0+ core and two CM7 cores. This application note shows an example code for the firmware development using ModusToolbox™ software.

A project folder consists of various subfolders – each denoting a specific aspect of the project.

1. An application project contains a Makefile which is typically at the root folder. It has instructions on how to recreate the project. This file also contains the set of directives that the make tool uses to compile and link the application project. There can be more than one project in an application, and each dependent project usually resides within its own folder within the application folder and contains its own Makefile
2. The bsp folder contains all the configuration files that are generated by the device and peripheral configurators, and are included in the GeneratedSource folder of the BSP. These files are prefixed with `cycfg_`. These files contain the design configuration as defined by the BSP. You can view and modify the design configuration by clicking the Device Configurator link in the Quick Panel. However, note that if you upgrade the BSP library to a newer version, the manual edits done to the `design.x` files are lost. You can also create custom Device Configurator files for an application and override the ones provided by the BSP. See the “Modifying the BSP configuration for a single application” section in the [ModusToolbox™ user guide](#) for more details. The BSP folder also contains the linker scripts and the startup code for the TRAVEO™ T2G family MCU device used on the board
3. The *build* folder contains all the artifacts resulting from the make build of the project. The output files are organized by target BSPs

#### 4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...



**Figure 12 Project explorer view**


4. The *deps* folder contains .mtb files, which provide the location from which ModusToolbox™ software pulls the BSP/library that is directly referenced by the application. These files typically contain the GitHub location of the entire library. The .mtb files also contains a git commit hash or tag that tells which version of the library is to be fetched and a path as to where the library should be stored  
For example, *retarget-io.mtb* points to [https://github.com/infineon/retarget-io#latest-v1.X#\\$ASSET\\_REPO\\$\\$/retarget-io/latest-v1.X](https://github.com/infineon/retarget-io#latest-v1.X#$ASSET_REPO$$/retarget-io/latest-v1.X)
5. The *libs* folder also contains .mtb files; these point to libraries that are included indirectly as a dependency of a BSP or another library. For each indirect dependency, the Library Manager places an .mtb file in this folder. These files have been populated based on the targets available in the *deps* folder  
For example, using the BSP lib file, *TARGET\_KIT\_T2G-B-H\_EVK.mtb* populates the *libs* folder with the following .mtb files: [core-lib.mtb](#), [core-make.mtb](#), [mtb-hal-cat1.mtb](#), [mtb-pdl-cat1.mtb](#), [recipe-make-cat1c.mtb](#)

## 4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...

The *libs* folder contains the `mtb.mk` file, which stores the relative paths of all the libraries required by the application. The build system uses this file to find all the libraries required by the application

- By default, when creating a new application or adding a BSP/library to an existing application and specifying it as 'shared', all BSPs/libraries are placed in an `mtb_shared` directory adjacent to the application directories

The `mtb_shared` folder is shared between different applications that use the same versions of the BSP/library. Of interest are the configuration files that are in the `COMPONENT_BSP_x` folder. Click on the **Device Configurator** link in the **Quick Panel**. Figure 13 shows the resulting window called the **Device Configurator** window. You can also double-click open the other `design.x` files to open them in their respective configurators or click the corresponding links in the **Quick Panel**.



**Figure 13** *design.modus* overview

The **Device Configurator** window provides a **Resources Categories** pane. Here you can choose between different resources available in the device such as peripherals, pins, and clocks from the **List of Resources**.


You can choose how a resource behaves by choosing a **Personality** for the resource. For example, a **Serial Communication Block (SCB)** resource can have **EZI2C**, **I2C**, **SPI**, or **UART** personalities. The **Alias** is your name for the resource, which is used in firmware development. One or more aliases can be specified by using a comma to separate them (with no spaces).

The **Parameters** pane is where you enter the configuration parameters for each enabled resource and the selected personality. The **Code Preview** pane shows the configuration code generated per the configuration parameters selected. This code is populated in the `cycfg_` files in the `GeneratedSource` folder. Any errors, warnings, and information messages arising out of the configuration are displayed in the **Notices** pane.

The application project contains relevant files that help you create an application for the CM7 CPU (`main.c`).

At this point in the development process, we are ready to add the required middleware to the design. The only middleware required for the 'Hello World' application is the [retarget-io](#) library.

## 4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...



**Figure 14 Add the retarget-io middleware**

### 1. Add retarget-io middleware

In this step, you will add the [retarget-io](#) middleware to redirect standard input and output streams to the UART configured by the BSP. The initialization of the middleware will be done in the `main.c` code

- In the **Quick Panel**, click on the **Library Manager** link
- In the **Library Manager** window, click on **Add Library**
- Under **Peripheral**, select and enable [retarget-io](#), and click **OK**
- Click **Update**

The necessary files to use the [retarget-io](#) middleware are added in the `mtb_shared/retarget_io` folder; the `.mtb` file is also added to the `deps` folder (see [Figure 14](#))

### 2. Configuration of UART, timer peripherals, pins, and system clocks

The configuration of the debug UART peripheral, timer peripheral, pins, and system clocks can be done directly in the code using the function APIs provided by the BSP and HAL. See [Part 3: Write firmware](#).

## 4.6 Part 3: Write firmware

At this point in the development process, you have created an application, with the assistance of an application template and modified it to add the [retarget-io](#) middleware. In this part, you write the firmware that implements the design functionality.

If you are working from scratch using the empty TRAVEO™ T2G family starter application, you can copy the respective source code to the `main.c` of the application project from the code snippet provided in this section. If you are using the Hello World code example, all the required files are already in the application.

### 4.6.1 Firmware flow

We now examine the code in the `main.c` file of the application. [Figure 15](#) shows the firmware flowchart.

After reset, this code example initializes and configures the system clocks, pins, clock to peripheral connections, and other platform resources.

After reset, the clocks and system resources are initialized by the BSP initialization function. The [retarget-io](#) middleware is configured to use the debug UART, and the user LED is initialized. The debug UART prints a “Hello World!” message on the terminal emulator – the onboard KitProg3 acts the USB-to-UART bridge to create the

---


## 4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...

virtual COM port. A timer object is configured to generate an interrupt every 1000 milliseconds. At each timer interrupt, CPU toggles the LED state on the kit.

The firmware is designed to accept 'Enter' key as an input; on every press of the **Enter** key, the firmware starts or stops the blinking of the LED.

**Note:** *The application code uses BSP/HAL/middleware functions to execute the intended functionality.*

#### 4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...



**Figure 15** **Firmware flowchart**

This completes the summary of how the firmware works in the code example. See the source files for more information.

---

**4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...**


---

**Table 2 List of 'Hello World' configuration functions**

Function	Description
cybsp_init()	This BSP function sets up the HAL hardware manager and initializes all the system resources of the device including but not limited to the system clocks and power regulators
cy_retarget_io_init()	This function from the retarget-io middleware uses the aliases set up for debug UART pins to configure the debug UART with a standard baud rate of 115200 and redirects the input/output stream to the debug UART
cyhal_gpio_init()	This function from the GPIO HAL initializes the physical pin to drive the LED. The LED used is derived from the BSP definition
timer_init()	This function wraps a set of timer HAL function calls to instantiate and configure a timer. It also sets up a callback for the timer interrupt

Copy the following code snippet to the `main.c` of your application project.

---

**4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...****Example code for the 'Hello World' application**

```
#include "cyhal.h"
#include "cybsp.h"
#include "cy_retarget_io.h"

//****************************************************************************
* Macros
//****************************************************************************

/* LED blink timer clock value in Hz */
#define LED_BLINK_TIMER_CLOCK_HZ          (10000)

/* LED blink timer period value */
#define LED_BLINK_TIMER_PERIOD           (9999)

//****************************************************************************
* Function Prototypes
//****************************************************************************

void timer_init(void);
static void isr_timer(void *callback_arg, cyhal_timer_event_t event);

//****************************************************************************
* Global Variables
//****************************************************************************

bool timer_interrupt_flag = false;
bool led_blink_active_flag = true;

/* Variable for storing character read from terminal */
uint8_t uart_read_value;

/* Timer object used for blinking the LED */
cyhal_timer_t led_blink_timer;

//****************************************************************************
* Function Name: main
//****************************************************************************

* Summary:
* This is the main function. It sets up a timer to trigger a
* periodic interrupt. The main while loop checks for the status of a flag set
* by the interrupt and toggles an LED at 1Hz to create an LED blinky. The
* while loop also checks whether the 'Enter' key was pressed and
* stops/restarts LED blinking.
*
* Parameters:
* none
*
* Return:
* int
```

---

**4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...**

---

```
* ****
int main(void)
{
    cy_rslt_t result;

    /* Initialize the device and board peripherals */
    result = cybsp_init();

    /* Board init failed. Stop program execution */
    if (result != CY_RSLT_SUCCESS)
    {
        CY_ASSERT(0);
    }

    /* Enable global interrupts */
    __enable_irq();

    /* Initialize retarget-io to use the debug UART port */
    result = cy_retarget_io_init(CYBSP_DEBUG_UART_TX, CYBSP_DEBUG_UART_RX,
                                CY_RETARGET_IO_BAUDRATE);

    /* retarget-io init failed. Stop program execution */
    if (result != CY_RSLT_SUCCESS)
    {
        CY_ASSERT(0);
    }

    /* Initialize the User LED */
    result = cyhal_gpio_init(CYBSP_USER_LED, CYHAL_GPIO_DIR_OUTPUT,
                            CYHAL_GPIO_DRIVE_STRONG, CYBSP_LED_STATE_OFF);

    /* GPIO init failed. Stop program execution */
    if (result != CY_RSLT_SUCCESS)
    {
        CY_ASSERT(0);
    }

    /* \x1b[2J\x1b[;H - ANSI ESC sequence for clear screen */
    printf("\x1b[2J\x1b[;H");

    printf("***** "
          "HAL: Hello World! Example "
          "***** \r\n\r\n");

    printf("Hello World!!!\r\n\r\n");

    printf("For more projects, "
          "visit our code examples repositories:\r\n\r\n");

    printf("https://github.com/Infineon/"
          "Code-Examples-for-ModusToolbox-Software\r\n\r\n");
}
```

---

#### 4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...

```

/* Initialize timer to toggle the LED */
timer_init();

printf("Press 'Enter' key to pause or "
      "resume blinking the user LED \r\n\r\n");

for (;;)
{
    /* Check if 'Enter' key was pressed */
    if (cyhal_uart_getc(&cy_retarget_io_uart_obj, &uart_read_value, 1)
        == CY_RSLT_SUCCESS)
    {
        if (uart_read_value == '\r')
        {
            /* Pause LED blinking by stopping the timer */
            if (led_blink_active_flag)
            {
                cyhal_timer_stop(&led_blink_timer);

                printf("LED blinking paused \r\n");
            }
            else /* Resume LED blinking by starting the timer */
            {
                cyhal_timer_start(&led_blink_timer);

                printf("LED blinking resumed\r\n");
            }
        }

        /* Move cursor to previous line */
        printf("\x1b[1F");

        led_blink_active_flag ^= 1;
    }
}

/* Check if timer elapsed (interrupt fired) and toggle the LED */
if (timer_interrupt_flag)
{
    /* Clear the flag */
    timer_interrupt_flag = false;

    /* Invert the USER LED state */
    cyhal_gpio_toggle(CYBSP_USER_LED);
}
}

*****  

* Function Name: timer_init  

*****  

* Summary:  

* This function creates and configures a Timer object. The timer ticks

```

---

#### 4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...

```

* continuously and produces a periodic interrupt on every terminal count
* event. The period is defined by the 'period' and 'compare_value' of the
* timer configuration structure 'led_blink_timer_cfg'. Without any changes,
* this application is designed to produce an interrupt every 1 second.
*
* Parameters:
* none
*
*****/
void timer_init(void)
{
    cy_rslt_t result;

    const cyhal_timer_cfg_t led_blink_timer_cfg =
    {
        .compare_value = 0,                      /* Timer compare value, not used */
        .period = LED_BLINK_TIMER_PERIOD,        /* Defines the timer period */
        .direction = CYHAL_TIMER_DIR_UP,         /* Timer counts up */
        .is_compare = false,                     /* Don't use compare mode */
        .is_continuous = true,                  /* Run timer indefinitely */
        .value = 0                             /* Initial value of counter */
    };

    /* Initialize the timer object. Does not use input pin ('pin' is NC) and
     * does not use a pre-configured clock source ('clk' is NULL). */
    result = cyhal_timer_init(&led_blink_timer, NC, NULL);

    /* timer init failed. Stop program execution */
    if (result != CY_RSLT_SUCCESS)
    {
        CY_ASSERT(0);
    }

    /* Configure timer period and operation mode such as count direction,
     * duration */
    cyhal_timer_configure(&led_blink_timer, &led_blink_timer_cfg);

    /* Set the frequency of timer's clock source */
    cyhal_timer_set_frequency(&led_blink_timer, LED_BLINK_TIMER_CLOCK_HZ);

    /* Assign the ISR to execute on timer interrupt */
    cyhal_timer_register_callback(&led_blink_timer, isr_timer, NULL);

    /* Set the event on which timer interrupt occurs and enable it */
    cyhal_timer_enable_event(&led_blink_timer, CYHAL_TIMER_IRQ_TERMINAL_COUNT,
                           7, true);

    /* Start the timer with the configured settings */
    cyhal_timer_start(&led_blink_timer);
}

*****

```

## 4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...

```

* Function Name: isr_timer
*****
* Summary:
* This is the interrupt handler function for the timer interrupt.
*
* Parameters:
*   callback_arg    Arguments passed to the interrupt callback
*   event           Timer/counter interrupt triggers
*
*****
static void isr_timer(void *callback_arg, cyhal_timer_event_t event)
{
    (void) callback_arg;
    (void) event;


    /* Set the interrupt flag and process it from the main while(1) loop */
    timer_interrupt_flag = true;
}

```

## 4.7 Part 4: Build the application

This section shows how to build the application.

1. **Build the application**
2. Select the application project in the Project Explorer window and click on the **Build <name> Application** shortcut under the **<name>** group in the Quick Panel. It selects the **Debug** build configuration and compiles/links all projects that constitute the application
3. The **Console** view lists the results of the build operation (see [Figure 16](#))



**Figure 16** Build the application

## 4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...

If you encounter errors, revisit prior steps to ensure that you accomplished all the required tasks.

**Note:** You can also use the command-line interface (CLI) to build the application. See the “Using the command-line” section in the [ModusToolbox™ user guide](#). This document is located in the `/ide_<version>/docs/` folder in the ModusToolbox™ installation.

### 4.8 Part 5: Program the device

This section shows how to program the TRAVEO™ T2G family MCU device.


ModusToolbox™ software uses the OpenOCD protocol to program and debug applications on TRAVEO™ T2G family MCU devices. For ModusToolbox™ software to identify the device on the kit, the kit must be running KitProg3. See [Programming/debugging](#) for details.

If you are using a development kit with a built-in programmer, connect the board to your computer using the USB cable.

If you are developing on your own hardware, you may need a hardware programmer/debugger; for example, a [CY8CKIT-005 MiniProg4](#).


1. **Program the application**
2. Connect to the board and perform the following step
3. Select the application project and click on the **<application name> Program (KitProg3\_MiniProg4)** shortcut under the **Launches** group in the Quick Panel, as [Figure 17](#) shows. The IDE will select and run the appropriate run configuration. Note that this step will also perform a build if any files have been modified since the last build

#### 4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...



**Figure 17** +Programming an application to a deviceConsole – programming results

The **Console** view lists the results of the programming operation, as [Figure 18](#) shows.



```

Console Problems Progress Memory Terminal
<terminated> Hello_World Program (KitProg3_MiniProg4) [GDB OpenOCD Debugging] openocd.exe (Terminated 2023/03/10 11:07:59)

[100%] [#####] [ Erasing      ]
[100%] [#####] [ Programming ]
Info : Padding image section 1 at 0x100828c0 with 320 bytes (bank write end alignment)
Warn : Adding extra erase range, 0x10082a00 .. 0x10087fff
[100%] [#####] [ Erasing      ]
[100%] [#####] [ Programming ]
Info : Enabling the CM7_0 CPU...
Info : Enabling the CM7_1 CPU...
Info : SWD PIDR 0x6ba02477
Info : kitprog3: acquiring the device (mode: reset)...
catic.cpu.cm0 halted due to debug-request, current mode: Thread

```

**Figure 18** Console – programming results

## 4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...

### 4.9 Part 6: Test your design

This application note uses Tera Term as the UART terminal emulator to view the results. You can use any terminal of your choice to view the output. Follow these steps to observe the output of your design:

#### 1. Select the serial port

Launch Tera Term and select the USB-UART COM port as shown in [Figure 19](#). Note that your COM port number may be different





Figure 19

Selecting the KitProg3 COM port in Tera Term

#### 2. Set the baud rate

Set the baud rate to 115200 under [Setup > Serial port](#) as shown in [Figure 20](#)


#### 4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...



**Figure 20** Configuring the baud rate in Tera Term

#### 3. Reset the device

Press the reset switch (**SW1**) on the kit. A message appears on the terminal as shown in [Figure 21](#). The user LED on the kit starts blinking




**Figure 21** Printed UART message

#### 4. Pause/resume LED blinking functionality

Press the Enter key to pause/resume blinking the LED. When the LED blinking is paused, a corresponding message is displayed on the terminal as shown in [Figure 22](#)

## 4 My first TRAVEO™ T2G family MCU design using Eclipse IDE for ModusToolbox™ soft...



**Figure 22** Printed UART message

---

## 5 How to use the Qt Design Studio

### 5 How to use the Qt Design Studio

KIT\_T2G-C-2D-6M\_LITE kit has a demonstration code example ModusToolbox™ and Qt Design Studio working together to output image. To use these graphics code examples, some configuration is required in advance.

Follow the instructions on how to set up Qt Design Studio and use it with the KIT\_T2G-C-2D-6M\_LITE kit. For more details, see the [Steps to use the Qt Design Studio using the ModusToolbox™](#).

1. To procure the license, go to [Qt + Infineon](#)
2. To download Qt software, go to [Login](#)
3. Install Qt Design Studio
4. To install, go to [TRAVEO™ T2G Virtual Display Tool](#)
5. Configure the Windows environment variable on your PC

**Note:** *The above procedure should be performed before creating the graphics.*

---

**6 Summary**

## **6 Summary**

This application note explores the TRAVEO™ T2G family MCU device architecture and the associated development tools. The TRAVEO™ T2G family MCU is a truly programmable embedded system-on-chip with configurable analog and digital peripheral functions, memory, and a triple-CPU system on a single chip. The integrated features and low-power modes make TRAVEO™ T2G family MCU an ideal choice for BCM, gateway, instrument cluster, and other automotive body control applications.

---

## References

### References

#### TRAVEO™ T2G webpage

- [1] [32-bit TRAVEO™ T2G Arm® Cortex® microcontroller](#)

#### Application notes

- [2] [AN220270 - Hardware design guide for the TRAVEO™ T2G family](#)
- [3] [AN235303 - Clock configuration setup for TRAVEO™ T2G family MCUs in ModusToolbox™](#)

#### Device datasheets

- [4] [CYT2BL datasheet 32-bit Arm® Cortex®-M4F microcontroller TRAVEO™ T2G family](#)
- [5] [CYT4BF datasheet 32-bit Arm® Cortex®-M7 microcontroller TRAVEO™ T2G family](#)
- [6] [CYT4DN datasheet 32-bit Arm® Cortex®-M7 microcontroller TRAVEO™ T2G family](#)

#### CYT2BL architecture/registers reference manual for body controller entry family

- [7] [TRAVEO™ T2G automotive body controller entry family architecture reference manual](#)
- [8] [TRAVEO™ T2G automotive body controller entry registers reference manual](#)

#### CYT4BF architecture/registers reference manual for body controller high family

- [9] [TRAVEO™ T2G automotive body controller high family architecture reference manual](#)
- [10] [TRAVEO™ T2G automotive body controller high registers reference manual](#)

#### CYT4DN architecture/registers reference manual for body controller high family

- [11] [TRAVEO™ T2G automotive cluster 2D architecture reference manual](#)
- [12] [TRAVEO™ T2G automotive cluster 2D registers reference manual](#)

#### Customer training workshop (CTW)

- [13] [Steps to use the Qt Design Studio using the ModusToolbox™](#)
- [14] For more TRAVEO™ T2G documents, contact [Technical Support](#).

---

## Glossary

### Glossary

This section lists the most commonly used terms that you might encounter while working with TRAVEO™ T2G family of devices.

- **Board support package (BSP):** A BSP is the layer of firmware containing board-specific drivers and other functions. The board support package is a set of libraries that provide firmware APIs to initialize the board and provide access to board level peripherals
- **Hardware Abstraction Layer (HAL):** The HAL wraps the lower-level drivers and provides a high-level interface to the MCU. The interface is abstracted to work on any MCU
- **KitProg:** Onboard programmer/debugger with USB-I<sup>2</sup>C and USB-UART bridge functionality. KitProg is integrated onto most TRAVEO™ T2G development kits
- **MiniProg3/MiniProg4:** Programming hardware for development that is used to program TRAVEO™ T2G devices on your custom board or TRAVEO™ T2G development kits that do not support a built-in programmer
- **Personality:** Expresses the configurability of a resource for a functionality. For example, the SCB resource can be configured to be an UART, SPI, or I<sup>2</sup>C personalities
- **Middleware:** Middleware is a set of firmware modules that provide specific capabilities to an application. Some middleware may provide network protocols (e.g., MQTT), and some may provide high-level software interfaces to device features (e.g., USB, audio)
- **Peripheral Driver Library (PDL):** Simplifies software development for the TRAVEO™ T2G MCU architecture. The PDL reduces the need to understand register usage and bit structures, thus easing software development for the extensive set of peripherals available

---

**Revision history****Revision history**

Document revision	Date	Description of changes
**	2022-09-14	Initial release
*A	2022-11-14	Added 4.7.1 section
*B	2023-04-06	Added KIT_T2G-B-H_LITE Added Enable support for additional code example section
*C	2023-10-16	Added CYT2BL series related information in all instances across the document Added KIT_T2G-B-E_LITE
*D	2023-11-27	Web release
*E	2024-11-25	Added CYT4DN series related information in all instances across the document Added KIT_T2G_C_2D-6M_LITE
*F	2025-09-01	Updated how to set Manifest-DB and supported version for ModusToolbox™ from 3.2 to 3.5 Added <a href="#">How to use the Qt Design Studio</a>

## Trademarks

All referenced product or service names and trademarks are the property of their respective owners.

**Edition 2025-09-01**

**Published by**

**Infineon Technologies AG  
81726 Munich, Germany**

**© 2025 Infineon Technologies AG**

**All Rights Reserved.**

**Do you have a question about any aspect of this document?**

**Email: [erratum@infineon.com](mailto:erratum@infineon.com)**

**Document reference  
IFX-tzk1755516026189**

## Important notice

The information contained in this application note is given as a hint for the implementation of the product only and shall in no event be regarded as a description or warranty of a certain functionality, condition or quality of the product. Before implementation of the product, the recipient of this application note must verify any function and other technical information given herein in the real application. Infineon Technologies hereby disclaims any and all warranties and liabilities of any kind (including without limitation warranties of non-infringement of intellectual property rights of any third party) with respect to any and all information given in this application note.

The data contained in this document is exclusively intended for technically trained staff. It is the responsibility of customer's technical departments to evaluate the suitability of the product for the intended application and the completeness of the product information given in this document with respect to such application.

## Warnings

Due to technical requirements products may contain dangerous substances. For information on the types in question please contact your nearest Infineon Technologies office.

Except as otherwise explicitly approved by Infineon Technologies in a written document signed by authorized representatives of Infineon Technologies, Infineon Technologies' products may not be used in any applications where a failure of the product or any consequences of the use thereof can reasonably be expected to result in personal injury.