

Using a Magnetic 3D Sensor in a Gear Stick Application

3D Magnetic Sensors

Application Note

Rev. 1.0 2015-10-15

Sense & Control



Table of Contents

1	Abstract	3
2	Introduction	3
3	How to use a 3D Sensor?	4
4	Accuracy	7
5	Sensor Functionality	9
5.1	Sensing part	9
6	Appendix: Calculation of Spherical Coordinates	10
6.1	Generals in 3D Movements	10
6.2	Conversion from X,Y and Z Coordinates to Spherical Coordinates	11
7	Revision History	13

Abstract

1 Abstract

Target of this application note is to show how a magnetic 3D sensors can be used in a gear stick application.

Note: The following information is given as a hint for the implementation of our devices only and shall not be regarded as a description or warranty of a certain functionality, condition or quality of the device.

2 Introduction

A magnetic 3D sensor is well suitable for a detection of the position of the gear stick. The „State-of-the-art“ solution with up to 6 single hall switches can be replaced by one 3D sensor. The TLE493D-W1B6 has the same package dimensions as a hall switch and leads to cost and space savings.




Figure 1 Principle of a position detection in a gear stick

The idea is that dedicated positions of a lever needs to be detected. For automated transmission normally following positions are required:

- P - Park
- R - Reverse
- N - Neutral
- D - Drive
- Optional „+“ and „-“ for “manual” gear shift

Up to now the detection is realized by a hall switch matrix on a PCB. Up to 6 simple Hall switches are needed to detect the gear position. Due to safety reasons often two switch arrays are necessary.

How to use a 3D Sensor?

3 How to use a 3D Sensor?

For a robust design with a magnetic 3D sensor following parameters are used:

- Arc range 0° .. 30° (each 6° one Hall switch)
- Magnet Parameters
 - Material = NdFeB
 - Magnet shape= rectangular block (7mm x 5mm x 3 mm)
 - Airgap between sensor and magnet = 4mm
 - Magnetization direction = axial
 - Remanence $B_r = 1T$
 - Lever = 1.3cm

With the above used parameters a linear characteristic between magnetic calculated angel theta Θ and mechanical movement of the gear stick is obtained. The spherical angle theta is calculated of the X, Y and Z components of the sensor, see [Chapter 6](#). With those a clear position detection can be obtained.

The absolute value of the field is always in the range of around 30mT and is therefore considered as a sufficient signal.




Figure 2 Mechanical Angle versus Theta

The linear range of theta depends on the length of the lever. The smaller the lever the bigger is the linear range ([Figure 3](#)).

How to use a 3D Sensor?




Figure 3 Linear Range versus Lever Length

Further simulations for a cheaper magnet have been evaluated. The magnet material NdFeB has been replaced by a ferrite. All other parameters have been kept the same.




Figure 4 Influence of Magnetic Material; Mechanical Angle versus Theta

How to use a 3D Sensor?

As you can see in [Figure 4](#) the linear range has not changed, but the strength of the magnetic field has decreased. If this still fits the application needs than you are fine with a ferrite.

But, you may come up with some concerns that the robustness is not sufficient anymore due to the smaller field. This decline of field can be compensated by a reduction of the airgap from 4mm to 2mm. This is shown in [Figure 5](#).




Figure 5 Reduction of Airgap with Ferrite

All those simulations give a good indication for a proper magnetic design as position detection in a gear stick application.

This simulation will be verified in the future.

Accuracy

4 Accuracy

The accuracy is evaluated for below mentioned parameters:

Geometry:

- Lever: 1.3 cm
- Airgap: 4 mm




Figure 6 Magnet Lever

Magnet:

- Size: 7x5x3 mm
- Remanence: 1000 mT
- Magnetization: axial




Figure 7 Linear Fit of the Mech. Angle

Accuracy




Figure 8 Error of the Linear Fit Compared to the Original Value

Result:

The error is below 1° for an ideal magnetic circuit. Sensor errors may lead to additional errors.

Sensor Functionality

5 Sensor Functionality




Figure 9 Block Diagram

The IC consists of three main function units containing following building blocks:

- The power mode control system, containing a low-power oscillator, basic biasing, accurate reset, undervoltage detection and a fast oscillator.
- The sensing part, containing the HALL biasing, HALL probes with multiplexers and successive tracking ADC. Furthermore a temperature sensor is implemented.
- The I²C interface, containing the register file and I/O pads

5.1 Sensing part

Performs the measurements of the magnetic field in X, Y and Z direction. Each X, Y and Z-HALL probe is connected sequentially to a multiplexer, which is then connected to an Analog to Digital Converter (ADC). Optional, the temperature is determined as well after the three HALL channels. The current consumption decreases by -25% when temperature measurement is deactivated.

6 Appendix: Calculation of Spherical Coordinates

6.1 Generals in 3D Movements




Figure 10 Spherical Movements

- In the Zero position (=Z-axis) $\text{Phi}=0^\circ$ & $\text{Theta}=0^\circ$
- A pure forward or backward movement along the x-axis will lead to an increasing absolute Theta value. Phi will stay at 0°
- A pure left or right movement along the y-axis will lead to an increasing absolute Theta value. Phi will jump from 0° to 90°
- All other movements/positions can be described as a combination of Theta & Phi

Appendix: Calculation of Spherical Coordinates

6.2 Conversion from X,Y and Z Coordinates to Spherical Coordinates

The readouts have been translated from X, Y & Z coordinates to spherical coordinates.




Figure 11 Movements in spherical coordinates

Following formulas have been used for this translation:

Mag. flux density vectors given by mechanics

$$x = r \cdot \sin \theta \cdot \cos \varphi$$

$$y = r \cdot \sin \theta \cdot \sin \varphi$$

$$z = r \cdot \cos \theta$$

- r, x, y, z corresponds to Br, Bx, By, Bz
- with Br = vector length of magnetic field
- Bx = field component in x-direction
- By = field component in y-direction
- Bz = field component in z-direction

Sensor measures Bx, By, Bz (with some errors)

µC calculates:

$$r = \sqrt{x^2 + y^2 + z^2}$$

theta

$$\theta = \arccos \frac{z}{\sqrt{x^2 + y^2 + z^2}} = \arccos \frac{z}{r} = \frac{\pi}{2} - \arctan \frac{z}{\sqrt{x^2 + y^2}}$$

Appendix: Calculation of Spherical Coordinates

phi

$$\varphi = \text{atan2}(y,x) = \begin{cases} \arctan\left(\frac{y}{x}\right) & , \text{ if } x > 0 \\ \text{sgn}(y) \frac{\pi}{2} & , \text{ if } x = 0 \\ \arctan\left(\frac{y}{x}\right) + \pi & , \text{ if } x < 0 \wedge y \geq 0 \\ \arctan\left(\frac{y}{x}\right) - \pi & , \text{ if } x < 0 \wedge y < 0 \end{cases}$$



Revision History

7 Revision History

Revision	Date	Changes
Rev. 1.0	2015-10-15	

Trademarks of Infineon Technologies AG

AURIX™, C166™, CanPAK™, CIPOS™, CoolGaN™, CoolMOS™, CoolSET™, CoolSiC™, CORECONTROL™, CROSSAVE™, DAVE™, DI-POL™, DrBLADE™, EasyPIM™, EconoBRIDGE™, EconoDUAL™, EconoPACK™, EconoPIM™, EiceDRIVER™, eupec™, FCOS™, HITFET™, HybridPACK™, Infineon™, ISOFACE™, IsoPACK™, i-Wafer™, MIPAQ™, ModSTACK™, my-d™, NovalithIC™, OmniTune™, OPTIGA™, OptiMOS™, ORIGA™, POWERCODE™, PRIMARION™, PrimePACK™, PrimeSTACK™, PROFET™, PRO-SIL™, RASIC™, REAL3™, ReverSave™, SatRIC™, SIEGET™, SIPMOST™, SmartLEWIS™, SOLID FLASH™, SPOC™, TEMPFET™, thinQ!™, TRENCHSTOP™, TriCore™.

Other Trademarks

Advance Design System™ (ADS) of Agilent Technologies, AMBA™, ARM™, MULTI-ICE™, KEIL™, PRIMECELL™, REALVIEW™, THUMB™, µVision™ of ARM Limited, UK. ANSI™ of American National Standards Institute. AUTOSAR™ of AUTOSAR development partnership. Bluetooth™ of Bluetooth SIG Inc. CAT-iq™ of DECT Forum. CIPURSE™ of OSPT Alliance. COLOSSUS™, FirstGPS™ of Trimble Navigation Ltd. EMV™ of EMVCo, LLC (Visa Holdings Inc.). EPCOS™ of Epcos AG. FLEXGO™ of Microsoft Corporation. HYPERTERMINAL™ of Hilgraeve Incorporated. MCS™ of Intel Corp. IEC™ of Commission Electrotechnique Internationale. IrDA™ of Infrared Data Association Corporation. ISO™ of INTERNATIONAL ORGANIZATION FOR STANDARDIZATION. MATLAB™ of MathWorks, Inc. MAXIM™ of Maxim Integrated Products, Inc. MICROTEC™, NUCLEUS™ of Mentor Graphics Corporation. MIPI™ of MIPI Alliance, Inc. MIPS™ of MIPS Technologies, Inc., USA. muRata™ of MURATA MANUFACTURING CO., MICROWAVE OFFICE™ (MWO) of Applied Wave Research Inc., OmniVision™ of OmniVision Technologies, Inc. Openwave™ of Openwave Systems Inc. RED HAT™ of Red Hat, Inc. RFMD™ of RF Micro Devices, Inc. SIRIUS™ of Sirius Satellite Radio Inc. SOLARIS™ of Sun Microsystems, Inc. SPANSION™ of Spansion LLC Ltd. Symbian™ of Symbian Software Limited. TAIYO YUDEN™ of Taiyo Yuden Co. TEAKLITE™ of CEVA, Inc. TEKTRONIX™ of Tektronix Inc. TOKO™ of TOKO KABUSHIKI KAISHA TA. UNIX™ of X/Open Company Limited. VERILOG™, PALLADIUM™ of Cadence Design Systems, Inc. VLYNQ™ of Texas Instruments Incorporated. VXWORKS™, WIND RIVER™ of WIND RIVER SYSTEMS, INC. ZETEX™ of Diodes Zetex Limited.

Trademarks Update 2014-11-12

www.infineon.com

Edition 2015-10-15

Published by

Infineon Technologies AG

81726 Munich, Germany

© 2014 Infineon Technologies AG.

All Rights Reserved.

Do you have a question about any aspect of this document?

Email: erratum@infineon.com

Document reference

Doc_Number

Legal Disclaimer

THE INFORMATION GIVEN IN THIS APPLICATION NOTE (INCLUDING BUT NOT LIMITED TO CONTENTS OF REFERENCED WEBSITES) IS GIVEN AS A HINT FOR THE IMPLEMENTATION OF THE INFINEON TECHNOLOGIES COMPONENT ONLY AND SHALL NOT BE REGARDED AS ANY DESCRIPTION OR WARRANTY OF A CERTAIN FUNCTIONALITY, CONDITION OR QUALITY OF THE INFINEON TECHNOLOGIES COMPONENT. THE RECIPIENT OF THIS APPLICATION NOTE MUST VERIFY ANY FUNCTION DESCRIBED HEREIN IN THE REAL APPLICATION. INFINEON TECHNOLOGIES HEREBY DISCLAIMS ANY AND ALL WARRANTIES AND LIABILITIES OF ANY KIND (INCLUDING WITHOUT LIMITATION WARRANTIES OF NON-INFRINGEMENT OF INTELLECTUAL PROPERTY RIGHTS OF ANY THIRD PARTY) WITH RESPECT TO ANY AND ALL INFORMATION GIVEN IN THIS APPLICATION NOTE.

Information

For further information on technology, delivery terms and conditions and prices, please contact the nearest Infineon Technologies Office (www.infineon.com).

Warnings

Due to technical requirements, components may contain dangerous substances. For information on the types in question, please contact the nearest Infineon Technologies Office. Infineon Technologies components may be used in life-support devices or systems only with the express written approval of Infineon Technologies, if a failure of such components can reasonably be expected to cause the failure of that life-support device or system or to affect the safety or effectiveness of that device or system. Life support devices or systems are intended to be implanted in the human body or to support and/or maintain and sustain and/or protect human life. If they fail, it is reasonable to assume that the health of the user or other persons may be endangered.