

Please note that Cypress is an Infineon Technologies Company.

The document following this cover page is marked as “Cypress” document as this is the company that originally developed the product. Please note that Infineon will continue to offer the product to new and existing customers as part of the Infineon product portfolio.

Continuity of document content

The fact that Infineon offers the following product as part of the Infineon product portfolio does not lead to any changes to this document. Future revisions will occur when appropriate, and any changes will be set out on the document history page.

Continuity of ordering part numbers

Infineon continues to support existing part numbers. Please continue to use the ordering part numbers listed in the datasheet for ordering.

This code example uses the base timer in PWM mode to drive the green LED.

Overview

This example uses the base timer (BT) in PWM mode. The timer runs continuously. When the timer reaches zero, the underflow interrupt modifies the duty cycle. The output pin for the BT_PWM is connected to the green LED. The LED brightness varies with the PWM duty cycle.

Requirements

Tool: PSoC Creator 4.0


Programming Language: C (GCC 4.9.3)

Associated Parts: All S6E1C parts

Related Hardware: [FM0-64L-S6E1C3](#)

Design

The schematic includes the PDL_BT Component, configured as a PWM. The **bPwmUnderflowIrq** field is set to true. The **ConnectTIOA** field is also set to true. The design sets that output pin (PWM:TIOA) to drive the green LED.



The firmware performs following functions:

1. Sets the pin function for the PWM output pin.
2. Initializes the PWM peripheral
3. Sets the count value for the down counter
4. Sets the initial PWM duty cycle
5. Starts the peripheral and triggers the PWM
6. In the underflow interrupt handler, modify the duty cycle

Design Considerations

PDL Installation

The project assumes that you have installed the PDL in the location specified in the **Project Management** panel of the **Tools > Options** dialog. If that location is incorrect, you will see the build error "The given PDL path is invalid. Unable to find required PDSC file." To correct this problem in a newly-created project, open the **Project > Properties** dialog and enter the correct path to the PDL. To avoid the problem in projects you create in the future, make sure you put the correct path in the **Tools > Options** dialog.

Hardware Setup

As configured, the PWM Component uses one output pin. [Table 1](#) lists the pin connections required to use this code example on supported FM0+ kits.

Table 1. List of Pins

| Pin | FM0-64L-S6E1C3 |
|----------|----------------|
| PWM:TIOA | P3E |

Components

[Table 2](#) lists the PSoC Creator Components used in this example, as well as the hardware resources used by each.

Table 2. List of PSoC Creator Components

| Component | Version | Hardware Resources |
|-----------------|---------|------------------------|
| PDL_BT as a PWM | 1.0 | BT block, one GPIO pin |

Parameter Settings

The PWM Component uses default parameter settings, with these exceptions.

Table 3: Component Settings

| Tab | Setting | Value |
|------------|------------------|-------|
| Basic | ConnectTIOA | True |
| Interrupts | bPwmUnderflowIrq | True |
| | bTouchNvic | True |

Operation

Program the kit, then click the Resume Execution button. The green LED starts out bright, fades, and then reverts to bright as the PWM duty cycle changes.

Related Documents

[Table 4](#) lists relevant application notes, code examples, knowledge base articles, device datasheets, and Component datasheets.

Table 4. Related Documents

| PSoC Creator Component Datasheets | |
|-------------------------------------|--|
| PDL_BT | Supports PWM, PPG, PWC, and Reload timers, in either continuous or one-shot mode |
| Device Documentation | |
| S6E1C | FM0+ S6E1C-Series Ultra Low Power ARM® Cortex®-M0+ Microcontroller (MCU) Family |
| Development Kit (DVK) Documentation | |
| FM0-64L-S6E1C3 | ARM® Cortex®-M0+ MCU Starter Kit with USB and Digital Audio Interface |

Document History

Document Title: CE215900 - FM0+ Base Timer PWM

Document Number: 002-15900

| Revision | ECN | Orig. of Change | Submission Date | Description of Change |
|----------|---------|-----------------|-----------------|--|
| ** | 5419492 | JETT | 07/29/16 | New Code Example. |
| *A | 5448672 | YFS | 9/25/16 | Added workspace file. |
| *B | 5453277 | YFS | 9/28/16 | Changed the workspace folder name. Moved the PDF file. Corrected the Documentation entry in XML file. |
| *C | 5775223 | YFS | 6/15/17 | Added search keyword so that user can quickly find Code Examples from the component instance popup menu. Updated logo and copyright date. |
| *D | 5987580 | YFS | 12/7/17 | Removed S6E1B support. |

Worldwide Sales and Design Support

Cypress maintains a worldwide network of offices, solution centers, manufacturer's representatives, and distributors. To find the office closest to you, visit us at [Cypress Locations](#).

Products

| | |
|-------------------------------|--|
| ARM® Cortex® Microcontrollers | cypress.com/arm |
| Automotive | cypress.com/automotive |
| Clocks & Buffers | cypress.com/clocks |
| Interface | cypress.com/interface |
| Lighting & Power Control | cypress.com/powerpsoc |
| Memory | cypress.com/memory |
| PSoC | cypress.com/psoc |
| Touch Sensing | cypress.com/touch |
| USB Controllers | cypress.com/usb |
| Wireless/RF | cypress.com/wireless |

PSoC® Solutions

[PSoC 1](#) | [PSoC 3](#) | [PSoC 4](#) | [PSoC 5LP](#)

Cypress Developer Community

[Forums](#) | [Projects](#) | [Videos](#) | [Blogs](#) | [Training](#) | [Components](#)

Technical Support

cypress.com/support



Cypress Semiconductor
198 Champion Court
San Jose, CA 95134-
1709

Phone : 408-943-2600
Fax : 408-943-4730
Website : www.cypress.com

© Cypress Semiconductor Corporation, 2016-2017. This document is the property of Cypress Semiconductor Corporation and its subsidiaries, including Spansion LLC ("Cypress"). This document, including any software or firmware included or referenced in this document ("Software"), is owned by Cypress under the intellectual property laws and treaties of the United States and other countries worldwide. Cypress reserves all rights under such laws and treaties and does not, except as specifically stated in this paragraph, grant any license under its patents, copyrights, trademarks, or other intellectual property rights. If the Software is not accompanied by a license agreement and you do not otherwise have a written agreement with Cypress governing the use of the Software, then Cypress hereby grants you a personal, non-exclusive, nontransferable license (without the right to sublicense) (1) under its copyright rights in the Software (a) for Software provided in source code form, to modify and reproduce the Software solely for use with Cypress hardware products, only internally within your organization, and (b) to distribute the Software in binary code form externally to end users (either directly or indirectly through resellers and distributors), solely for use on Cypress hardware product units, and (2) under those claims of Cypress's patents that are infringed by the Software (as provided by Cypress, unmodified) to make, use, distribute, and import the Software solely for use with Cypress hardware products. Any other use, reproduction, modification, translation, or compilation of the Software is prohibited.

TO THE EXTENT PERMITTED BY APPLICABLE LAW, CYPRESS MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS DOCUMENT OR ANY SOFTWARE OR ACCOMPANYING HARDWARE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. To the extent permitted by applicable law, Cypress reserves the right to make changes to this document without further notice. Cypress does not assume any liability arising out of the application or use of any product or circuit described in this document. Any information provided in this document, including any sample design information or programming code, is provided only for reference purposes. It is the responsibility of the user of this document to properly design, program, and test the functionality and safety of any application made of this information and any resulting product. Cypress products are not designed, intended, or authorized for use as critical components in systems designed or intended for the operation of weapons, weapons systems, nuclear installations, life-support devices or systems, other medical devices or systems (including resuscitation equipment and surgical implants), pollution control or hazardous substances management, or other uses where the failure of the device or system could cause personal injury, death, or property damage ("Unintended Uses"). A critical component is any component of a device or system whose failure to perform can be reasonably expected to cause the failure of the device or system, or to affect its safety or effectiveness. Cypress is not liable, in whole or in part, and you shall and hereby do release Cypress from any claim, damage, or other liability arising from or related to all Unintended Uses of Cypress products. You shall indemnify and hold Cypress harmless from and against all claims, costs, damages, and other liabilities, including claims for personal injury or death, arising from or related to any Unintended Uses of Cypress products.

Cypress, the Cypress logo, Spansion, the Spansion logo, and combinations thereof, WICED, PSoC, CapSense, EZ-USB, F-RAM, and Traveo are trademarks or registered trademarks of Cypress in the United States and other countries. For a more complete list of Cypress trademarks, visit cypress.com. Other names and brands may be claimed as property of their respective owners.